



7.1 - Wiring Connectors: Digital Input




POSITIVE LOGIC vs. NEGATIVE LOGIC WIRING:
The Canvas 5 can be wired for Positive Logic inputs or Negative Logic inputs.


7.2 - Wiring Connectors: Digital Output



7.3 - Wiring Connectors: Analog Input




7.4 - Wiring Connectors: Power



Primary Power Port Pins		
PIN	SIGNAL	DESCRIPTION
1	Ground	Frame Ground
2	DC-	Input Power Supply Ground
3	DC+	Input Power Supply Voltage

NOTE: Primary Power Range: 24VDC ±20%VDC



8 - Precautions

All applicable codes and standards need to be followed in the installation of this product. Adhere to the following safety precautions whenever any type of connection is made to the module:

1. Connect the safety (earth) ground on the power connector first before making any other connections.
2. When connecting to the electric circuits or pulse-initiating equipment, open their related breakers.
3. Do NOT make connection to live power lines.
4. Make connections to the module first; then connect to the circuit to be monitored.
5. Route power wires in a safe manner in accordance with good practice and local codes.
6. Wear proper personal protective equipment including safety glasses and insulated gloves when making connections to power circuits.
7. Ensure hands, shoes, and floor are dry before making any connection to a power line.
8. Make sure the unit is turned OFF before making connection to terminals.
9. Make sure all circuits are de-energized before making connections.
10. Before each use, inspect all cables for breaks or cracks in the insulation. Replace immediately if defective.
11. Use copper conductors in Field Wiring only, 60/75°C.
12. Do not disconnect while circuit is live unless area is known to be non-hazardous.
13. Do not remove or replace jumpers or connectors while circuit is live unless the area is known to be free of ignitable concentrations of flammable gases or vapors.
14. EXPLOSION HAZARD - substitution of components may impair suitability for intended use.

15. Use caution when making connections to the controller to protect against static discharge. Special care must be taken when replacing the battery or inserting or adjusting I/O or communication boards.
16. Use caution when connecting controllers to PCs via serial or USB. PCs and especially laptops may use "floating power supplies" that are ungrounded. This could cause a voltage potential between the laptop and controller. Ensure the controller and laptop are grounded for maximum protection. Consider using a USB isolator due to voltage potential differences as a preventative measure.
17. Failure to follow these guidelines can damage the controller and/or controller.

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 1. This device may not cause harmful interference.
 2. This device must accept any interference received, including interference that may cause undesired operation.

Technical Support

For assistance and manual updates, contact Technical Support at the following locations:

North America +1 (317) 916-4274 www.hornerautomation.com techsppt@heapg.com	Europe +353 (21) 4321-266 www.hornerautomation.eu technical.support@horner-apg.com
---	--

Canvas 5

HE-CV-043C-01

BUILT-IN I/O: 4 DIGITAL DC INPUTS, 4 DIGITAL DC OUTPUTS, 4 ANALOG INPUTS

GETTING STARTED

1. Read this document to fully understand the Canvas 5 and safety requirements
2. Connect 24VDC power and I/O according to the quick reference guide and data sheet.
3. Refer to the Canvas 5 User Manual for further instructions, MAN1372, or the Canvas 5 datasheet, MAN1374.



MAN1373_00_EN_CV5_QRG

1 - General Specifications

1.1 General	
Primary Power Range	10-30VDC
Inrush Current	20A for < 1 ms at 24VC DC Switched
Relative Humidity	5 to 95% Non-condensing
Operating Temp.	-10°C to +60°C
Storage Temp.	-30°C to +70°C
Weight	10 oz / 271 g
Included in Box	Controller, 3 x I/O connectors, 4 x mounting clips, 1 x power connector, Quick Reference Guide
Altitude	Up to 2000m
Rated Pollution Degree	Evaluated for Pollution Degree 2 Rating
Certifications (UL/CE)	USA: https://hornerautomation.com/certifications/ Europe: http://www.horner-apg.com/en/support/certification.aspx

2 - Port Connectors

1.2 Connectivity	
Serial Ports	2 (1xRS-232, 1x2-wire [half duplex] RS-485)
CAN	CAN 125kbps - 1Mbps
Ethernet	1 x 10Mbps/100Mbps
USB (2)	1 x Mini Program, 1 x USB Flash
microSD	1 x SD, SDHC, SDXC in FAT32 format

1.3 User Interface / Control & Logic	
Display	Resistive 4.3" Touchscreen 450 cd/m ² (nits)
Resolution	WVGA (480 x 272)
Backlight	White LED
Control Language Support	Advanced ladder logic Full IEC 61131-3 languages



1. Power
2. Input Connector
3. CAN Port
4. Serial Ports
5. Ethernet Port
6. USB A Port
7. Output Connector
8. DIP Switches
9. USB Mini B Port
10. microSD Slot


NOTE: See Precaution #16 about USB and grounding.

3 - Installation Procedure

The Canvas 5 utilizes a clip installation method to ensure a robust and watertight seal to the enclosure. Please follow the steps below for the proper installation and operation of the unit. This equipment is a panel mounted device and is meant to be installed in an enclosure suitable for the environment, such that the equipment is only accessible with the use of a tool.

1. Carefully locate an appropriate place to mount the Canvas 5. Be sure to leave enough room at the top of the unit for insertion and removal of the microSD™ card.
2. Carefully cut the host panel per the diagram, creating a 90.5mm x 119.5mm (with a tolerance of +0.5mm-0mm) opening into which the Canvas 5 may be installed. If the opening is too large, water may leak into the enclosure, potentially damaging the unit. If the opening is too small, the OCS may not fit through the hole without damage.
3. Remove any burrs and or sharp edges and ensure the panel is not warped in the cutting process.
4. Install and tighten the four mounting clips (provided in the box) until the gasket forms a tight seal. For included metal mounting clips, use a torque rating of 7-10 in-lbs (0.79-1.13 N-m).
5. Connect communications cables to the serial port, USB ports, and CAN port as required.

4 - Panel Cutout



5 - Hazardous Location Notice

1. THIS EQUIPMENT IS SUITABLE FOR USE IN CLASS I, DIVISION 2, GROUPS A B C D or NON-HAZARDOUS LOCATIONS ONLY.
2. **WARNING - EXPLOSION HAZARD - SUBSTITUTION OF COMPONENTS MAY IMPAIR SUITABILITY FOR CLASS I, DIVISION 2.**
AVERTISSEMENT - RISQUE D'EXPLOSION LA SUBSTITUTION DE COMPOSANTS PEUT RENDRE MATE RIEL INACCEPTABLE POUR LES EMPLACEMENTS DE CLASSE I, DIVISION 2
3. **WARNING - EXPLOSION HAZARD - DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NON-HAZARDOUS AND FREE OF IGNITABLE CONCENTRATIONS.**
ATTENTION - RISQUE D'EXPLOSION - NE DECONNECTEZ PAS L'EQUIPEMENT A MOINS DE L'AVOIR MIS HORS TENSION OU QUE LA ZONE EST CONNUE NON-DANGEREUSE ET NE CONTIENT PAS DE CONCENTRATIONS INFLAMMABLES.
4. **WARNING - BATTERY MAY EXPLODE IF MISTREATED. DO NOT RECHARGE, DISASSEMBLE, OR DISPOSE OF IN FIRE.**
AVERTISSEMENT - LA BATTERIE PEUT EXPLOSER SI ELLE EST MALTRAITÉE. NE PAS RECHARGER, DÉMONTER OU JETER AU FEU.

6 - Connecting the Canvas 5 to a PC

The Canvas 5 can communicate with Cscape using USB to USB, USB to serial adapters, serial port communications via M/J Port, or CAN (CsCAN).

To communicate with the Canvas 5 via USB you will need the Automated Driver Installer located on our website. The drivers may be loaded from the HE-XEC Ethernet Utility / HTTP Web Server Demo / Communications Driver section of the support files page found at : <https://hornerautomation.com/support-files>

Next, connect a PC's (Personal Computer running a Windows Microsoft operating system) USB port via USB cable to the USB mini B port on the Canvas 5.

Now that the Canvas 5 is plugged in, go to the Cscape menu Controller > Connection Wizard, choose the connection method. If connecting for the first time, USB is the suggested connection method.

If communication is established, the target indicator will show the mode of the controller Target: yy(R).

If the controller is not communicating, you may need to set the Target ID of the controller in Cscape or change the controllers ID on the unit itself. The Target ID allows directing communications to a particular unit when multiple units are connected via a CsCAN network. Units without CsCAN network ports respond to any network ID and do not require the ID to be configured.

For more information, review the Cscape Configuration chapter of the Canvas 5 User Manual, MAN1372.