

Industrial controls

Soft starters and semiconductor switching devices SIRIUS 3RW50 soft starter

Equipment Manual

Siemens Industry Online Support	1
Safety information	2
Description	3
Mounting and dismantling	4
Connecting	5
Parameter assignment	6
Commissioning	7
Functions	8
Messages and diagnosis	9
Maintenance and service	10
Technical specifications	11
Dimension drawings	12
Circuit diagrams	13
Example circuits	A

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

DANGER

indicates that death or severe personal injury **will** result if proper precautions are not taken.

WARNING

indicates that death or severe personal injury **may** result if proper precautions are not taken.

CAUTION

indicates that minor personal injury can result if proper precautions are not taken.

NOTICE

indicates that property damage can result if proper precautions are not taken.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified persons are those who, because of their training and experience, are familiar with the installation, assembly, commissioning, operation, decommissioning and disassembly of the product and can recognize risks and avoid possible hazards.

Proper use of Siemens products

Note the following:

WARNING

Siemens products may only be used for the application described in the catalog and the associated usage information. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of Siemens Aktiengesellschaft. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Table of contents

1	Siemens Industry Online Support.....	9
1.1	Siemens SiePortal Support	9
1.2	Support Request	10
1.3	Additional documentation	11
2	Safety information.....	13
2.1	ESD Guidelines.....	13
2.2	Five safety rules for work in or on electrical installations	16
2.3	Reactive power compensation.....	17
2.4	Electromagnetic compatibility (EMC) according to IEC 60947-4-1	17
2.5	Cybersecurity information	17
2.6	ATEX / IECEx.....	18
2.6.1	Use in hazardous areas.....	18
2.6.2	ATEX / IECEx-certified motor overload protection.....	18
2.7	Protection against unauthorized actuation.....	21
2.8	Preventing automatic restart following reset.....	21
2.9	Firmware update.....	21
2.10	Recycling and disposal	22
3	Description.....	23
3.1	Target group	23
3.2	History.....	23
3.3	Device design	24
3.4	Operating principle	24
3.5	Access options for the 3RW50 soft starter.....	27
3.6	Operating modes and master control function.....	29
3.6.1	Operating modes.....	29
3.6.2	Sets the operating mode	31
3.7	Device versions	34
3.8	Areas of application / load types	35
3.9	Selection of the soft starter using the Simulation Tool for Soft Starters.....	36
3.10	Structure of the article number	37
3.11	Accessories	38
3.11.1	Accessories for 3RW50 soft starters	38
3.11.2	3RW5 communication module	39

3.11.3	SIRIUS Soft Starter ES (TIA Portal)	40
3.11.4	3RW5 HMI	42
4	Mounting and dismantling	45
4.1	Installing 3RW50 soft starters.....	45
4.2	Mounting the fan cover.....	45
4.3	Mount the 3RW50 soft starter on a level surface.....	46
4.4	Connecting the 3RW5 HMI	48
4.4.1	Connect the HMI connecting cable to the 3RW50 soft starter	48
4.4.2	Installing the Standard 3RW5 HMI into the control cabinet door	49
4.4.3	Installing the High Feature 3RW5 HMI in the control cabinet door	51
4.4.4	Installing the Standard 3RW5 HMI on a flat surface	54
4.4.5	Installing the High Feature 3RW5 HMI on a flat surface	56
4.4.6	Removing and installing the hinged cover of the 3RW50 soft starter	57
4.5	3RW5 communication module	58
4.5.1	Installing the 3RW5 communication module on a level surface	58
4.5.2	Removing the 3RW5 communication module on a level surface	60
4.5.3	COM connection cable	61
4.5.3.1	Connecting the COM connecting cable to the 3RW50 soft starter.....	61
4.5.3.2	Connecting the COM connecting cable to the 3RW5 communication module	62
4.5.3.3	Removing the COM connecting cable on the 3RW5 communication module.....	63
4.5.3.4	Remove the COM connecting cable on the 3RW50 soft starter	64
5	Connecting	67
5.1	Connections	67
5.1.1	Overview of all connections	67
5.1.2	State diagrams of the inputs and outputs	69
5.2	Connecting the 3RW50 soft starter.....	70
5.3	Connecting the 3RW50 soft starter to the main circuit connection (mains / motor)	71
5.4	Mounting and dismantling box terminal blocks	72
5.5	Mounting terminal covers on main circuit connections	74
5.6	Connecting the control terminals (screw terminals)	75
5.7	Disconnecting the control current form the screw-type terminals.....	76
5.8	Connecting the control terminals (spring-type terminals).....	77
5.9	Disconnecting the control current from the spring-loaded terminals	78
5.10	Replacing the control terminals	79
6	Parameter assignment.....	81
6.1	Setting elements on 3RW50 soft starter.....	81
6.2	Overview of parameters	83
6.3	Suggested settings.....	84
6.4	Parameterizing the 3RW50 soft starter	84
6.5	Setting RESET MODE and Soft Torque	85

6.6	RESET MODE.....	87
6.7	Parameterizing output 13 / 14 (output signal ON or RUN)	88
6.8	Parameterize the response to bus errors and output 13, 14 (ON / RUN)	89
6.9	Design and operator controls of the High Feature 3RW5 HMI	92
6.10	Menu of the 3RW5 HMI High Feature	93
6.11	Parameterizing analog output AQ via the High Feature 3RW5 HMI	101
6.12	Parameterizing the High Feature 3RW5 HMI	103
6.13	Parameterize 3RW5 HMI High Feature serially / identically.....	105
7	Commissioning	107
7.1	Commissioning the 3RW50 soft starter.....	107
7.2	Sealing the 3RW50 soft starter	107
7.3	First commissioning of the High Feature 3RW5 HMI.....	108
8	Functions	111
8.1	Soft starting	111
8.2	Current limiting function.....	113
8.3	Soft stopping	115
8.4	Motor protection.....	116
8.4.1	Electronic motor overload protection.....	117
8.4.2	Thermistor motor protection with temperature sensor (optional)	118
8.5	Intrinsic device protection	119
8.6	Soft torque	119
8.7	ATEX / IECEx-certified motor overload protection.....	121
8.8	Functions under "Additional parameters".....	124
8.9	Test mode.....	125
8.10	Test with small load	126
8.11	Response to bus errors / Control via digital input.....	127
8.12	3RW5 HMI Standard	129
8.12.1	Design of the Standard 3RW5 HMI	129
8.12.2	Standard 3RW5 HMI menu	130
8.12.3	Display of the error number with 3RW5 HMI Standard.....	132
8.13	3RW5 HMI High Feature	133
8.13.1	Monitoring	133
8.13.1.1	Monitoring the measured values of the 3RW50 soft starter with the 3RW5 HMI High Feature.....	133
8.13.1.2	Graphic display of measured values on the 3RW5 HMI High Feature.....	134
8.13.1.3	Monitoring the process image of the 3RW50 soft starter with the 3RW5 HMI High Feature...	136
8.13.2	Overview	138
8.13.3	Local access protection (PIN)	139
8.13.3.1	Define PIN.....	140

8.13.3.2	Change PIN	141
8.13.3.3	Delete PIN	142
8.13.4	Micro SD card	142
8.13.5	Reloading a language for the High Feature 3RW5 HMI	144
9	Messages and diagnosis	147
9.1	Diagnostics options	147
9.2	LED display	148
9.2.1	Overview of the device LEDs of the 3RW50 soft starter	148
9.2.2	Status and error displays	149
9.2.3	STATE / OVERLOAD LED	150
9.2.4	Overview of LEDs on Standard 3RW5 HMI	150
9.2.5	Overview of LEDs on High Feature 3RW5 HMI	151
9.3	Warnings and remedial actions of the 3RW50 soft starter	152
9.4	Faults and remedial actions of the 3RW50 soft starter	153
9.5	Faults and remedial actions of the 3RW5 HMI High Feature	158
9.6	Performing diagnostics of the 3RW50 soft starter with the 3RW5 HMI High Feature	159
9.7	Performing diagnostics of the 3RW5 communication module with the 3RW5 HMI High Feature	162
9.8	Execute HMI diagnostics with the 3RW5 HMI High Feature	163
9.9	Self-test (user-test)	164
9.10	Logbooks	168
9.11	Save service data to micro SD card	169
10	Maintenance and service	173
10.1	Maintenance and repairs	173
10.2	Replacing the fan	173
10.3	Firmware update	176
10.4	Performing firmware update with micro SD card (3RW5 HMI High Feature)	177
10.5	Restoring factory setting	178
10.5.1	Effects of the factory setting	178
10.5.2	Restoring the factory settings via High Feature 3RW5 HMI	179
10.5.3	Restoring the factory settings with the Master RESET button via 3RW5 HMI High Feature... ..	180
10.5.4	Restoring the factory settings with the MODE and RESET / TEST keys	180
10.6	"Device change" function	181
10.6.1	Device change with micro SD card on the 3RW5 HMI High Feature	182
10.6.2	Device change with SIRIUS Soft Starter ES (TIA Portal)	183
11	Technical specifications	185
11.1	Product information in the Siemens SiePortal	185
12	Dimension drawings	187
12.1	Product information in the Siemens SiePortal	187
12.2	Drilling pattern for 3RW5 HMI Standard	187

12.3	Drilling pattern for 3RW5 HMI High Feature	188
12.4	Drilling patterns for 3RW5 communication module on the 3RW50 soft starter	189
13	Circuit diagrams	191
13.1	Product information in the Siemens SiePortal	191
A	Example circuits	193
A.1	Main circuit connection	193
A.1.1	Feeder assembly, type of coordination 1 fuseless	193
A.1.2	Feeder assembly, type of coordination 1 with fuses	194
A.1.3	Feeder assembly, type of coordination 2	195
A.2	Control current connection	196
A.2.1	Control by pushbutton	196
A.2.2	Control by switch	198
A.2.3	Switching with the control supply voltage	199
A.2.4	Control by PLC	201
A.2.5	Actuation of a line contactor	202
A.2.6	Wiring for remote RESET	204
A.2.7	Connecting the temperature sensor	204
A.2.8	Connecting the evaluation unit to the analog output	205
A.3	Special applications	207
A.3.1	Reversing circuit	207
A.3.2	Wiring for ATEX / IECEx applications with additional line contactor	209
A.3.3	Controlling a motor with a magnetic parking brake	211
A.3.4	EMERGENCY STOP shutdown to SIL 1 or PL c with a 3SK1 safety relay	212
A.3.5	EMERGENCY STOP shutdown to SIL 3 or PL e with a 3SK1 safety relay	214
A.3.6	Contact for emergency start	218
	Glossary	221
	Index	223

Siemens Industry Online Support

1.1 Siemens SiePortal Support

At Siemens SiePortal Support you can obtain up-to-date information from our global support database: You can also define your personal workspace.

Support

You can find information and comprehensive know-how covering all aspects of your product here:

- **Solution Guide**
Our AI functionality answers your questions based on verified technical product information.
- **Manuals/operating instructions**
Read online or download, available as PDF or individually configurable.
- **Downloads**
Here you will find updates, service packs, HSPs and much more for your product.
- **Certificates**
Clearly sorted according to approving authority, type and country.
- **Characteristics**
For support in planning and configuring your system.
- **Catalogs / Brochures**
Read online or download, available as PDF.
- **Technical data**
Technical product data for support in planning and implementing your project
- **Product announcements**
The latest information and news concerning our products.
- **Forum**
Harness the potential of our community.
- **FAQs**
Answers to frequently asked questions
- **Application examples**
Function blocks, background and system descriptions, performance statements, demonstration systems, and application examples, clearly explained and represented.

Link: Siemens SiePortal Support (<https://sieportal.siemens.com/en-ww/support>)

mySiePortal

The following functions are available in your personal work area "mySiePortal":

- **My conversations**
Overview of your previous conversations.
- **Installed products**
Your registered products are displayed here.
- **Service requests**
Overview of your previous support requests.
- **Lists & notifications**
Here you can view your search queries, favorites, notifications and lists of products.
- **Product data & documentation**
Easy access to CAx data, e.g. 3D models, 2D dimension drawings, EPLAN macros, device circuit diagrams
- **My Quicklinks**
Compile a list of frequently used links to access information more quickly.

Siemens Industry Online Support app

The Siemens Industry Online Support app provides you access to all the device-specific information available on the Siemens Industry Online Support portal for a particular article number, such as operating instructions, manuals, data sheets, FAQs etc.

The Siemens Industry Online Support app is available for Android and iOS:



Android



iOS

1.2 Support Request

You can submit and manage support requests in the mySupport Cockpit. To do this, you must register once.

Support request:	Internet (https://support.industry.siemens.com/My/ww/en/requests)
------------------	--

1.3 Additional documentation

Manuals / online help

At this point, you will find further manuals and online help that may be of interest to you for your automation system. They are available to download from the Internet free of charge. You can create your own individual system documentation in mySupport.

- 3RW5 topic page (<https://support.industry.siemens.com/cs/ww/en/view/109747404>)
- Equipment Manual for the 3RW50 soft starter (<https://support.industry.siemens.com/cs/ww/en/view/109753750>)
- Equipment Manual for the 3RW52 soft starter (<https://support.industry.siemens.com/cs/ww/en/view/109753751>)
- Equipment Manual for the 3RW55 and 3RW55 Failsafe Soft Starters (<https://support.industry.siemens.com/cs/ww/en/view/109753752>)
- Equipment Manuals for the 3RW5 soft starter (<https://support.industry.siemens.com/cs/ww/en/ps/16212/man>)
- Equipment Manual for the 3RW5 PROFINET communication modules (<https://support.industry.siemens.com/cs/ww/en/view/109753754>)
- Equipment Manual for the 3RW5 PROFIBUS communication module (<https://support.industry.siemens.com/cs/ww/en/view/109753753>)
- Equipment Manual for the 3RW5 Modbus communication modules (<https://support.industry.siemens.com/cs/ww/en/view/109753755>)
- Equipment Manual for the 3RW5 EtherNet/IP communication module (<https://support.industry.siemens.com/cs/ww/en/view/109758201>)
- Online help for SIRIUS Soft Starter ES (TIA Portal)
- Online help for STEP 7
- The EMC Directive 2014/30/EU in practice (<http://www.siemens.com/emc-guideline>)
- Industrial Control Panels and Electronic Equipment of Industrial Machinery for North America (<http://www.siemens.com/UL508A>)
- Control Panels compliant with IEC Standards and European Directives (<http://www.siemens.com/iec60204>)

Interesting links

- Manuals in Siemens Industry Online Support (<https://support.industry.siemens.com/cs/ww/en/ps/man>)
- FAQs for soft starters 3RW5 (<https://support.industry.siemens.com/cs/ww/en/ps/16212/faq>)
- Downloads for soft starters 3RW5 (<https://support.industry.siemens.com/cs/ww/en/ps/16212/dl>)
- Catalog IC 10 (<https://support.industry.siemens.com/cs/ww/en/view/109747945>)
- Product support for STEP 7 (TIA Portal) (<https://support.industry.siemens.com/cs/ww/en/ps/14672>)

Safety information

2.1 ESD Guidelines

ESD

All electronic devices are equipped with large-scale integrated ICs or components. Due to their design, these electronic elements are highly sensitive to overvoltage, and thus to any electrostatic discharge.

ESD devices are identified by the following symbol:




NOTICE
Electrostatic discharge ESD devices can be destroyed by voltages well below the threshold of human perception. These static voltages develop when you touch a component or electrical connection of a device without having drained the static charges present on your body. The damage caused to a device by overvoltage is usually not immediately evident and is only noticed after an extended period of operation.

Electrostatic charging

Anyone who is not connected to the electrical potential of their surroundings can be electrostatically charged.

The diagram below shows the maximum electrostatic voltage which may build up on a person coming into contact with the materials specified in the diagram. These values are in conformity with the specifications of IEC 61000-4-2.



NOTICE**Protective measures against damage to equipment due to discharge of static electricity**

Electronic devices contain components that can be damaged by electrostatic discharge if they are handled improperly.

- **Grounding/discharge**

When handling electrostatic sensitive devices, ensure that your body, the workplace, and packaging are grounded. In this way, you can avoid becoming electrostatically charged. Discharge your body electrostatically immediately before touching an electronic component. To do this, touch a conductive, grounded object, e.g., a bare metal part of a switch cabinet or the water pipe.

Electrostatically sensitive devices should not be brought into contact with electrically insulating materials such as plastic film, plastic parts, insulating table supports, or clothing made of synthetic fibers.

- **Direct contact**

Only touch electrostatic sensitive devices when this is unavoidable (e.g. during maintenance work). Handle the devices, if possible, only by the plastic enclosure and without touching any chip pins or PCB traces. In this way, the discharged energy cannot reach or damage sensitive devices.

Discharge your body before taking any necessary measurements on a device. Do so by touching grounded metallic parts. Use only grounded measuring instruments.

Always place an electrostatic sensitive device on conductive bases.

- **Storage and transport**


Always store and transport electrostatic sensitive devices or components in ESD-safe conductive packaging, e.g. metallized plastic or metal containers. Leave the device in its packaging until installation.

NOTICE**Storage and transport in non-conductive packaging**

If you have to store or transport the electrostatic sensitive device in non-conductive packaging, you must first pack the device in ESD-safe, conductive material, e.g., conductive foam rubber, ESD bag.

The diagrams below illustrate the required ESD protective measures for electrostatic sensitive devices.

2.2 Five safety rules for work in or on electrical installations



- ① ESD seat
- ② ESD standing position
- ③ ESD seat and ESD standing position

Protective measures

- a Conductive floor
- b ESD table
- c ESD shoes
- d ESD smock
- e ESD bracelet
- f Cabinet ground connection

2.2 Five safety rules for work in or on electrical installations

A set of rules, which are summarized in DIN VDE 0105 as the "five safety rules", are defined for working in or on electrical systems as a preventative measure against electrical accidents:

1. Isolate
2. Secure against reclosing
3. Verify absence of operating voltage
4. Ground and short-circuit
5. Provide protection against adjacent live parts

These five safety rules must be applied in the above order prior to starting work on an electrical system. After completing the work, proceed in the reverse order.

It is assumed that every electrically skilled person is familiar with these rules.

Explanations

1. The isolating distances between live and de-energized parts of the system must vary according to the operating voltage that is applied.
"Isolate" refers to the all-pole disconnection of live parts.
2. The feeder must be locked against inadvertent reconnection to ensure that it remains isolated for the duration of the work. This can be achieved, for instance, by locking the motor and system circuit breakers in the OFF position or by unscrewing the fuses and using lockable elements to prevent them from being reinserted.

3. The de-energized state of the equipment should be verified using suitable test equipment, e.g. a 2-pole voltmeter. 1-pole test pins are not suitable for this purpose. The absence of power must be established for all poles, phase to phase, and phase to N/PE.
4. Grounding and short-circuiting are only mandatory if the system has a rated voltage greater than 1 kV. In this case, the system should always be grounded first and then connected to the live parts to be short-circuited.
5. These parts should be covered, or barriers erected around them, to avoid accidental contact during the work with adjacent parts that are still live.

2.3 Reactive power compensation

Capacitors for improving the power factor (reactive power compensation)

Do not connect any capacitors to the output terminals of the 3RW5 soft starter. If capacitors are connected to the output terminals, the 3RW5 soft starter will be damaged.

Do not operate active filters, e.g. for reactive power compensation, parallel to the 3RW5 soft starter.

If you use capacitors to correct the power factor (actively or passively), you must connect them on the line side of the 3RW5 soft starter. Make sure that the capacitors do not actively control the power factor during the starting and coasting down phases. If you use a contactor disconnect or main contactor together with the 3RW5 soft starter, the capacitors must be disconnected from the 3RW5 soft starter when the contactor is open.

You will find further information in the Internet (<https://support.industry.siemens.com/cs/ww/en/view/67131557>).

2.4 Electromagnetic compatibility (EMC) according to IEC 60947-4-1

This product is designed for use in Environment A. Use of this product in Environment B may cause unwanted electromagnetic interference, in which case the user may be required to take adequate mitigation measures.

2.5 Cybersecurity information

Siemens provides products and solutions with industrial cybersecurity functions that support the secure operation of plants, systems, machines and networks.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial cybersecurity concept. Siemens' products and solutions constitute one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. Such systems, machines and components should only be connected to an enterprise network or the internet if and to the extent such a connection is necessary

2.6 ATEX / IECEx

and only when appropriate security measures (e.g. firewalls and/or network segmentation) are in place.

For additional information on industrial cybersecurity measures that may be implemented, please visit

<https://www.siemens.com/cybersecurity-industry>.

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends that product updates are applied as soon as they are available and that the latest product versions are used. Use of product versions that are no longer supported, and failure to apply the latest updates may increase customer's exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Cybersecurity RSS Feed under

<https://www.siemens.com/cert>.

2.6 ATEX / IECEx

2.6.1 Use in hazardous areas

The components of the 3RW50 soft starters are not suitable for installation in hazardous areas. Use the device only in a control cabinet with at least degree of protection IP 4x.

If you have any questions, ask your ATEX / IECEx expert.

2.6.2 ATEX / IECEx-certified motor overload protection

Environmental conditions

Comply with the ambient conditions for which the 3RW50 soft starter is approved.

Note

Ambient temperature during operation.

Note that the 3RW50 soft starters are approved for operation in a temperature range of -25 °C to +60 °C.

In ambient temperatures higher than 40 °C, take the derating of the rated operational current into consideration.

You can find more information on derating in the data sheet, see Chapter "Technical specifications (Page 185)", section "Power electronics" or in Catalog IC 10 (<https://support.industry.siemens.com/cs/ww/en/view/109747945>).

Note**Temperature sensor**

For ATEX / IECEx-certified motor protection, use of the PTC type A sensor only is approved.

Note**Simulation Tool for Soft Starters**

Note that the Simulation Tool for Soft Starters (Page 36) already takes into account the derating for certain ambient temperatures when selecting a suitable 3RW5 soft starter.

Parameterizing the soft starter

The parameters for ATEX / IECEx applications are to be set using the setting elements of the 3RW50 soft starter.

Setting the rated motor operational current

Set the 3RW50 soft starter to the rated operational current of the motor as stated on the nameplate or prototype test certificate of the motor.

Tripping class (electronic overload protection)

Make sure that the motor and the cables are dimensioned for the selected tripping class.

- Note that the trip class "CLASS OFF" when operating motors in hazardous areas is only permissible if a "PTC thermistor type A" temperature sensor is used.
The rated data of the 3RW5 soft starter relates to normal starting (CLASS 10E). For heavy starting (> CLASS 10E), you may have to overdimension the 3RW5 soft starter.
- For 3RW50 soft starters with an analog output, trip class "CLASS OFF" is not permitted in an ATEX / IECEx application.

Parameterizing the motor protection functions (RESET setting)

Note that the "Auto RESET" setting is not permissible when operating motors in hazardous areas.

Short-circuit protection

The 3RW50 soft starter does not have short-circuit protection. Make sure that short-circuit protection is provided.

Line protection

Avoid impermissibly high cable surface temperatures by correctly dimensioning the cross-sections. Select a sufficiently large conductor cross-section.

Cyclic test of the motor protection functions

Only perform the Self-test (user-test) (Page 164) locally by means of the RESET / TEST key or the 3RW5 HMI High Feature to ensure that the correct 3RW50 soft starter is tested. Only in this way can the certified motor overload protection according to ATEX / IECEx be guaranteed.

On soft starters in ATEX / IECEx applications, perform the Self-test (user-test) (Page 164) during commissioning and periodically at intervals of no more than 36 months.

Certification of the 3RW50 soft starters

The motor overload protection of the 3RW50 soft starters is ATEX / IECEx-certified to SIL 1.

The 3RW50 soft starters are approved under Equipment Groups I and II, Category (2) or (M2) in zones "G" and "D". Zones "G" and "D" are areas in which explosive gas, vapor, mist or air mixtures and combustible dust are present:

IECEx BVS 19.0053 X [Ex]

BVS 19 ATEX F001 X

II (2)G [EX eb Gb] [EX db Gb] [EX pxb Gb]¹⁾

II (2)D [EX tb Db] [EX pxb Db]

I (M2) [EX db Mb]

¹⁾ For the px applications, pressure and flow rate monitoring are additionally required for the pressurized enclosure systems.

Certified motor overload protection according to ATEX / IECEx



DANGER

**Loss of the certified motor overload protection according to ATEX/IECEx.
Will cause death or serious injury.**

Note that operation in the standard type of motor connection without implementing one of the two following remedial measures results in loss of certified motor overload protection according to ATEX / IECEx.

Depending on the structure of the circuit, choose one of the following possibilities for ensuring certified motor overload protection according to ATEX / IECEx:

- Use an additional line contactor in the main circuit.
Connect the line contactor at outputs 95, 96 and 98 (output 3).
- For a motor feeder configuration with a circuit breaker, use an additional undervoltage trip unit.
Connect the undervoltage trip unit at outputs 95, 96 and 98 (output 3).
You can find more information in Chapter Connections (Page 67).

Observing standards

Increased danger in hazardous areas means it is necessary to carefully observe the following standards:

- **IEC / EN 60079-14 / VDE 0165-1:** For electrical apparatus for hazardous areas.
- **IEC / EN 60079-17:** Inspection and maintenance of electrical installations in explosive atmosphere.
- **EN 50495:** Safety devices required for the safe functioning of equipment with respect to explosion risks.

ATEX/IECEx-specific safety data

ATEX/IECEx-specific safety data relating to 3RW50 soft starters can be found in the data sheet, see Chapter "Technical specifications (Page 185)".

Maintenance and repair

The 3RW50 soft starters are maintenance-free. The repair of soft starters with approval according to IEC 61508 / EN 13849 is only permissible in the manufacturer's plant.

A repair on 3RW50 soft starters that is not performed in the manufacturer's plant results in loss of ATEX / IECEx approval.

2.7 Protection against unauthorized actuation

Protect freely accessible operator controls on your machine / system against unauthorized actuation if this could result in a risk or danger. Take suitable action in this regard, for example, a lockable key-operated switch.

2.8 Preventing automatic restart following reset

If a starting command is pending, a restart will be triggered automatically after the reset. This particularly applies if the motor protection has tripped. Dangerous states of the system can result and it can cause death or serious injury.

To avoid that, reset the start command (e.g. via the PLC or switch) before performing a reset. To do this, for example, link the group error output (terminals 95 and 96) into the control.

2.9 Firmware update

To be able to use 3RW50 soft starters without any problem and with their full range of functions, ensure that all components have the latest firmware (Page 176):

- 3RW50 soft starter
- 3RW5 HMI High Feature (accessory)
- 3RW5 communication module (accessory)

2.10 Recycling and disposal

You will find current downloads and a history of the versions with new features on the 3RW5 topic page (<https://support.industry.siemens.com/cs/ww/en/view/109747404>).

2.10 Recycling and disposal

For environmentally-friendly recycling and disposal of your old device, contact a company certified for the disposal of used electrical and electronic equipment, and dispose of the device as specified in the regulations for your particular country.

Description

3.1 Target group

Target group

The manual is intended for everyone involved in the following tasks:

- Planning and configuring systems
- Installation
- Commissioning
- Service and maintenance

Requirements for use of 3RW5 soft starters


Basic knowledge of the following areas:

- General electrical engineering
- Drive technology
- Automation technology
- Handling the automation system and the software used

3.2 History

Release number	New features
09/2019	<ul style="list-style-type: none"> • Initial release
11/2021	<ul style="list-style-type: none"> • Revision of the Equipment Manual • Description adapted: "Certified motor overload protection according to ATEX / IECEx" • Supplement: Saving logbooks and service data • Revision of Chapter "Messages and diagnostics" • New Chapter: Replacing the fan
01/2023	<ul style="list-style-type: none"> • Revision of the Equipment Manual • Revision of warning messages on HMI Standard • UKEX added • Typical circuit diagram added
09/2026	<ul style="list-style-type: none"> • Removing UKEX

3.3 Device design



- ① Main circuit connection (mains supply)
- ② Control terminals (inputs / outputs)
- ③ Scale of the setting element I_e
You will also find the applicable scale in the Chapter "Technical specifications (Page 185)".
- ④ RESET / TEST key
- ⑤ Interface for 3RW5 HMI Standard (accessories) or 3RW5 HMI High Feature (accessories)
- ⑥ Setting elements for parameter assignment
- ⑦ MODE key
- ⑧ Interface for 3RW5 communication module (accessory)
- ⑨ Connectable conductor cross-sections
You will also find the applicable connectable conductor cross-sections in the Chapter "Technical specifications (Page 185)".
- ⑩ ID link (from 11/2022)
- ⑪ Diagnostics LEDs and RESET key
- ⑫ Eye for lead seal
- ⑬ Main circuit connection (motor)


3.4 Operating principle

Soft starters are used to start three-phase induction motors with reduced torque and reduced starting current.

The 3RW50 soft starter starts the motor as soon as the switch-on command is issued (t_1). During the ramp up time (t_1 to t_3), the current is conducted via power semiconductors (switching elements) which start the motor up smoothly.

The 3RW50 soft starter features internal run-up recognition. If a successful motor run-up is detected before the ramp up time elapses, the motor voltage is immediately increased to 100 % of the line voltage (t_2). The internal bypass contacts close and the power semiconductors are bypassed. The 3RW50 soft starter is in bypass operation.

Coast-down to zero speed is activated when the switch-on command is cancelled (t_4) and the motor is shut down. The power semiconductors also ensure that the motor coasts down smoothly to a stop. As long as the stopping time is active (t_4 to t_5), energy is still supplied to the motor. It may take longer for the motor to actually coast down to a standstill (t_6).



Functions

Note the information in Chapter Firmware update (Page 21).

- **Soft starting** with parameterizable starting voltage and ramp up time for a smooth starting of the drive
- **Soft stopping** with parameterizable stopping time for a smooth run-down of the drive
- Parameterizable **current limit** for avoiding current peaks
- **Soft torque** for smooth ramp up and ramp-down (avoiding torque peaks by means of torque limitation)

3.4 Operating principle


- **Integrated electronic motor overload protection** with adjustable tripping class (Off, CLASS 10A, 10E, 20E)
- **Intrinsic device protection** protects the 3RW50 soft starter against overload
- **Ramp-up detection**
- Extended operating and diagnostic functions provided by the optional **3RW5 HMI Standard** or **3RW5 HMI High Feature**
- Connection to motor in **standard circuit**
- Adjustable **RESET MODE** (Manual RESET, Remote RESET, Auto RESET) for the functions of motor protection
- Extended full motor protection via optional **thermistor motor protection** for connection of a temperature switch (e.g. Thermoclick) or a thermistor (e.g. PTC type A) (alternative to analog output)
- Optional **analog output** for displaying a measured value with the aid of an external display device (alternative to the thermistor motor protection)
- Optional **3RW5 communication module** for integration into bus systems
- **Firmware updates** upgrade the firmware of the respective device
- ATEX / IECEx certification

More information

You can find an overview of all of the functions of the 3RW5 soft starter in the Catalog IC 10 (<https://support.industry.siemens.com/cs/ww/en/view/109747945>).

Further details of the functions can be found in Chapter Functions (Page 111).

3.5 Access options for the 3RW50 soft starter



- ① SIRIUS 3RW50 Soft Starter
- ② LED display on 3RW50 soft starter
- ③ 3RW5 HMI Standard (accessories)
- ④ 3RW5 HMI High Feature (accessory) (firmware version V3.0 or higher)
- ⑤ PC with SIRIUS Soft Starter ES (TIA Portal) via local interface on 3RW5 HMI High Feature
- ⑥ Fieldbus (via optional communication module)
- ⑦ PC or programming device with configuration software of the controller (e.g. STEP 7)
- ⑧ Programmable logic controller (e.g. SIMATIC S7-1500)
- ⑨ PC with SIRIUS Soft Starter ES (TIA Portal) Premium / Professional via 3RW5 communication module
- ⑩ Motor

Options for data transfer

	Monitoring	Diagnostics	Control	Parameter assignment
3RW5 HMI High Feature	✓	✓	✓	— 2), 3)
3RW5 HMI Standard	✓	✓	✓	— 4)
SIRIUS Soft Starter ES (TIA Portal) ¹⁾	✓	✓	✓	— 3)

3.5 Access options for the 3RW50 soft starter

	Monitoring	Diagnostics	Control	Parameter assignment
Fieldbus via 3RW5 communication module	✓ (via user program)	✓	✓	–
3RW50 soft starter	LEDs	LEDs	Via input IN	Setting elements

- ¹⁾ Via the local interface on the 3RW5 HMI High Feature or via a 3RW5 communication module PROFINET or PROFIBUS.
- ²⁾ Analog output (for device version with analog output only) and ON / RUN relay output can be set.
- ³⁾ Communication parameters of all compatible communication modules can be set.
- ⁴⁾ Station address can be set for a 3RW5 PROFIBUS and Modbus RTU communication module.

3.6 Operating modes and master control function

In the "Automatic" mode the master control function rests with a higher-level control:

- PROFINET, PROFIBUS, EtherNet/IP: Programmable logic controller (PLC)
- Modbus TCP: Modbus Client (e.g. PLC)
- Modbus RTU: Modbus Master (e.g. PLC)

Operating mode "manual - bus"

For operating mode "manual - bus", you require a 3RW5 PROFINET or PROFIBUS communication module and a PC with SIRIUS Soft Starter ES (TIA Portal) Premium / Professional. The control source is connected to the 3RW50 soft starter via the 3RW5 communication module.

In operating mode "manual - bus", master control is with the SIRIUS Soft Starter ES (TIA Portal) Premium / Professional.

Operating mode "manual - local"

In the operating mode "manual - local" the master control function rests with a control source directly on the 3RW50 soft starter:

- Input IN
- 3RW5 HMI (accessories)
- SIRIUS Soft Starter ES (TIA Portal) via local interface on the 3RW5 HMI High Feature (accessory)

Priorities of the operating modes

Mode		Control source	Priority
Automatic		Higher-level control (e.g. PLC)	Lowest
Manual - bus (depending on the 3RW5 communication module)	-	Connection abort ¹⁾	↓
	PC controlled	SIRIUS Soft Starter ES (TIA Portal) Premium / Professional	↓
Manual - local	Input controlled	Input IN	↓ ²⁾
	3RW5 HMI controls	3RW5 HMI	↓
	PC controlled	SIRIUS Soft Starter ES (TIA Portal)	Highest

¹⁾ Explanation in text below

²⁾ Lowest priority without 3RW5 communication module

Connection abort

On failure of the bus connection or a CPU stop, the 3RW50 soft starter behaves independently of the mode in accordance with the parameter "Control via digital input" (Page 127).

If other connections between the control source and 3RW50 soft starter are aborted, the master control function automatically switches back to the lowest priority of the current mode.

- "Automatic" mode: The 3RW50 soft starter behaves in accordance with the parameter "Control via digital input" (Page 127).
- Operating mode "manual - bus": The master control function switches to "Manual - bus - Connection abort".
- Operating mode "manual - local": The master control function switches to "Manual - local - Input controlled".

Further information

You will find more information on the 3RW5 communication modules in the manual for the 3RW5 communication module in question.

3.6.2 Sets the operating mode

Fundamental response when changing the mode

A higher-priority mode can take over as master control from a lower-priority mode at any time; the reverse is not possible. The master control function can only be returned to the mode with the lowest priority. Control sources with higher priority must take the master control function from the mode with the lowest priority.

Requirements

- A mode with lower priority can only take the master control function back while the motor is switched off.
- For the "Automatic" mode and "Manual - bus" mode you require a 3RW5 communication module.

"Automatic" mode

Receive master control function

The "Automatic" mode receives the master control function from the "Manual - bus" or "Manual - local" mode as follows:

- Command in SIRIUS Soft Starter ES (TIA Portal) Premium / Professional (fieldbus)
Brief overview: Window "Task Card" > Tab "Online Tools" > "SIRIUS Control Panel > Master Control > Release Control"
- By disabling the "Manual operation local - input controlled" bit in the process image output (PIQ) or in the data table "Process image output (PIQ)" (depending on the 3RW5 communication module), the "Automatic" mode receives master control from the Input IN.

3.6 Operating modes and master control function

- Action "LOCAL / REMOTE" on the 3RW5 HMI
- Command in SIRIUS Soft Starter ES (TIA Portal) (local interface on the 3RW5 HMI High Feature)
Brief overview: Window "Task Card" > Tab "Online Tools" > "SIRIUS Control Panel > Master Control > Release Control"

Revocation of the master control by other control sources

In the "Automatic" mode, the master control function can be withdrawn from any control source.

Operating mode "manual - bus"

Assume master control

SIRIUS Soft Starter ES (TIA Portal) Premium / Professional actively fetches master control from the "Automatic" mode in response to a command to this effect.

Brief overview: Window "Task Card" > Tab "Online Tools" > "SIRIUS Control Panel > Master Control > Get Control"

Relinquish master control

SIRIUS Soft Starter ES (TIA Portal) Premium / Professional actively passes master control to "Automatic" mode in response to a command to this effect.

Brief overview: Window "Task Card" > Tab "Online Tools" > "SIRIUS Control Panel > Master Control > Release Control"

Revocation of the master control by other control sources

The master control function is withdrawn from the operating mode "manual - bus" by the operating mode "manual - local" as follows:

- Activation of the "Manual operation local - input controlled" bit in the process image output (PIQ) or in the data table "Process image output (PIQ)" (depending on the 3RW5 communication module)
- Action "LOCAL / REMOTE" on the 3RW5 HMI
- Command in SIRIUS Soft Starter ES (TIA Portal) (local interface on the 3RW5 HMI High Feature)
Brief overview: Window "Task Card" > Tab "Online Tools" > "SIRIUS Control Panel > Master Control > Get Control"

"Manual operation local - input controlled" mode

Assume master control

By enabling the "Manual operation local - input controlled" bit in the process image output (PIQ) or in the data table "Process image output (PIQ)" (depending on the 3RW5 communication module), the Input IN receives the master control function from the "Automatic" mode or operating mode "manual - bus".

If the master control function is on the 3RW5 HMI or, in the case of the local interface, on the 3RW5 HMI High Feature (higher priority), you must actively give up the master control function beforehand. Subsequently the Input IN can assume the master control function.

Relinquish master control

By disabling the "Manual operation local - input controlled" bit in the process image output (PIQ) or in the data table "Process image output (PIQ)" (depending on the 3RW5 communication module), the "Automatic" mode receives the master control function.

Revocation of the master control by other control sources

The master control function is withdrawn from the Input IN as follows:

- Action "LOCAL / REMOTE" on the 3RW5 HMI
- Command in SIRIUS Soft Starter ES (TIA Portal) (local interface on the 3RW5 HMI High Feature)
Brief overview: Window "Task Card" > Tab "Online Tools" > "SIRIUS Control Panel > Master Control > Get Control"

"Manual operation local - HMI controlled" mode

Assume master control

The 3RW5 HMI actively assumes the master control function via the action "LOCAL / REMOTE" from the lower priority control source.

If the master control function at the local interface on the 3RW5 HMI High Feature (higher priority), you must actively give up the master control function beforehand in SIRIUS Soft Starter ES (TIA Portal). You can then assume the master control function by means of the action "LOCAL / REMOTE".

Relinquish master control

The 3RW5 HMI actively gives up the master control function via the action "LOCAL / REMOTE" to the "Automatic" mode or alternatively to the Input IN. In the following cases the master control function is given up to the Input IN.

- No 3RW5 communication module is connected to the 3RW50 soft starter.
- The parameter "Control via digital input" (Page 127) is set to "Permanent activation".

Revocation of the master control by other control sources

If a command to this effect is issued in the SIRIUS Soft Starter ES (TIA Portal) at the local interface on the 3RW5 HMI High Feature, master control is taken from the 3RW5 HMI.
Brief overview: Window "Task Card" > Tab "Online Tools" > "SIRIUS Control Panel > Master Control > Get Control"

"Manual operation local - PC controlled" mode

Assume master control

If there is a corresponding command, SIRIUS Soft Starter ES (TIA Portal) actively assumes the master control function from every control source.

Brief overview: Window "Task Card" > Tab "Online Tools" > "SIRIUS Control Panel > Master Control > Get Control"

Relinquish master control

If there is a corresponding command, SIRIUS Soft Starter ES (TIA Portal) actively gives up the master control function to the "Automatic" mode or alternatively to the Input IN.

Brief overview: Window "Task Card" > Tab "Online Tools" > "SIRIUS Control Panel > Master Control > Release Control"

In the following cases the master control function is given up to the Input IN:

- No 3RW5 communication module is connected to the 3RW50 soft starter.
- The parameter "Control via digital input" (Page 127) is set to "Permanent activation".

Revocation of the master control by other control sources


The master control function cannot be withdrawn from SIRIUS Soft Starter ES (TIA Portal) by any control source.


Further information

You will find more information on the process images and data tables in the manual for the 3RW5 communication module in question.

You can find more information on the operation of SIRIUS Soft Starter ES (TIA Portal) in the online help of SIRIUS Soft Starter ES (TIA Portal).

3.7 Device versions





I_e Rated operational current
P Rated power
The stated power ratings apply to a rated operational voltage of U_e = 400 V in a standard circuit.

3.8 Areas of application / load types

Conveyor belts	Pumps	Compressors
Agitator	Fans	Saws

3.9 Selection of the soft starter using the Simulation Tool for Soft Starters


Starting of a motor causes a rapid change in the load current. The resulting torque impulses place severe stresses on the mechanical parts of a machine or plant. Moreover, voltage dips can occur in the power supply system which can have a negative influence on other devices:

- Flicker in lights
- Influence on computer systems
- Contactors and relays dropping out

The 3RW50 soft starter controls the voltage continuously. The torque and the current are thus also increased continuously. The power supply system is safeguarded against peak loads and the drive train is protected against damage:

- Smooth starting / stopping, e.g. for conveyor belts
- No pressure surges, e.g. for pumps
- Increased service life of the pipe system, e.g. for compressors
- Reduced starting current, e.g. for agitators
- Reduced stress on gearbox and V belt, e.g. for saws

3.9 Selection of the soft starter using the Simulation Tool for Soft Starters



The soft starter can be configured with the STS (Simulation Tool for Soft Starters) software. The STS suggests suitable soft starters for the respective application based on the entered

motor and load data and application requirements, as well as providing information on the parameterization.

You can download the Simulation Tool for Soft Starters (STS) for free on the 3RW5 topic page (<https://support.industry.siemens.com/cs/ww/en/view/109747404>).

3.10 Structure of the article number

Digit of the article number	1st-4th	5th	6th	7th	8th	9th	10th	11th	12th
SIRIUS 3RW soft starter	3RW5	0					B		
Frame size (FS) and rated operational current I_e of the soft starter			$x^{*1)}$	$x^{**1)}$					
Connection system	Control circuit: Spring-type terminals				2				
	Control circuit: Screw terminals				6				
Control terminals with	Analog output					A			
	Thermistor motor protection					T			
Rated control supply voltage $U_s^{2)}$					24 V AC / DC		0		
					110 V - 250 V AC		1		
Rated operational voltage U_e						200 - 480 V AC		4	
						200 - 600 V AC		5	

¹⁾ Explanation in the following table.

²⁾ When rating the control supply voltage, pay attention to the maximum starting current when closing the bypass contacts; details can be found in the technical data.

The following table shows the size and rated operational current for $U_e = 400$ V and $T_U = 40$ °C and in a standard circuit:

	Rated operational current I_e of the soft starter	Rated operational power P_e of the soft starter	x^*	x^{**}
S6	$I_e = 143$ A	$P_e = 75$ kW	5	5
	$I_e = 171$ A	$P_e = 90$ kW	5	6
S12	$I_e = 210$ A	$P_e = 110$ kW	7	2
	$I_e = 250$ A	$P_e = 132$ kW	7	3
	$I_e = 315$ A	$P_e = 160$ kW	7	4
	$I_e = 370$ A	$P_e = 200$ kW	7	5
	$I_e = 470$ A	$P_e = 250$ kW	7	6
	$I_e = 570$ A	$P_e = 315$ kW	7	7


Ambient temperature during operation

Note that the 3RW50 soft starters are approved for operation in a temperature range of -25 °C to +60 °C.

Consider the derating of the rated operational current at ambient temperatures higher than 40 °C. You can find more information on derating in the Chapter "Technical specifications (Page 185)" in the section "Power electronics" or in the Catalog IC 10 (<https://support.industry.siemens.com/cs/ww/en/view/109747945>).

3.11 Accessories

3.11.1 Accessories for 3RW50 soft starters




- ① 3RW50 soft starter
- ② 3RW5 HMI modules:
 - 3RW5 HMI Standard (3RW5980-OHS00)
 - 3RW5 HMI High Feature (3RW5980-OHF00) (firmware version V3.0 or higher)
- ③ 3RW5 communication modules:
 - PROFINET standard (3RW5980-OCS00) (firmware version V1.0.1 or higher)
 - PROFIBUS (3RW5980-OCF00) (firmware version V1.0.1 or higher)
 - EtherNet/IP (3RW5980-OCE00)
 - Modbus RTU (3RW5980-OCR00)
 - Modbus TCP (3RW5980-OCT00) (firmware version V1.1 or higher)

- ④ Box terminal blocks:
 - Size S6 (3RT1956-4G)
 - Size S12 (3RT1966-4G)
- ⑤ Terminal covers for box terminals:
 - Size S6 (3RT1956-4EA2)
 - Size S12 (3RT1966-4EA2)
- ⑥ Terminal covers for cable lug connection and bar connection:
 - Size S6 (3RT1956-4EA1)
 - Size S12 (3RT1966-4EA1)
- ⑦ Fan cover:
 - Size S6 and S12 (3RW5985-0FC00)
- ⑧ Push-in lugs for wall mounting (3ZY1311-0AA00)
- ⑨ IP65 door mounting kit (3RW5980-0HD00)
- ⑩ HMI connecting cable:
 - 0.5 m (3UF7932-0BA00-0)
 - 1 m (3UF7937-0BA00-0)
 - 2.5 m (3UF7933-0BA00-0)
 - 5 m (3RW5980-0HC60)
- ⑪ COM connecting cable (3RW5900-0CC00)

Note the information in Chapter Firmware update (Page 21).

3.11.2 3RW5 communication module

The following 3RW5 communication modules are available for integration of the 3RW50 soft starter in fieldbus systems:



- ① 3RW5 PROFINET Standard communication module (firmware version V1.0.1 or higher)
- ② 3RW5 PROFIBUS communication module (firmware version V1.0.1 or higher)
- ③ 3RW5 EtherNet/IP communication module
- ④ 3RW5 Modbus RTU communication module
- ⑤ 3RW5 communication module Modbus TCP (firmware version V1.1)

Note the information in Chapter Firmware update (Page 21).

The following accessories are available for using the 3RW5 communication modules on the 3RW50 soft starter:

- Push-in lugs for wall mounting (3ZY1311-0AA00)
- COM connecting cable (3RW5900-0CC00)

Integration into the automation software

The 3RW50 soft starter can be integrated in an automation software, e.g. STEP 7 (TIA Portal) via GSD / GSDML or HSP.

You will find further information on operation of the 3RW5 communication module in the Manual (Page 11) for the 3RW5 communication module in question.

3.11.3 SIRIUS Soft Starter ES (TIA Portal)

SIRIUS Soft Starter ES (TIA Portal) as of V15 Update 2 is the central software for configuring, commissioning, operation, and diagnostics of 3RW5 soft starters. 3RW50 soft starters are supported depending on the firmware as of V15.1 Update 2.

You connect your PC or your programming device to the 3RW50 soft starter via the local interface on the 3RW5 HMI High Feature (accessory). With the Premium or Professional license (V16 and higher), you can also connect your PC or your programming device from a central point to the 3RW50 soft starter via a 3RW5 PROFINET or PROFIBUS communication module (accessory).

By displaying all operating data, service data and diagnostics data, SIRIUS Soft Starter ES (TIA Portal) supplies reliable information, helping to avoid faults, or to quickly locate and eliminate them if they occur.




Illustration similar

Download

SIRIUS Soft Starter ES (TIA Portal) can be downloaded on the 3RW5 topic page (<https://support.industry.siemens.com/cs/ww/en/view/109747404>) or via the following link (<https://support.industry.siemens.com/cs/ww/en/ps/24231/dl>).

You will find more information on the SIRIUS Soft Starter ES (TIA Portal) software program and necessary versions and updates in Catalog IC 10 (<https://support.industry.siemens.com/cs/ww/en/view/109747945>) and on the 3RW5 topic page.

Versions available V15 and V15.1

Supported functions	SIRIUS Soft Starter ES (TIA Portal)		
	Basic	Standard ¹⁾	Premium
Access via local interface on the 3RW5 HMI High Feature	x	x	x
Parameterizing ²⁾	x	x	x
Operator control	x	x	x
Diagnostics	x	x	x
Creation of typicals	-	x ³⁾	x
Parameter export	-	x	x
Comparison functions	-	x	x
Service data (min/max pointer, statistic data)	-	x	x
Access via PROFIBUS or PROFINET	-	-	x

Supported functions	SIRIUS Soft Starter ES (TIA Portal)		
	Basic	Standard ¹⁾	Premium
Parameter comparison	-	-	x
Teleservice via MPI	-	-	x
Routing	-	-	x

¹⁾ Available up to V16

²⁾ 3RW5 HMI High Feature and supported 3RW5 communication modules

³⁾ Typical with Service Pack 1 and higher

Versions available as of V16

Supported functions	SIRIUS Soft Starter ES (TIA Portal)	
	Basic	Professional ¹⁾
Access via local interface on the 3RW5 HMI High Feature	x	x
Parameterizing ²⁾	x	x
Operator control	x	x
Diagnostics	x	x
Expert list	-	x
Parameter comparison	-	x
Service data (maximum pointer, statistic data)	-	x
Trace	-	x
Access via PROFIBUS or PROFINET	-	x
Teleservice via MPI	-	x
Routing	-	x
Bulk engineering (group function)	-	x


¹⁾ The "Professional" version corresponds to the "Premium" version of V15.1

²⁾ 3RW5 HMI High Feature and supported 3RW5 communication modules

3.11.4 3RW5 HMI

3RW5 HMI Standard

The 3RW50 soft starter can be monitored and controlled using the 3RW5 HMI Standard (Motor ON/OFF). The 3RW5 HMI Standard can be installed in the control cabinet door or mounted on a wall using accessories. The 3RW5 HMI Standard has an LCD with red display illumination, LEDs for status display, and function and control keys.



! WARNING

Automatic restart following acknowledgement of a fault on the 3RW5 HMI Standard. Can cause death or serious injury.

When using the 3RW5 HMI Standard: After acknowledging a fault, another automatic restart occurs if the motor was controlled via the HMI Standard before the fault occurred.

In the fault state, press the off button on the 3RW5 HMI Standard before acknowledging the fault in order to prevent an automatic restart.


Functions

- Any changes of setting elements will be indicated immediately in the display.
- Error diagnostics are output as error numbers (Faults and remedial actions of the 3RW50 soft starter (Page 153)).
- Acknowledgment of faults and execution of user tests via the RESET / TEST key
- Starting and stopping the motor via control keys
- Switching modes via the LOCAL / REMOTE key.
- Setting the station address for PROFIBUS and Modbus RTU.
- Display of the device LEDs of the 3RW5 HMI Standard shows the messages of the following devices:
 - 3RW50 soft starter
 - 3RW5 HMI Standard
 - Communication module (if there is one)

3RW5 HMI High Feature (HF)**Note****3RW5 HMI High Feature**

The 3RW50 soft starter is supported by the 3RW5 HMI High Feature as of firmware version V2.0.

The 3RW5 HMI High Feature can be used to parameterize, monitor and control (motor ON / OFF) the 3RW50 soft starter. The 3RW5 HMI High Feature can be installed in the control cabinet door or mounted on a wall using accessories. It can be connected to the SIRIUS Soft Starter ES software (TIA Portal) via the local interface. The 3RW5 HMI High Feature has a TFT color display, LEDs for the status display, and function and control keys.



Functions

- Language selection
- Starting and stopping the motor via control keys
- Local interface
- Display of error diagnoses as plain-text messages
- Display of up to 5 measured values at the same time
- Analog output and ON / RUN relay output can be parameterized with the 3RW5 HMI High Feature.
- Setting communication parameters of 3RW5 communication modules:
 - PROFINET (device name, IP parameters and other communication parameters)
 - PROFIBUS (station address and other communication parameters)
 - EtherNet/IP (IP parameters and other communication parameters)
 - Modbus RTU (station address and other communication parameters)
 - Modbus TCP (IP parameters and other communication parameters)
- Backup of parameterization data on a micro SD card
- The display of the device LEDs of the 3RW5 HMI High Feature shows the messages of the following devices:
 - 3RW50 soft starter
 - 3RW5 HMI High Feature
 - Communication module (if there is one)
- Firmware updates can be performed using the 3RW5 HMI High Feature and a micro SD card for the following devices:
 - 3RW50 soft starter
 - 3RW5 HMI High Feature
 - Communication module (if there is one)

Note the information in Chapter Firmware update (Page 21).

Mounting and dismantling

4.1 Installing 3RW50 soft starters

Procedure

1. Mount the 3RW50 soft starter on a level surface. (Page 46)
2. Ensure that the permissible temperature range and the necessary distances are complied with.
Technical specifications (Page 185)
3. Optionally mount the fan cover. (Page 45)
4. Connect the HMI connecting cable to the 3RW50 soft starter and optionally secure the 3RW5 HMI Standard or High Feature in the cabinet door or on a level surface.
 - Connect the HMI connecting cable to the 3RW50 soft starter (Page 48).
 - Installing the Standard 3RW5 HMI into the control cabinet door (Page 49).
 - Installing the High Feature 3RW5 HMI in the control cabinet door (Page 51).
 - Installing the Standard 3RW5 HMI on a flat surface (Page 54).
 - Installing the High Feature 3RW5 HMI on a flat surface (Page 56).
5. Optionally attach the 3RW5 communication module to a level surface.
You will find more details in the equipment manual for the 3RW5 communication module in question.

Result

The 3RW50 soft starter is now mounted and ready for connection.

4.2 Mounting the fan cover

Requirements

- Screwdriver T20
- Fan cover (accessory) suitable for the frame size


Size	Article number of the soft starter	Article number of the fan cover
S6	3RW505.-.....	3RW5985-0FC00
S12	3RW507.-.....	

Procedure

NOTICE

Material damage due to mechanical load.

Avoid a mechanical load on the fan hub when mounting the fan cover.



- Place the fan cover on the fan ① and fasten the fan cover ② using the 4 screws supplied.

Result

The fan cover provides enhanced touch protection and prevents the fan from being blocked by foreign objects.

4.3 Mount the 3RW50 soft starter on a level surface


Requirements

- Note the mounting positions, minimum clearances and ambient conditions stated on the data sheet.
- Level surface, e.g. sufficiently strong mounting plate
- 4 properly executed drill holes with thread or plug on the level surface.
- 4 screws of suitable size and with regular thread for insertion into the selected mounting plate or wall.
Use an additional four washers if the head of the screw is smaller than the specified diameter.
- Screwdriver (depending on the drive of the screws)
- If necessary, use shims and snap rings.

4.3 Mount the 3RW50 soft starter on a level surface

Size	Article number	Screws	Tightening torque
Size S6	3RW505.-.....	M6	5 Nm
Size S12	3RW507.-.....	M8	8 Nm

The following figure shows the minimum clearances for the 3RW50 soft starter:



Procedure


⚠ CAUTION

Heavy device.

Device can cause injury if it is dropped.

Always ask a second person to help you transport, install and dismantle a heavy device.

Use suitable lifting equipment and wear personnel protective equipment.



4.4 Connecting the 3RW5 HMI

- Screw the lower 2 screws into the mounting plate ①. Ensure that both screws protrude a minimum of 1.5 cm (min. 2 cm for size 4) and then place the 3RW50 soft starter onto the 2 lowermost screws ② from above.
- Tilt the 3RW50 soft starter up so that it is resting level against the mounting plate ③ and tighten all 4 screws with the specified torque setting ④.


4.4 Connecting the 3RW5 HMI

4.4.1 Connect the HMI connecting cable to the 3RW50 soft starter

Requirements

- Note the mounting positions, minimum clearances and ambient conditions stated on the data sheet.
- HMI connecting cable (accessory) of suitable length
- Removed hinged cover (Page 57)

Procedure



- Connect the HMI connecting cable to the 3RW50 soft starter. Observe the coding of the plug and socket ①.
- Lock the connector in the socket ②.
- Route the HMI connecting cable downward out of the HMI cable duct ③.
Then fit the hinged cover. (Page 57)
Make sure that you install the cable in accordance with EMC requirements. For example, route data cables separately from the motor cable. Connect both sides of shielded cables over a large surface area.

4.4.2 Installing the Standard 3RW5 HMI into the control cabinet door


Requirements

- Note the mounting positions, minimum clearances and ambient conditions stated on the data sheet.
- 3RW5 HMI Standard (accessories)
- HMI connecting cable (accessory) of suitable length connected to the soft starter (Page 48)
- Cutout of suitable size in the control cabinet door
- Device depth of the 3RW5 HMI Standard:
 - Total depth: 32 mm
 - Embedded depth: 29 mm
- Permissible wall thickness of the cabinet door:
 - Without IP65 door mounting kit: 1.5 to 3.0 mm
 - With IP65 door mounting kit: 1.0 to 7.0 mm

For using door mounting kit IP65:


- IP65 door mounting kit (accessory)
The fixing brackets with marking "001" are intended for a 3RW5 HMI Standard.
- Screwdriver PZ2

Procedure without door mounting kit IP65



Place the 3RW5 HMI Standard in the cutout of the control cabinet door ①. Ensure that the 3RW5 HMI Standard engages audibly in the 4 fixtures ②.


Procedure with IP65 door mounting kit



- Remove the protective film from the adhesive tape on the seal and secure the seal on the rear side of the 3RW5 HMI Standard ①. Ensure that the seal does not overlap.
- Place the 3RW5 HMI Standard in the cutout of the control cabinet door ②.

- Continue to screw the screws into the fixing brackets ③ until they protrude approx. 10 mm at the front. Fasten the fixing brackets onto the 3RW5 HMI Standard ④.
- Tighten the 3RW5 HMI Standard with a tightening torque of 0.3 ... 0.35 Nm ⑤.
Ensure that all of the screw heads are in contact with the fixing bracket.

Procedure for connecting with the HMI connecting cable



- Observe the coding of the plug and socket ①.
- Lock the connector in the socket ②.
- The HMI connecting cable in the cable duct of the 3RW5 HMI Standard may only be routed downward.
Make sure that you install the cable in accordance with EMC requirements. For example, route data cables separately from the motor cable. Connect both sides of shielded cables over a large surface area.

4.4.3 Installing the High Feature 3RW5 HMI in the control cabinet door


Requirements

- Note the mounting positions, minimum clearances and ambient conditions stated on the data sheet.
- 3RW5 HMI High Feature (accessories)
- HMI connecting cable (accessory) of suitable length connected to the soft starter (Page 48)
- Cutout of suitable size in the control cabinet door
- Device depth of the High Feature 3RW5 HMI:
 - Total depth: 32 mm
 - Embedded depth: 26 mm
- Permissible wall thickness of the cabinet door:
 - Without IP65 door mounting kit: 1.5 to 3.0 mm
 - With IP65 door mounting kit: 1.0 to 7.0 mm

For using door mounting kit IP65:


- IP65 door mounting kit (accessory)
The fixing brackets with marking "002" are intended for a 3RW5 HMI High Feature.
- Screwdriver PZ2

Procedure without door mounting kit IP65



Place the 3RW5 HMI High Feature in the cutout of the control cabinet door ①. Ensure that the 3RW5 HMI High Feature engages audibly in the 4 fixtures ②.

Procedure with door mounting kit IP65




- Remove the protective film from the adhesive tape on the seal and secure the seal on the rear side of the 3RW5 HMI High Feature ①. Ensure that the seal does not overlap.
- Place the 3RW5 HMI High Feature in the cutout of the control cabinet door ②.

4.4 Connecting the 3RW5 HMI

- Continue to screw the screws into the fixing brackets ③ until they protrude approx. 8 mm at the front. Fasten the fixing brackets onto the 3RW5 HMI High Feature ④.
- Tighten the 3RW5 HMI High Feature with a tightening torque of 0.3 ... 0.35 Nm ⑤. Ensure that all of the screw heads are in contact with the fixing bracket.

Procedure for connecting with the HMI connecting cable




- Observe the coding of the plug and socket ①.
- Lock the connector in the socket ②.
- The HMI connecting cable in the cable duct of the 3RW5 HMI High Feature may only be routed downward.
Make sure that you install the cable in accordance with EMC requirements. For example, route data cables separately from the motor cable. Connect both sides of shielded cables over a large surface area.

4.4.4 Installing the Standard 3RW5 HMI on a flat surface


Requirements

- Note the mounting positions, minimum clearances and ambient conditions stated on the data sheet.
- 3RW5 HMI Standard (accessories)
- Level surface, e.g. sufficiently strong mounting plate
- 2 properly executed drill holes with thread or plugs on the level surface. Refer to the drilling pattern (Page 187).
- 2 head screws M4 x 12 DIN ISO 7045 to fit the drill-holes
- Screwdriver (depending on the drive of the screws)
- 2 push-in lugs (accessories) for wall mounting
- HMI connecting cable (accessory) of suitable length connected to the soft starter (Page 48)

Procedure



- Observe the coding of the plug and socket ①.
- Lock the connector in the socket ②.
- The HMI connecting cable in the cable duct of the 3RW5 HMI Standard may only be routed downward.
Make sure that you install the cable in accordance with EMC requirements. For example, route data cables separately from the motor cable. Connect both sides of shielded cables over a large surface area.




- Make sure that the locking switch on the rear of the 3RW5 HMI Standard is in the required position.
For more information, see Chapter 3RW5 HMI Standard (Page 129).
- Insert the push-in lugs into each side of the enclosure until you hear them engage ① and fix the 3RW5 HMI Standard on the wall ② / ③.

4.4.5 Installing the High Feature 3RW5 HMI on a flat surface


Requirements

- Note the mounting positions, minimum clearances and ambient conditions stated on the data sheet.
- 3RW5 HMI High Feature (accessories)
- Level surface, e.g. sufficiently strong mounting plate
- 2 properly executed drill holes with thread or plugs on the level surface. Refer to the drilling pattern (Page 188).
- 2 head screws M4 x 12 DIN ISO 7045 to fit the drill-holes
- Screwdriver (depending on the drive of the screws)
- 2 push-in lugs (accessories) for wall mounting
- HMI connecting cable (accessory) of suitable length connected to the soft starter (Page 48)

Procedure



- Observe the coding of the plug and socket ①.
- Lock the connector in the socket ②.
- The HMI connecting cable in the cable duct of the 3RW5 HMI High Feature may only be routed downward.
Make sure that you install the cable in accordance with EMC requirements. For example, route data cables separately from the motor cable. Connect both sides of shielded cables over a large surface area.




- Insert the push-in lugs into each side of the enclosure until you hear them engage (1) and fix the 3RW5 HMI High Feature on the wall (2) / (3).

4.4.6 Removing and installing the hinged cover of the 3RW50 soft starter

Requirements

- Hinged cover

Procedure



- Unlock the hinged cover on both sides ① / ②.
- Open the hinged cover ③ at an angle of approx. 20°.
- Loosen the hinges horizontally to the soft starter surface ④ / ⑤ starting from the left.
- Take the cover off the 3RW50 soft starter.
- Follow the steps in reverse order to install the replacement hinged cover.

4.5 3RW5 communication module

4.5.1 Installing the 3RW5 communication module on a level surface

Requirements

- 3RW5 communication module (accessory)
- Level surface, e.g. sufficiently strong mounting plate
- Observe the mounting positions, minimum clearances and ambient conditions stated on the data sheet.
- 2 properly executed drill holes with thread or plugs on the level surface.
The 3RW5 communication module must be mounted to the left of the 3RW50 soft starter. Observe the position of the 3RW5 communication module in the drilling pattern (Page 189). The COM connecting cable has a limited length.
- 2 head screws M4 x 12 DIN ISO 7045 to fit the drill-holes
- Screwdriver (depending on the drive of the screws)
- 2 push-in lugs (accessories) for wall mounting




Illustration similar

Procedure




Illustration similar

1. Insert the push-in lugs into each side of the enclosure until you hear them engage.
2. Position the 3RW5 communication module on the level surface over the drill-holes and insert the head screws.
3. Attach the 3RW5 communication module on the bottom and top side of the level surface using the head screws.

Result

You have mounted the 3RW5 communication module on a level surface. You can connect the COM connecting cable to the 3RW50 soft starter (Page 61) and on the 3RW5 communication module (Page 62) and connect the 3RW50 soft starter to the fieldbus via the 3RW5 communication module.

You can find further information on connecting to the fieldbus in the Equipment Manual for the respective 3RW5 communication module.

4.5.2 Removing the 3RW5 communication module on a level surface

Requirements

- 3RW5 communication module (accessory)
- Removed bus connector (fieldbus)
You can find further information on connecting to the fieldbus in the Equipment Manual for the respective 3RW5 communication module.
- Removed COM connecting cable (Page 63)
- Screwdriver (depending on the drive of the screws)

Procedure




Illustration similar

1. Loosen the head screws on the 3RW5 communication module.
2. Pull out the push-in lugs from the 3RW5 communication module.

Result

You have removed the 3RW5 communication module and can now mount another 3RW5 communication module.

4.5.3 COM connection cable

4.5.3.1 Connecting the COM connecting cable to the 3RW50 soft starter

Requirements

- 3RW5 communication module (accessory)
- Removed hinged cover (Page 57)
- COM connecting cable (accessory)

Procedure




Illustration similar

1. Plug the bus connector of the COM connecting cable (without pin connectors) into the corresponding socket on the 3RW50 soft starter. Observe the coding of the bus connector and of the socket.
2. Lock the bus connector in the socket.
3. Install the hinged cover (Page 57).

Result

You have connected the COM connecting cable to the 3RW50 soft starter. You can connect the other side of the COM connecting cable to the 3RW5 communication module (Page 62).

4.5.3.2 Connecting the COM connecting cable to the 3RW5 communication module

Requirements

- A 3RW5 communication module mounted on a level surface (accessory) (Page 58)
- Removed cover cap
Loosen and remove the securing mechanism of the cover cap and keep the cover cap in a safe place.
- 3RW50 soft starter with connected COM connecting cable (accessory) (Page 61)

NOTICE

Damage to property due to electrical voltage

Switch off the power to the 3RW5 soft starter before starting work (main and control supply voltage).

Procedure

NOTICE

Material damage due to incorrect plug-in connection

Use the front plug-in connection of the 3RW5 communication module for the 3RW5 soft starter. The rear plug-in connection is not suitable for connecting to the COM connecting cable.




Illustration similar




Illustration similar

Plug the bus connector of the COM connecting cable with the pin connectors into the front plug-in connection of the 3RW5 communication module for the 3RW5 soft starter until the securing mechanism on the bus connector of the COM connecting cable latches into place.

Route the COM connecting cable in front under the 3RW50 soft starter and then on the side next to the 3RW50 soft starter. Maintain sufficient distance from the main power connections and ensure that your routing is EMC-compliant.

Result

The 3RW5 communication module is now properly mounted and connected to the 3RW50 soft starter. You can connect the 3RW50 soft starter via the 3RW5 communication module on the fieldbus.

You can find further information on connecting to the fieldbus in the Equipment Manual for the respective 3RW5 communication module.

4.5.3.3 Removing the COM connecting cable on the 3RW5 communication module

Requirements

- 3RW5 communication module (accessory)
- Removed bus connector (fieldbus)
You can find further information on connecting to the fieldbus in the Equipment Manual for the respective 3RW5 communication module.
- Cover cap

NOTICE

Damage to property due to electrical voltage

Switch off the power to the 3RW5 soft starter before starting work (main and control supply voltage).

Procedure




Illustration similar

1. Loosen the securing mechanism on the bus connector of the COM connecting cable.
2. Pull the bus connector of the COM connecting cable out of the plug-in connection of the 3RW5 communication module for the 3RW5 soft starter.

Result

You have disconnected the 3RW5 communication module from the 3RW50 soft starter. Place the cover cap onto the front plug-in connection of the 3RW5 communication module for the 3RW5 soft starter.

4.5.3.4 Remove the COM connecting cable on the 3RW50 soft starter

Requirements

- 3RW5 communication module (accessory)
- Removed hinged cover (Page 57)
- COM connecting cable (accessory) on the 3RW5 communication module removed (Page 63)

Procedure




Illustration similar

1. Loosen the securing mechanism on the bus connector of the COM connecting cable.
2. Pull the bus connector of the COM connecting cable out of the socket on the 3RW50 soft starter.
3. Install the hinged cover (Page 57).


Result

You have disconnected the COM connecting cable from the 3RW50 soft starter.

Connecting

5.1 Connections

5.1.1 Overview of all connections



- ① Main circuit connection network 1 / L1, 3 / L2, 5 / L3
- ② A1 / A2: Supply voltage for control terminals
- ③ Input IN to switch the motor on and off
- ④ Output 13, 14: For signaling the operating state ON or RUN (parameterizable (Page 88))
- ⑤ Output 23, 24: To signal operating state BYPASSED
- ⑥ Output 95, 96, and 98 to signal warnings and faults

- ⑦ Dependent on the variant of the 3RW50 soft starter:
- Thermistor motor protection T11 / T21, T12, and T22: Connection of a temperature sensor (optional)
T11 / T21 - T22: Connection for Thermoclick
T11 / T21 - T12: Connection for PTC Type A
 - Analog output AQ-, AQ I+ and AQ U+: Connection of an evaluation unit to display the motor current (optional, average phase current in %)
AQ- / AQ U+: For evaluation units with output signal type **Voltage**:
Signal range 0 - 10 V
AQ- / AQ I+: For evaluation units with output signal type **Current**:
Signal range 4 - 20 mA (factory setting)
- ⑧ Main circuit connection load (motor) 2 / T1, 4 / T2, 6 / T3

Note

Parameterizing output 13 / 14


You will find more information on parameterization in Chapter Parameterizing output 13 / 14 (output signal ON or RUN) (Page 88).

Note

Parameterizing the analog output

You can parameterize the output of the analog output with the 3RW5 HMI High Feature (Page 101).

5.1.2 State diagrams of the inputs and outputs



- ① Supply voltage for control terminals A1 and A2 (example model: 24 V)
- ② Main circuit connection network 1 / L1, 3 / L2, 5 / L3
- ③ Input IN to switch the motor on and off

- ④ Main circuit connection load (motor) 2 / T1, 4 / T2, 6 / T3
- ⑤ Output 13, 14: Parameterized to signal operating state ON
- ⑥ Output 13, 14: Parameterized to signal operating state RUN
- ⑦ Output 23, 24: To signal operating state BYPASSED
- ⑧ Output 95, 96 (NC) to signal warnings and faults
- ⑨ Output 95, 98 (NO) to signal warnings and faults
- ⑩ Temperature sensor (Thermoclick)

5.2 Connecting the 3RW50 soft starter

Requirements

- Observe the conductor cross-sections and tightening torques in the data sheet or on the front beneath the hinged cover.
- Pay attention to the required tools indicated on the front beneath the hinged cover.
- Optional accessories:
 - Terminal cover for 3RW50 soft starter in sizes S6 and S12
 - Box terminal block for 3RW50 soft starter in sizes S6 and S12
 - Terminal cover for box terminal in sizes S6 and S12

Procedure



DANGER

**Hazardous voltage.
Will cause death or serious injury.**

Turn off and lock out all power supplying this device before working on this device.

1. Connect the main circuit connections (line side / motor side) of the 3RW50 soft starter. (Page 71)
2. Optionally install the box terminal blocks for sizes S6 and S12. (Page 72)
3. Optionally install the terminal covers for sizes S6 and S12. (Page 74)
4. Connect the control terminals of the 3RW50 soft starter.
 - Connecting the control terminals (screw terminals) (Page 75)
 - Connecting the control terminals (spring-type terminals) (Page 77)

Result

The 3RW50 soft starter is connected and ready to operate.

5.3 Connecting the 3RW50 soft starter to the main circuit connection (mains / motor)

Requirements

- Observe the conductor cross-sections and tightening torques in the data sheet or on the front beneath the hinged cover.
- Pay attention to the required tools indicated on the front beneath the hinged cover.
-

Size	Article number	Screw size	Tightening torque
S6	3RW505.-.....	M8x25	10 ... 14 Nm
S12	3RW507.-.....	M10x35	14 ... 24 Nm


Procedure



! DANGER

**Hazardous voltage.
Will cause death or serious injury.**

Turn off and lock out all power supplying this device before working on this device.



Pay attention to the diagram on the packaging of the enclosed connection set.

- Connect terminal 1 / L1, 3 / L2, 5 / L3 to the supply network ①.
- Repeat step ① for connection 2 / T1, 4 / T2, 6 / T3 with the motor.


Example circuits

- Feeder assembly, type of coordination 1 fuseless (Page 193)
- Feeder assembly, type of coordination 1 with fuses (Page 194)
- Feeder assembly, type of coordination 2 (Page 195)

5.4 Mounting and dismantling box terminal blocks


Requirements

- Box terminal blocks (accessories) for 3RW50 soft starters
- Box terminal blocks are permissible for the following 3RW50 soft starters:
 - 3RW5055-.....
 - 3RW5056-.....
 - 3RW5072-.....
 - 3RW5073-.....
 - 3RW5074-.....
- Note the required tools on the box terminal nameplate.

Assembly procedure

- Plug the new box terminal blocks into the main circuit connections ① until they click into place.

Connect main circuit connection (line supply/motor)



- Plug the conductor for the main circuit connection into the box terminals (not shown in graphic) and tighten the six bolts with the specified torque ①:
 - 3RW505.-..... (size S6): 10 ... 12 Nm
 - 3RW507.-..... (size S12): 20 ... 22 Nm


Dismantling procedure



! DANGER

**Hazardous voltage.
Will cause death or serious injury.**

Turn off and lock out all power supplying this device before working on this device.



- Lever the box terminal blocks from the main circuit connections ① / ②.
- Pull the box terminal blocks off the main circuit connections ③.

5.5 Mounting terminal covers on main circuit connections

Requirements

- Terminal cover (accessory) for 3RW50 soft starter

Note

Touch protection by terminal cover.

Touch protection according to EN 50274 finger-safe only for vertical contact from the front.


Procedure



! DANGER

**Hazardous voltage.
Will cause death or serious injury.**

Turn off and lock out all power supplying this device before working on this device.



- Make sure that you mount the terminal cover the right way round on the connecting terminal, as shown in the diagram.

5.6 Connecting the control terminals (screw terminals)

Requirements

- Observe the conductor cross-sections and tightening torques in the data sheet or on the front beneath the hinged cover.
- Pay attention to the required tools indicated on the front beneath the hinged cover.


Procedure



 **DANGER**

Hazardous voltage.
Will cause death or serious injury.

Turn off and lock out all power supplying this device before working on this device.



Example circuits

- Control by pushbutton (Page 196)
- Control by switch (Page 198)
- Switching with the control supply voltage (Page 199)
- Control by PLC (Page 201)
- Actuation of a line contactor (Page 202)
- Wiring for remote RESET (Page 204)
- Connecting the temperature sensor (Page 204)
- Connecting the evaluation unit to the analog output (Page 205)

5.7 Disconnecting the control current from the screw-type terminals

Requirements

Pay attention to the required tools indicated on the front beneath the hinged cover.


Procedure



DANGER

**Hazardous voltage.
Will cause death or serious injury.**

Turn off and lock out all power supplying this device before working on this device.



5.8 Connecting the control terminals (spring-type terminals)

Requirements

- Observe the conductor cross-sections and tightening torques in the data sheet or on the front beneath the hinged cover.
- Pay attention to the required tools indicated on the front beneath the hinged cover.


Procedure



! DANGER

**Hazardous voltage.
Will cause death or serious injury.**

Turn off and lock out all power supplying this device before working on this device.



Example circuits

- Control by pushbutton (Page 196)
- Control by switch (Page 198)
- Switching with the control supply voltage (Page 199)
- Control by PLC (Page 201)
- Actuation of a line contactor (Page 202)
- Wiring for remote RESET (Page 204)
- Connecting the temperature sensor (Page 204)
- Connecting the evaluation unit to the analog output (Page 205)

5.9 Disconnecting the control current from the spring-loaded terminals

Requirements

Pay attention to the required tools indicated on the front beneath the hinged cover.


Procedure



! DANGER

Hazardous voltage.
Will cause death or serious injury.

Turn off and lock out all power supplying this device before working on this device.



5.10 Replacing the control terminals

Requirements

- Control terminal as spare part (screw terminal: 3RW5980-1TR00, spring-type: 3RW5980-2TR00)


Dismantling procedure



! DANGER


**Hazardous voltage.
Will cause death or serious injury.**

Turn off and lock out all power supplying this device before working on this device.



- Press against the lock ① and pull the control terminal out ②.


Assembly procedure



- Place the control terminal onto the intended connection until the terminal engages.

Parameter assignment

6.1 Setting elements on 3RW50 soft starter




- ① Scale of rated operational current I_e of the motor
- ② Stopping time
- ③ MODE key
 - Parameterization of RESET MODE
 - Deactivation / activation of Soft Torque
 - Parameterization of ON / RUN relay output
 - Parameterizing mode
 - Restoring factory setting
- ④ RESET / TEST key
 - Acknowledges faults
 - Performing the self-test (user test)
 - Parameterization of ON / RUN relay output
 - Parameterizing mode
 - Restoring factory setting
- ⑤ CLASS setting for the motor overload protection
- ⑥ Rated operational current I_e of the motor
- ⑦ Current limiting factor as a multiple of the set rated operational current I_e of the motor
- ⑧ Ramp up time
- ⑨ Starting voltage

Requirements

- Slotted screwdriver or cross-tip screwdriver PZ1

Procedure



- Insert the slotted screwdriver in the opening of the setting element.
- Turn the slotted screwdriver until the arrow of the setting element points to the required parameter setting.

Tip

Please note that the displays on the setting elements are approximate values which are subject to production engineering tolerances. To perform a detailed setting, a 3RW5 HMI should be used.







Display of the parameter value in the 3RW5 HMI (accessories)

- 3RW5 HMI Standard
During the setting of parameters at the setting elements, the current value is indicated on the display of the 3RW5 HMI Standard and undergoes cyclic updating.
- 3RW5 HMI High Feature
During the setting of parameters at the setting elements, the current value is indicated in the "Parameters > Parameter list" menu on the display of the 3RW5 HMI High Feature and undergoes cyclic updating.

Display of the parameter values in SIRIUS Soft Starter ES (TIA Portal)

Brief overview: Window "Project Navigation" with current project under created Soft Starter > "Parameters" > Window "Work area" > "Soft Starter > Parameter list"

6.2 Overview of parameters

Parameter	Symbol	Setting range	Factory setting
Tripping class for motor overload protection	CLASS	10A, 10E, 20E, OFF	10E
Rated operational current I_e of the motor ¹⁾		1 ... 16 ²⁾	1
Current limiting value as a multiple of the set rated operational current I_e of the motor		<ul style="list-style-type: none"> 1.3 ... 7 x I_e max <p>The "max" setting corresponds to 7 times the maximum rated operating current I_e of the 3RW50 soft starter.</p>	4 x I_e
Ramp up time		<ul style="list-style-type: none"> 0 ... 20 s With the setting "0 s", the motor is switched on with a ramp up time of approx. 100 ms. 	10 s
Starting voltage		30 ... 100 %	30 %
Stopping time		0 ... 20 s	0 s
Soft torque	SOFT TORQUE ☐ 	<ul style="list-style-type: none"> Off (LED off) On (LED on) 	Off
RESET MODE	RESET MODE ☐ 	<ul style="list-style-type: none"> Manual RESET (LED off) Remote RESET (LED flashes green) Auto RESET (LED lit green) 	Manual RESET

¹⁾ The rated operational current I_e of the motor may, according to the standard, deviate by 20% from the nameplate specification of the manufacturer.

²⁾ For meaning of scale, refer to laser-cut table on front panel of device.

6.3 Suggested settings

Application	Starting voltage [%]	Ramp up time [s]	Current limitation	Stopping time [s]
Conveyor belt (full)	70	5	$7 \times I_e$	10
Roller conveyor (full)	60	5	$7 \times I_e$	10
Compressor (without pressure)	50	4	$4 \times I_e$	Not relevant
Small fan	40	2	$4 \times I_e$	Not relevant
Pump ¹⁾	40	3	$4 \times I_e$	10
Hydraulic pump	40	2	$4 \times I_e$	Not relevant
Agitator	40	2	$4 \times I_e$	Not relevant
Milling machine	40	4	$4 \times I_e$	Not relevant

¹⁾ It is recommended that the Soft Torque function is activated.

6.4 Parameterizing the 3RW50 soft starter

Requirements

- The 3RW50 soft starter is mounted and connected.
- Supply voltage (control supply voltage) is present.
- Suggested settings (Page 84)

Note

Tips for parameterizing the 3RW50 soft starter.

Entering the motor and load data in the STS software (Page 36) will simulate the application and a suitable 3RW5 soft starter will be suggested. In addition, information regarding parameterization is also provided.

Procedure

1. You set the parameters on the setting elements of the 3RW50 soft starter (Page 81).
2. Set the motor overload protection on the setting elements "CLASS" and " I_e " (Page 117). The scale for rated operational current I_e is listed for each type of connection in the table on the front of the 3RW50 soft starter.
Make sure that the arrow of the "CLASS" setting element points to the required setting.
3. Set the soft starting on the setting elements "t" and "U" (Page 111).
4. Set the current limit at the setting element "Current limiting value $\times I_e$ " (Page 113).
5. Set the soft stopping on the setting element "t" (Page 115).
6. Activate the Soft Torque function, if required.
Note the information in Chapters Setting RESET MODE and Soft Torque (Page 85) and Soft torque (Page 119).

7. Set the required RESET MODE (Page 85).
8. Set the signal of your choice at the ON / RUN relay output (Page 88).
9. Set the parameters in Chapter Functions under "Additional parameters" (Page 124) if desired.

Result

The 3RW50 soft starter has been parameterized and is ready for operation. You can parameterize the signal of the analog output via an optional 3RW5 HMI High Feature (Page 101).

6.5 Setting RESET MODE and Soft Torque

RESET MODE and Soft Torque

With the MODE key you set the functions RESET MODE and Soft Torque at the same time.

Procedure

WARNING

**Automatic restart.
Can cause death or serious injury.**

If a starting command is pending, a restart will be triggered automatically after the reset. This particularly applies if the motor protection has tripped. Dangerous states of the system can result.

Reset the start command (e.g. via the PLC or switch) before performing a reset.


To do this, for example, link the group error output (terminals 95 and 96) into the control.

WARNING

**Automatic restart following acknowledgement of a fault on the 3RW5 HMI Standard.
Can cause death or serious injury.**

When using the 3RW5 HMI Standard: After acknowledging a fault, another automatic restart occurs if the motor was controlled via the HMI Standard before the fault occurred.

In the fault state, press the off button on the 3RW5 HMI Standard before acknowledging the fault in order to prevent an automatic restart.



RESET MODE

Note that the setting of the RESET MODE (Page 87) only has an effect on the acknowledgment response of the motor overload protection.

You can find more information in Chapter Faults and remedial actions of the 3RW50 soft starter (Page 153) with the comment "Depends on parameter RESET MODE".

Note

ATEX / IECEx applications

Note that the "Auto RESET" setting is not permissible when operating motors in hazardous areas.

RESET MODE LED	Set RESET MODE
<div>□</div> <div>Off</div>	Manual RESET
<div></div> <div>Flashes green</div>	Remote RESET
<div></div> <div>Lights up green</div>	Auto RESET

Soft torque

You can find more information in Chapter Soft torque (Page 119).

SOFT TORQUE LED	Set soft torque
<div style="text-align: center;">  Off </div>	Off
<div style="text-align: center;">  Lights up green </div>	On

6.6 RESET MODE

Effects of RESET MODE

Note that the setting of the RESET MODE only has an effect on the acknowledgment response of the motor overload protection.

You can find more information in Chapter Faults and remedial actions of the 3RW50 soft starter (Page 153) with the comment "Depends on parameter RESET MODE".

ATEX / IECEx applications

Note that the "Auto RESET" setting is not permissible when operating motors in hazardous areas.

Manual RESET

"Manual RESET" means that the following options are available for acknowledging faults:

- RESET / TEST key on the 3RW50 soft starter
- RESET / TEST key on the 3RW5 HMI Standard
- Reset via bus interface
- Reset via F key on 3RW5 HMI High Feature
- Reset via 3RW5 HMI High Feature (diagnosis state)
- Reset via SIRIUS Soft Starter ES (TIA Portal)

Remote RESET

"Remote RESET" means that faults are acknowledged by switching the control supply voltage off and on again. The control supply voltage on the 3RW50 soft starter must be switched off for at least 4 s.

Auto RESET

"Auto RESET" means that faults are automatically reset as soon as the cause is eliminated.

6.7 Parameterizing output 13 / 14 (output signal ON or RUN)

Operating principle

One of these two states is output at output 13 / 14:

- ON (factory setting)
- RUN

You will find additional information in Chapters Operating principle (Page 24) and State diagrams of the inputs and outputs (Page 69).

Use the **output function ON**, for instance, to implement latching if you selected pushbutton control.

Use the **Output function RUN** in order, for instance, to control a line contactor connected upstream.

Requirements

- Control supply voltage is connected.
- The 3RW50 soft starter does not signal any errors, the STATE / OVERLOAD LED is extinguished.

Video instructions

Video instructions can be found in SIOS (<https://support.industry.siemens.com/cs/ww/en/view/109778873>):



6.8 Parameterize the response to bus errors and output 13, 14 (ON / RUN)

Procedure

1. Start programming by pressing the MODE key longer than 2 seconds until the STATE / OVERLOAD LED flickers green.
Press and hold the MODE key.
2. Also press the RESET / TEST key longer than 2 seconds until the LED STATE / OVERLOAD illuminates red.
The set state of ON / RUN relay output is displayed on the SOFT TORQUE LED:

LED Soft Torque	Signal set on output 13 / 14
 Flashes green	ON (factory setting)
 Flickers green	RUN

3. Release the MODE and RESET / TEST keys.
4. Switch the mode by pressing the MODE key briefly. The SOFT TORQUE LED switches between flickering green and flashing green.
You can switch between the modes at the output as often as you want.

Note

If you do not press a key in the programming mode for longer than 10 s, the 3RW50 soft starter automatically terminates the programming mode.

5. Terminate programming mode by pressing the RESET / TEST key for longer than 1 s until the STATE / OVERLOAD LED no longer shines red.

More parameterization options

- 3RW5 HMI High Feature (accessory)
Menu: "Parameters > Soft Starter > ON / RUN relay output"
- Procedure in Chapter Parameterize the response to bus errors and output 13, 14 (ON / RUN) (Page 89)

6.8 Parameterize the response to bus errors and output 13, 14 (ON / RUN)

Requirements

- During the activation you must be able to switch off the supply voltage (control supply voltage).

Procedure

1. Press the MODE key during operation for longer than 2 seconds until the STATE / OVERLOAD LED flickers green and press and hold the MODE key.
2. Switch off the supply voltage (control supply voltage) of the 3RW50 soft starter for at least 5 seconds. After the 5 seconds have elapsed, you can release the MODE key.
3. Press and hold the MODE and TEST / RESET keys.
4. Switch the supply voltage (control supply voltage) of the 3RW50 soft starter on again. When the SOFT TORQUE and RESET MODE LEDs flicker green, the parameterization mode is active. You can release the MODE and TEST / RESET keys.
5. Select the desired parameter using the MODE key.
You can recognize your selection by the color of the STATE / OVERLOAD LED.

LED STATE / OVERLOAD	Parameters to be changed
 Off	No selection
 Lights up green	Control via digital input
 Lights up red	Output ON / RUN

6.8 Parameterize the response to bus errors and output 13, 14 (ON / RUN)

6. Change the setting of the selected parameter using the RESET / TEST key. You can recognize your selection by the color combination of the three LEDs RN, ER and MT. Setting the parameter "Control via digital input" (selection in Step 1):

Control via digital input / response to bus errors			
"RN" LED	"ER" LED	"MT" LED	Set parameter value
☐ Off	☐ Off	☐ Off	Manual activation
☐ Off	☐ Off	 Lights up yellow	Permanent activation
☐ Off	 Lights up red	 Lights up yellow	Activate on bus error (factory setting)
 Lights up green	 Lights up red	 Lights up yellow	No change on bus error

Setting of the parameter "Output ON / RUN" (selection in Step 1):

Output ON / RUN			
"RN" LED	"ER" LED	"MT" LED	Set parameter value
☐ Off	☐ Off	☐ Off	Output function ON
☐ Off	☐ Off	 Lights up yellow	Output function RUN

7. Switch off the supply voltage (control supply voltage) of the 3RW50 soft starter for at least 5 seconds.
The set parameters and parameter values are stored.
8. Switch the supply voltage (control supply voltage) of the 3RW50 soft starter on again.
The set parameters and parameter values are now active.

Further parameterization options


- 3RW5 HMI High Feature (accessory)
 - Menu: "Parameters > Soft Starter > Additional parameters > Control via digital input" (3RW5 HMI High Feature with firmware version V3.0 and higher)
 - Menu: "Parameters > Soft Starter > ON / RUN relay output"
- Procedure in Chapter Parameterizing output 13 / 14 (output signal ON or RUN) (Page 88)

Additional information

You can find more information on output 13, 14 in Chapter Parameterizing output 13 / 14 (output signal ON or RUN) (Page 88).

You can find more information on parameter "Control via digital input" in Chapter Response to bus errors / Control via digital input (Page 127).

6.9 Design and operator controls of the High Feature 3RW5 HMI



Navigating and setting

The keys are used for navigation, for selecting and setting menu items and for executing predefined actions.

Please note that parameters which are set manually using the 6 setting elements cannot be parameterized via the 3RW5 HMI High Feature.

Key	Actions
	<ul style="list-style-type: none"> Move one position to the right in the input field Displaying and switching over graphs. You can find more information in Chapter Graphic display of measured values on the 3RW5 HMI High Feature (Page 134).
	<ul style="list-style-type: none"> Move one position to the left in the input field Switching over graphs. For more information, see Chapter Graphic display of measured values on the 3RW5 HMI High Feature (Page 134).
	<ul style="list-style-type: none"> Jump to next menu item Set number or letter
	<ul style="list-style-type: none"> Jump to previous menu item Set number or letter
	<ul style="list-style-type: none"> Confirm Open the menu Jump to selected menu item
	<ul style="list-style-type: none"> Exit the menu
	<ul style="list-style-type: none"> Motor stops as parameterized if the 3RW5 HMI High Feature is the master control
	<ul style="list-style-type: none"> Motor starts as parameterized if the 3RW5 HMI High Feature is the master control <p>After an error has been acknowledged when using the 3RW5 HMI High Feature, you must repeat the ON command by pressing the "Motor Start" key.</p>
	<ul style="list-style-type: none"> F1: LOCAL / REMOTE: Changes master control F2: Reset F3-F9 (not available for 3RW50 soft starter)
	Master RESET key for restoring the factory settings (Page 180): All parameters that have not been set by means of setting elements are reset.

6.10 Menu of the 3RW5 HMI High Feature

This chapter explains the full menu of the 3RW5 HMI High Feature. Depending on the following points, contents may or may not be available:

- Version of the 3RW5 soft starter
- Up-to-date status of the firmware (Page 21)
This chapter refers to the necessary firmware version of the 3RW5 HMI High Feature. If a newer firmware version of the 3RW50 soft starter is required, refer to the description of the respective function.
- 3RW5 communication module

Overview of the main menu options on the 3RW5 HMI High Feature

Monitoring	Diagnostics	Parameter
		
Overview	Security	Micro SD card ¹⁾
		

¹⁾ Only visible if a micro SD card is inserted.

Additional information

Menu item "Additional information" shows the following QR code. The link behind the QR code is the 3RW5 topic page (<https://support.industry.siemens.com/cs/ww/en/view/109747404>).




Menu of the 3RW5 HMI High Feature

	Monitoring [1/1]
↓	
Measured values	
<ul style="list-style-type: none"> - Phase currents (%) <ul style="list-style-type: none"> └ I L1 └ I L2 └ I L3 └ I L1-3 └ Show bar chart¹⁾ - Phase currents (rms) <ul style="list-style-type: none"> └ I L1 └ I L2 └ I L3 └ I L1-3 └ Show bar chart¹⁾ - Motor temperature rise - Remaining motor cooling time - Remaining switching element cooling time - Switching element heating 	
Process image	
<ul style="list-style-type: none"> - Process image input (PII) <ul style="list-style-type: none"> └ Ready (automatic) └ Motor On └ Group error └ [...] ²⁾ - Process image output (PIQ) <ul style="list-style-type: none"> └ Motor CW └ Reset └ Self-test (user-test) └ Manual operation local - input controlled 	
Additional information	

¹⁾ 3RW5 HMI High Feature firmware version V3.0 or higher

²⁾ Further menu items. Refer to Chapter Monitoring the process image of the 3RW50 soft starter with the 3RW5 HMI High Feature (Page 136).



¹) Further menu items. Refer to Chapter Performing diagnostics of the 3RW50 soft starter with the 3RW5 HMI High Feature (Page 159).

	Diagnosis [2/2]
↓	
Soft Starter	
<ul style="list-style-type: none"> - Self-test - Logbooks <ul style="list-style-type: none"> └ Application └ Device └ Delete <ul style="list-style-type: none"> └ Application 	
Communication module	
<ul style="list-style-type: none"> - Diagnosis state <ul style="list-style-type: none"> └ Errors └ Prewarnings 	
HMI	
<ul style="list-style-type: none"> - Diagnosis state <ul style="list-style-type: none"> └ Errors └ Warnings └ Device state - Self-test <ul style="list-style-type: none"> └ Test LEDs └ Test buttons └ Test display 	
Additional information	

Parameter [1/3]		
Soft Starter	Setting Factory	Setting Customer
- Parameter list L Trip class L Rated operational current I_N L Current limiting value L Ramp up time L Starting voltage L Stopping time L Reset mode L Manual RESET L Auto RESET L Remote RESET L Soft torque L Deactivate L Activate - Analog output L Output signal type... L Deactivated L 4 ... 20 mA L 0 ... 10 V L Range start value L Range end value - ON / RUN relay output - Additional parameters L Bypass operating mode L Typical ambient temperature L Test with small load L Control via digital input ¹⁾ L Manual activation L Permanent activation L Activate on bus error L No change on bus error	CLASS 10E	
	1	
	400 %	
	10 s	
	30 %	
	0 s	
	x	
	x	
	x	
	0	
	96	
	ON	
	Internal bypass	
	60 °C	
	x	
Communication module		
- PROFINET²⁾ L MAC address L Device name L IP address L Subnet mask L Router address - EtherNet/IP³⁾ L MAC address L IP address setting L IP address L Subnet mask L Router address - Modbus TCP⁴⁾ L MAC address L IP address L Subnet mask L Router address L Access monitoring time		
	0.0.0.0	
	255.255.255.0	
	0.0.0.0	
	192.186.42.99	
	255.255.255.15	
	0.0.0.0	
	5 s	

1) 3RW5 HMI High Feature with firmware version V3.0 or higher

2) For 3RW5 PROFINET Standard communication module

3) For 3RW5 EtherNet/IP communication module

4) For 3RW5 Modbus TCP communication module

Parameter [2/3]		
Communication module	Setting Factory	Setting Customer
- Modbus RTU¹⁾ L Station address L Baud rate L Port configuration L Access monitoring time L Silent interval time - Detected baud rate¹⁾ - Detected port configuration¹⁾ - PROFIBUS DP²⁾ L Station address L Baud rate - Group diagnostics^{2), 3)} L Group error ^{2), 3)} L Group warning ³⁾		
	126	
	5 s	
	126	
HMI		
- Local interface activated⁴⁾ - Local interface deactivated⁴⁾ - Timer lighting dark - Do control after log off L Continue with motor control L Stop motor and give back control - Messages to show L Errors L Enable L Disable L Warnings L Enable L Disable - Operation display L Measured value 1 L Phase current average (%) ⁵⁾ L Measured value 2 L Phase current average (rms) ⁵⁾ L Measured value 3 L Phase current I L1 (rms) ⁵⁾ L Measured value 4 L Phase current I L2 (rms) ⁵⁾ L Measured value 5 L Phase current I L3 (rms) ⁵⁾ - Languages⁶⁾		
	5 min	
	x	
	x	
	x	
	x	
	x	
	English	

¹⁾ For 3RW5 Modbus RTU communication module

²⁾ For 3RW5 PROFIBUS communication module

³⁾ For 3RW5 PROFINET Standard communication module

⁴⁾ Display depends on the current setting


⁵⁾ Further menu items. Refer to Chapter Monitoring the measured values of the 3RW50 soft starter with the 3RW5 HMI High Feature (Page 133).

⁶⁾ Contains the lower level with settable languages.

Parameter [3/3]		
Factory settings	Setting Factory	Setting Customer
- Soft Starter		
- Communication module		
- HMI		
- All devices		
Additional information		

Overview [1/1]	
Soft Starter	
- Module L Article number L Hardware L Firmware - Module information L Tag function L Tag location L Installation date L Additional information - Manufacturer information L Manufacturer L Serial number	
Communication module	
- Module L Article number L Hardware L Firmware - Manufacturer information L Manufacturer L Serial number	
HMI	
- Module L Article number L Hardware L Firmware - Manufacturer information L Manufacturer L Serial number	
Additional information	

6.11 Parameterizing analog output AQ via the High Feature 3RW5 HMI



¹⁾ Display depends on the current setting

²⁾ The parameters of the analog output of the 3RW50 soft starter are also loaded.

³⁾ 3RW5 HMI High Feature firmware version V3.0 or higher

6.11 Parameterizing analog output AQ via the High Feature 3RW5 HMI

Operating principle

You can re-parameterize the output of the analog output with the 3RW5 HMI High Feature.

6.11 Parameterizing analog output AQ via the High Feature 3RW5 HMI

The actual average phase current L1 - L3 of the motor is displayed in % at the evaluation unit via the analog output. Depending on the respective connecting terminal being used, the signal can be displayed either as current or voltage.

- Terminals: AQ- / AQ I+
Measuring range of current output: 4 - 20 mA
- Terminals: AQ- / AQ U+
Measuring range of voltage output: 0 - 10 V

Requirements

- 3RW5 HMI High Feature
Menu: "Parameters > Soft Starter > Analog output"
- Access protection to the 3RW5 HMI High Feature is not active or has been reset.
- Device version with analog output
- Evaluation unit is connected properly (Page 205).

Parameter

Parameter	Description
Output signal type	<p>Via the "Output signal type" parameter you can define with what type of signal the analog value will be output.</p> <ul style="list-style-type: none"> • Deactivated • 4 - 20 mA (factory setting) • 0 ... 10 mA
Range start value	<p>With parameters "Range start value" and "Range end value" you can define which value of the analog value to be output corresponds to the lower output signal value and which to the upper output signal value. The respective value depends on the coding of the measured value.</p> <p>Factory setting:</p> <ul style="list-style-type: none"> • Range start value: 0 Setting of the analog range, e.g. 4 mA = 0 • Range end value: 96 Setting of the analog range, e.g. 20 mA = 96, corresponds to 300 % of the average phase current (%).
Range end value	

Factor for calculating the output measured value

Measured value	Factor	Unit	Range of values	Coding
Phase current average (%)	3.125	%	0 ... 796.9 %	0 ... 255

Example for calculating the parameters for the range start value and range end value

In this example, a pointer instrument indicates the measured value "Phase current average (%)" at the left stop with 50 % (start value) and the right stop with 200 % (end value). You can divide the scale of the pointer instrument between the left stop and the right stop, depending on the desired resolution.

The following parameters are given as examples at this point:

- Output signal type: 4 ... 20 mA
- Range start value = desired start value (%) / factor of the measured value
- Range end value = desired end value (%) / factor of the measured value

Procedure

1. Parameterize the output signal type, e.g. 4 ... 20 mA.
2. Parameterize the range start value and the range end value taking the following factor into account:
 - Range start value (50 % / 3.125 %) → 16
 - Range end value (e.g. 200 % / 3.125 %) → 64

Result

You have adjusted the output signal of the analog output.

Reference

An application example for the evaluation of analog signals of the SIRIUS 3RW5 soft starter can be found on the Internet (<https://support.industry.siemens.com/cs/ww/en/view/109815448>).

6.12 Parameterizing the High Feature 3RW5 HMI

Requirements

- 3RW5 HMI High Feature

Setting options

- 3RW5 HMI High Feature
Menu: "Parameters > HMI"
Access protection to the 3RW5 HMI High Feature is not active or has been reset.
- With SIRIUS Soft Starter ES (TIA Portal) via the local interface on the 3RW5 HMI High Feature
- With a fieldbus via a 3RW5 communication module:
 - With SIRIUS Soft Starter ES (TIA Portal) Premium / Professional (only via a 3RW5 PROFINET or PROFIBUS communication module)
 - Configuration software of the control system (e.g. STEP 7 with corresponding HSP)
 - User program

You can find further information on the parameters that can be set via the fieldbus in the Equipment Manual of the respective 3RW5 communication module.

Parameter

Parameter	Description
Local interface activated (via 3RW5 HMI High Feature only)	The parameter is only visible if the local interface is enabled (factory setting). Disables the local interface of the 3RW5 HMI High Feature. Before you can connect a PC with SIRIUS Soft Starter ES (TIA Portal) to the 3RW50 soft starter via the local interface, the local interface must be enabled. You can prevent unauthorized access via SIRIUS Soft Starter ES (TIA Portal) by disabling the local interface.
Local interface deactivated (via 3RW5 HMI High Feature only)	The parameter is only visible if the local interface is disabled. Enables the local interface of the 3RW5 HMI High Feature.
Timer lighting dark	If no keys on the 3RW5 HMI High Feature are pressed, the display will shut down after a specified time period has elapsed. The parameter value "0" deactivates the shutdown of the display. <ul style="list-style-type: none"> • Factory setting: 5 min • Setting range: 0 ... 60 min • Increment: 1 min
Do Control After Logoff	This parameter describes the response after logging off while the motor is running.
	Continue with motor control The master control is retained by the 3RW5 HMI High Feature.
	Stop motor and give back control (factory setting) The motor stops and the master control is no longer with the 3RW5 HMI High Feature. Refer to Chapter Operating modes and master control function (Page 29).
Message display	If errors and/or warnings are enabled, they will appear as pop-up windows in the display of the 3RW5 HMI High Feature as soon as they occur.
	Error <ul style="list-style-type: none"> • Enable (factory setting) • Disable
	Warnings <ul style="list-style-type: none"> • Enable (factory setting) • Disable

6.13 Parameterize 3RW5 HMI High Feature serially / identically

Parameter	Description
Operation display	Up to 5 different measured values can be selected from a list of measured values. These measured values are then shown in the status display. You can find more information on input actions in Chapter Monitoring the measured values of the 3RW50 soft starter with the 3RW5 HMI High Feature (Page 133).
Languages	<p>The required language is set in the "Languages" menu.</p> <ul style="list-style-type: none"> • English (factory setting) • German • French • Spanish • Italian • Portuguese • Chinese • Additional language¹⁾ (Page 144)

¹⁾ Only visible if an additional language has been added.

6.13 Parameterize 3RW5 HMI High Feature serially / identically

If you want to parameterize multiple 3RW5 HMI High Features identically on different 3RW50 soft starters, you can parameterize them serially with a micro SD card.

Requirements

- 3RW5 HMI High Feature (accessory)
- Micro SD card (Page 142)

Procedure

1. Parameterize the 3RW5 HMI High Feature (Page 103).
2. Plug the micro SD card into the 3RW5 HMI High Feature.
3. Load the parameters of the 3RW5 HMI High Feature onto the micro SD card.
Menu: "Micro SD card > Load communication and HMI parameters to micro SD card"
Example of a folder name created on the micro SD card: "1P3RW5 xxx-xxxxx"
Note the information in Chapter Micro SD card (Page 142).
4. Remove the micro SD card from the 3RW5 HMI High Feature.
5. Plug the micro SD card into the 3RW5 HMI High Feature that you want to parameterize identically with the original 3RW5 HMI High Feature.
6. Load the parameters of the 3RW5 HMI High Feature onto the 3RW5 HMI High Feature.
Menu: "Micro SD card > Load communication and HMI parameters to soft starter"
Note the information in Chapter Micro SD card (Page 142).
7. If you wish, repeat the procedure for further 3RW5 HMI High Features.

Result

You have parameterized several 3RW5 HMI High Features identically on different 3RW50 soft starters.

Commissioning

7.1 Commissioning the 3RW50 soft starter

Procedure

1. Install the 3RW50 soft starter (Page 45).
2. Connect the 3RW50 soft starter (Page 70).
3. Parameterize the 3RW50 soft starter according to the application with the setting suggestions (Page 84).
If necessary, optimize the setting suggestions step by step (Page 84).
For example, you can continually adjust the current limiting factor while the motor is starting up.
4. Perform the self-test (user test) (Page 164).
5. Optionally seal the 3RW50 soft starter with a lead seal (Page 107).

Result


The 3RW50 soft starter is now ready for operation.

7.2 Sealing the 3RW50 soft starter

Requirements

- Seal, sealing wire and a suitable sealing tool

Procedure



Push the wire through the openings provided and seal the ends.

Result

By sealing the hinged cover, you protect the operator controls of the 3RW50 soft starter from unauthorized access. It is nevertheless still possible to operate a 3RW5 HMI and acknowledge messages.

Tip

The local interface and the memory module interface of the 3RW5 HMI High Feature can be protected from unauthorized access by sealing the interface cover. Proceed in the same sequence as for sealing the hinged cover.

For more information, see Chapter Design and operator controls of the High Feature 3RW5 HMI (Page 92).

7.3 First commissioning of the High Feature 3RW5 HMI

Requirements

- 3RW5 HMI High Feature (accessory)
- Supply voltage (control supply voltage) is connected for the first time or the factory settings have been restored on the 3RW5 HMI High Feature.
- Design and operator controls of the High Feature 3RW5 HMI (Page 92)

Procedure

Set the desired language.

Result

The 3RW5 HMI High Feature is ready to use. You can find an overview of the functions in Chapter 3RW5 HMI (Page 42). Note the menu structure in Chapter Menu of the 3RW5 HMI High Feature (Page 93).

Functions

8.1 Soft starting


Operating principle

A voltage ramp is used to implement soft starting. The 3RW50 soft starter increases the motor voltage from a parameterizable starting voltage to the line voltage within a definable ramp up time.


Application

- Systems in which a startup of the drive without interfering jerky movements is required.
- E.g. pumps or small fans

Voltage characteristic




Torque curve



- ① Torque with direct-on-line starting without 3RW50 soft starter
- ② Torque with short ramp up time
- ③ Torque with long ramp up time
- ④ Torque of the load
- ⑤ Acceleration torque = Difference of activation torque and torque of load

Current path



- ① Current characteristic with direct-on-line starting without 3RW50 soft starter
- ② Current characteristic with short ramp up time
- ③ Current characteristic with long ramp up time
- I_e Rated operational current during rated operation
- n_e Rated operating speed of the motor

Parameter

Parameter	Description
Starting voltage	<p>The starting voltage determines the starting torque of the motor. A lower starting voltage results in a lower switch-on torque and a lower starting current. Set the starting voltage to a value that ensures that the motor starts up immediately and smoothly once the start command reaches the 3RW50 soft starter.</p> <ul style="list-style-type: none"> • Factory setting: 30% • Setting range: 30 ... 100 %
Ramp up time	<p>The ramp up time determines the time taken to increase the motor voltage from the parameterized starting voltage to the line voltage. This has an influence on the motor's acceleration torque which drives the load during the ramp-up operation. A longer ramp up time results in a shorter acceleration torque across the motor ramp up time. The motor therefore runs up more slowly and smoothly.</p> <p>Set the length of the ramp up time so that the motor can reach its rated speed by the time the end of the ramp up reached. The actual motor starting time is load-dependent and can differ from the parameterized ramp up time.</p> <p>If you choose a time that is too short, the ramp up time ends before the motor has accelerated to speed. A very high starting current that can reach the value of the direct starting current at this speed then occurs. In this case, the 3RW50 soft starter can switch itself off via the internal overload protection function and signal a fault.</p> <p>With the setting "0 s", the motor is switched on with a ramp up time of approx. 100 ms.</p> <ul style="list-style-type: none"> • Factory setting: 10 s • Setting range: 0 ... 20 s

8.2 Current limiting function


Operating principle

Activate the current limiting function if you want to ensure that a specific current value is not exceeded during motor starting. The motor is always started up with the voltage ramp. If the current exceeds the parameterized current limit $\times I_e$, the voltage ramp function is aborted and the current limitation function starts. The current limitation function remains active until the 3RW50 soft starter has detected the motor ramp up and the motor is in a normal operating state.

Application

- Avoiding current surges
- Reducing energy costs

Current path




- ① Current characteristic with direct-on-line starting without 3RW50 soft starter
 ② Adjustable current limiting value
 ③ Voltage ramp
 I_e Rated operational current during rated operation

Parameter

Parameter	Description
Current limiting value	<p>In order to ensure that the drive can reach its rated speed, the minimum current limiting value that you select must be high enough to generate sufficient torque in the motor.</p> <p>A typical value is 3 to 4 times the rated operational current (I_e).</p> <p>As soon as the current limiting value is reached, the motor is started with this value until it has reached its rated operating speed. In this case, the motor starting times may be longer than the maximum parameterizable ramp up time.</p> <p>The maximum possible current limiting value for the 3RW50 soft starter ("max." position) is 7x the value of the maximum rated operational current for the 3RW50 soft starter, where this value is identical to 7x the value of the maximum rated operational current I_e which can be set.</p> <p>This value is independent of the actual rated operational current I_e of the motor set at the 3RW50 soft starter.</p> <ul style="list-style-type: none"> Factory setting: $4 \times I_e$ Setting range: $1.3 \dots 7 \times I_e$ <p>The setting "max" corresponds to the 7-fold value of the maximum rated operational current I_e of the 3RW50 soft starter.</p>

Example



- ① Rated operational current I_e of the motor: $I_{e\ motor} = 350\ A$
- ② Current limitation of the 3RW50 soft starter: $4 \times I_{e\ Motor} = 4 \times 350\ A = 1\ 400\ A$
- ③ Maximum current limitation that can be set on this 3RW50 soft starter: $I_{max} = 7 \times 570\ A = 3\ 990\ A$

8.3 Soft stopping


Operating principle

A voltage ramp is used to implement a smooth ramp-down. With the "voltage ramp" stopping function, the motor voltage is decreased along a linear, negative voltage ramp down to stop voltage.

Application

- Drives that abruptly come to a stop when switched off, thereby damaging the transported goods.
- E.g. bottle filling plants

Voltage characteristic



$t_1 \dots t_2$ Stopping time

U_N Line voltage

U_{Stop} Stop voltage (50% of the line voltage)

Parameter

Parameter	Description
Stopping time	<p>The length of the stopping time defines the time within which the motor voltage is reduced from line voltage to 0 V. It may take longer for the motor to actually coast down to a standstill.</p> <p>The parameter value "0" causes the motor to be shut down immediately without a down ramp.</p> <ul style="list-style-type: none"> • Factory setting: 0 s • Setting range: 0 ... 20 s

8.4 Motor protection

The 3RW50 soft starter has two functions for protecting the motor:

- Electronic motor overload protection
- Thermistor motor protection with temperature sensor (optional)

Use a combination of both of these functions to implement full motor protection.

8.4.1 Electronic motor overload protection

Operating principle

The approximate temperature of the motor is calculated using the measured motor currents and the parameter settings "Rated operational current I_e " and "tripping class". This indicates whether the motor is overloaded or is functioning in the normal operating range. When overload is detected, the 3RW50 soft starter shuts the motor down. The setting for RESET MODE determines how the motor is restarted.

Parameter

 WARNING
<p>Automatic restart following fault acknowledgement/restart. Can cause death or serious injury.</p> <p>The 3RW50 soft starter immediately continues to operate with the values specified by the control following fault acknowledgement/restart. Outputs are activated when the ON condition is met.</p> <p>Take appropriate measures (e.g. start key with monitored start) to prevent unintentional restarting and to ensure a defined start of the system.</p>

NOTICE
<p>Damage to property possible due to deactivated motor protection.</p> <p>If the motor is not monitored by a temperature sensor and the tripping class is set to "CLASS OFF", no motor protection is provided.</p>

Parameter	Description
Tripping class	<p>The tripping class specifies the maximum time within which a protective device must trip from a cold state at $7.2 \times$ the rated operational current I_e (motor protection to IEC 60947).</p> <ul style="list-style-type: none"> CLASS OFF: Deactivates the electronic motor overload protection CLASS 10A / 10E / 20E: Tripping times according to the tripping class
Rated operational current I_e	<p>The rated operational current I_e is the current that can be continuously conducted by the feeder (switchgear and motor). Normally this is the rated operational current I_e of the motor.</p>

Recovery time following motor overload protection tripping

The recovery time after the electronic overload protection is tripped is 5 minutes. With Auto RESET set, the error is automatically reset after the recovery time has elapsed. With Manual RESET or Remote RESET set, a RESET is only possible once the recovery time has elapsed.

You will find further information on resetting the faults in Chapter RESET MODE (Page 87).

8.4.2 Thermistor motor protection with temperature sensor (optional)

Operating principle

**WARNING**

**Automatic restart following fault acknowledgement/restart.
Can cause death or serious injury.**

The 3RW50 soft starter immediately continues to operate with the values specified by the control following fault acknowledgement/restart. Outputs are activated when the ON condition is met.

Take appropriate measures (e.g. start key with monitored start) to prevent unintentional restarting and to ensure a defined start of the system.

You can connect the temperature sensor of the motor to the 3RW50 soft starter and evaluate it. If a specific motor-dependent temperature is exceeded, the 3RW50 soft starter recognizes this and reacts accordingly.

Two different types of measuring sensor can be connected to the 3RW50 soft starter:

- PTC thermistors type A
- Thermoclick
This sensor type is a temperature-dependent switch.

Note**ATEX / IECEx-certified motor overload protection**

Note that the sensor type "Thermoclick" is not permissible when operating motors in hazardous areas.

If the thermistor motor protection is tripped, the 3RW50 soft starter cannot be restarted until the sensor installed in the motor has cooled down. The recovery time varies according to the temperature state of the sensor.

The sensor cables of PTC thermistors type A can be monitored for wire break and short-circuit.

More information

You can find more information on resetting the faults in Chapter RESET MODE (Page 87).

You will find more information on the connection of the temperature sensor in Chapter Connecting the temperature sensor (Page 204).

8.5 Intrinsic device protection

Operating principle

The integrated intrinsic device protection protects the power semiconductors as well as the bypass contacts against impermissible overload. If the internal warning limit is exceeded, a message is output on the 3RW50 soft starter. If the internal fault threshold is exceeded, the 3RW50 soft starter will switch off automatically.

NOTICE

Property damage due to short circuits.

The intrinsic device protection system does not protect against irreparable equipment damage caused by short circuits.

Connect semiconductor fuses upstream in order to protect the power semiconductors against irreparable damage by short circuits (e.g. in case of cable damage or an interturn fault in the motor).

Recovery time after device protection is triggered

If the 3RW50 soft starter shuts down because the motor overload protection or the intrinsic device protection trips, you must wait a defined cooling time (recovery time) prior to acknowledging the fault or restarting the motor.


- In the event of power semiconductor overload: 60 s
- In the case of bypass overload: 60 s

8.6 Soft torque

Principle of operation of soft torque during starting


The Soft Torque function reduces the drive acceleration rate shortly before the motor reaches its rated operating speed. This produces an almost linear speed curve. This helps to ensure smooth movement of a conveyor belt, for example, and so prevent fragile goods on the belt from tipping over.

Torque curve



- ① Torque with direct start
- ② Torque without Soft Torque
- ③ Torque with Soft Torque

Speed curve




- n_e Rated operating speed of the motor
- ① Motor speed without Soft Torque
- ② Motor speed with Soft Torque

Principle of operation of Soft Torque during stopping

The Soft Torque function enables the motor to coast down smoothly at an almost constant rate of deceleration. Ensuring that the motor coasts down smoothly is particularly useful for stopping pumps in order to prevent water hammers in the connected piping. The Soft Torque function for stopping can only be activated when a stopping time of more than 3 s is set.

Speed curve



8.7 ATEX / IECEx-certified motor overload protection

Environmental conditions

Comply with the ambient conditions for which the 3RW50 soft starter is approved.

Note

Ambient temperature during operation.

Note that the 3RW50 soft starters are approved for operation in a temperature range of -25 °C to +60 °C.

In ambient temperatures higher than 40 °C, take the derating of the rated operational current into consideration.

You can find more information on derating in the data sheet, see Chapter "Technical specifications (Page 185)", section "Power electronics" or in Catalog IC 10 (<https://support.industry.siemens.com/cs/ww/en/view/109747945>).

Note

Temperature sensor

For ATEX / IECEx-certified motor protection, use of the PTC type A sensor only is approved.

Note

Simulation Tool for Soft Starters

Note that the Simulation Tool for Soft Starters (Page 36) already takes into account the derating for certain ambient temperatures when selecting a suitable 3RW5 soft starter.

Parameterizing the soft starter

The parameters for ATEX / IECEx applications are to be set using the setting elements of the 3RW50 soft starter.

Setting the rated motor operational current

Set the 3RW50 soft starter to the rated operational current of the motor as stated on the nameplate or prototype test certificate of the motor.

Tripping class (electronic overload protection)

Make sure that the motor and the cables are dimensioned for the selected tripping class.

- Note that the trip class "CLASS OFF" when operating motors in hazardous areas is only permissible if a "PTC thermistor type A" temperature sensor is used.
The rated data of the 3RW5 soft starter relates to normal starting (CLASS 10E). For heavy starting (> CLASS 10E), you may have to overdimension the 3RW5 soft starter.
- For 3RW50 soft starters with an analog output, trip class "CLASS OFF" is not permitted in an ATEX / IECEx application.

Parameterizing the motor protection functions (RESET setting)

Note that the "Auto RESET" setting is not permissible when operating motors in hazardous areas.

Short-circuit protection

The 3RW50 soft starter does not have short-circuit protection. Make sure that short-circuit protection is provided.

Line protection

Avoid impermissibly high cable surface temperatures by correctly dimensioning the cross-sections. Select a sufficiently large conductor cross-section.

Cyclic test of the motor protection functions

Only perform the Self-test (user-test) (Page 164) locally by means of the RESET / TEST key or the 3RW5 HMI High Feature to ensure that the correct 3RW50 soft starter is tested. Only in this way can the certified motor overload protection according to ATEX / IECEx be guaranteed.

On soft starters in ATEX / IECEx applications, perform the Self-test (user-test) (Page 164) during commissioning and periodically at intervals of no more than 36 months.

Certification of the 3RW50 soft starters

The motor overload protection of the 3RW50 soft starters is ATEX / IECEx-certified to SIL 1.

The 3RW50 soft starters are approved under Equipment Groups I and II, Category (2) or (M2) in zones "G" and "D". Zones "G" and "D" are areas in which explosive gas, vapor, mist or air mixtures and combustible dust are present:

IECEx BVS 19.0053 X [Ex]

BVS 19 ATEX F001 X

II (2)G [EX eb Gb] [EX db Gb] [EX pxb Gb]¹⁾

II (2)D [EX tb Db] [EX pxb Db]

I (M2) [EX db Mb]

¹⁾ For the px applications, pressure and flow rate monitoring are additionally required for the pressurized enclosure systems.

Certified motor overload protection according to ATEX / IECEx

<p> DANGER</p> <p>Loss of the certified motor overload protection according to ATEX/IECEx. Will cause death or serious injury.</p> <p>Note that operation in the standard type of motor connection without implementing one of the two following remedial measures results in loss of certified motor overload protection according to ATEX / IECEx.</p> <p>Depending on the structure of the circuit, choose one of the following possibilities for ensuring certified motor overload protection according to ATEX / IECEx:</p> <ul style="list-style-type: none"> • Use an additional line contactor in the main circuit. Connect the line contactor at outputs 95, 96 and 98 (output 3). • For a motor feeder configuration with a circuit breaker, use an additional undervoltage trip unit. Connect the undervoltage trip unit at outputs 95, 96 and 98 (output 3). You can find more information in Chapter Connections (Page 67).

Observing standards

Increased danger in hazardous areas means it is necessary to carefully observe the following standards:

- **IEC / EN 60079-14 / VDE 0165-1:** For electrical apparatus for hazardous areas.
- **IEC / EN 60079-17:** Inspection and maintenance of electrical installations in explosive atmosphere.
- **EN 50495:** Safety devices required for the safe functioning of equipment with respect to explosion risks.

ATEX/IECEx-specific safety data

ATEX/IECEx-specific safety data relating to 3RW50 soft starters can be found in the data sheet, see Chapter "Technical specifications (Page 185)".

Maintenance and repair

The 3RW50 soft starters are maintenance-free. The repair of soft starters with approval according to IEC 61508 / EN 13849 is only permissible in the manufacturer's plant.

A repair on 3RW50 soft starters that is not performed in the manufacturer's plant results in loss of ATEX / IECEx approval.

8.8 Functions under "Additional parameters"

Operating principle

The 3RW50 soft starter has additional functions and settable parameters that can be found under "Additional parameters" in the 3RW5 HMI High Feature.

Setting options

- **3RW5 HMI High Feature**
Access protection to 3RW5 HMI High Feature is not active or has been reset.
Menu: "Parameters > Soft Starter > Additional parameters"
- You can find additional setting options, if they exist, in the associated Chapter of the respective parameter.

Parameter

Parameter	Description
Typical ambient temperature (by means of 3RW5 HMI High Feature only)	The 3RW50 soft starter is set to the typical ambient temperature actually prevailing in the plant. Ensure that the set typical ambient temperature is not exceeded. <ul style="list-style-type: none"> • 40 °C • 50 °C • 60 °C (factory setting)
Test with small load	The control and main circuit wiring is tested on a small load using a test motor. A direction of rotation test can be performed by monitoring the motor shaft or the load connected to it. <ul style="list-style-type: none"> • Activate • Deactivate For more setting options and further information, see Chapter Test with small load (Page 126).
Control via digital input	The parameter defines how the master control behaves on failure of the bus connection or a CPU stop. For more setting options and further information, see Chapter Response to bus errors / Control via digital input (Page 127).

8.9 Test mode

Requirements

- Accessories, e.g. 3RW5 HMI High Feature or 3RW5 PROFINET or PROFIBUS communication module

Operating principle

For the test mode function "Test with small load" (Page 126), the 3RW50 soft starter must be in test mode. In test mode, the "RN" LED flashes green on the 3RW50 soft starter. For normal operation, the 3RW50 must be in Normal operation.

The parameters "Test mode" and "Normal operation" are not available in the 3RW5 HMI High Feature.

Setting options

- 3RW5 HMI High Feature (firmware version V2.0 or higher)
Access protection to 3RW5 HMI High Feature is not active or has been reset.
Menu: "Parameters > Soft Starter > Additional parameters"

Note

Activating test mode

If you activate or deactivate "Test with small load" on the 3RW5 HMI High Feature, you will automatically also switch to Test mode or Normal operation. For activation and deactivation on the 3RW5 HMI High Feature, the 3RW5 HMI High Feature must have master control.

- With SIRIUS Soft Starter ES (TIA Portal) via the local interface on the 3RW5 HMI High Feature
Brief overview: Window "Project Navigation" with current project under created Soft Starter > "Commissioning" > Window "Work area" > "Soft Starter > Functions > Test mode"
- With a fieldbus via a 3RW5 communication module (only via a 3RW5 PROFINET or PROFIBUS communication module):
 - With SIRIUS Soft Starter ES (TIA Portal) Premium / Professional
Brief overview: See SIRIUS Soft Starter ES (TIA Portal) via the local interface on the 3RW5 HMI High Feature
 - User program

8.10 Test with small load

Requirements

- The 3RW50 soft starter is connected to the main circuit.
- The test motor is connected to the 3RW50 soft starter.
- Permissible power range of the test motor:
 - < 10% of the rated power of the motor provided for the application
 - ≥ 1 kW
- The test motor is switched off prior to the activation of the test mode function "Test with small load".

Operating principle

The test mode function "Test with small load" is helpful during commissioning and when troubleshooting, as the correct function of the application can be tested before installation in a control cabinet or before the use of a motor provided for the application. The "Test with small load" enables the wiring of the control and main circuit to be checked with the aid of a small motor (test motor).

In the test mode function "Test with small load", the motor operating states and all functions and messages can be executed and displayed by the 3RW50 soft starter as in normal operation.

If, during an active "Test with small load", the 3RW50 soft starter detects a lack of main current, a fault is generated with a shutdown command and the message text "Line voltage for test required". After connecting the 3RW50 soft starter to the main supply this error message can be acknowledged with RESET.

The error monitoring functions that are to be attributed to a missing or inadequate main supply are not active. The test mode function "Test with small load" remains active until the test mode function is deactivated.

The motor and intrinsic device protection functions of the 3RW50 soft starter remain active according to their parameterization and are not influenced by the test mode function "Test with small load".

Setting options

The execution of the test mode function "Test with small load" is possible as follows:

- 3RW5 HMI High Feature
Access protection to 3RW5 HMI High Feature is not active or has been reset.
Menu: "Parameters > Soft Starter > Additional parameters"
- With SIRIUS Soft Starter ES (TIA Portal) via the local interface on the 3RW5 HMI High Feature
Brief overview: Window "Project Navigation" with current project under created Soft Starter > "Commissioning" > Window "Work area" > "Soft Starter > Functions > Test mode"
- With a fieldbus via a 3RW5 communication module (only via a 3RW5 PROFINET or PROFIBUS communication module):
 - With SIRIUS Soft Starter ES (TIA Portal) Premium / Professional
 - User program

Parameter

Parameter	Description
Activate test with small load	The 3RW50 soft starter switches to the test mode function "Test with small load".
Deactivate test with small load	The test mode function "Test with small load" is terminated. The 3RW50 soft starter exits the test mode and switches back to the parametrized operating mode.

8.11 Response to bus errors / Control via digital input

Operating principle

The parameter "Control via digital input" is only relevant when using a 3RW5 communication module. The parameter is helpful, for example, for applications in which the bus connection serves mainly for observation and monitoring purposes.

The parameter defines how the master control function behaves on failure of the bus connection or a CPU stop. A failure of the bus connection or a CPU stop can also occur in the operating mode "manual - local", for example when observing or monitoring via the

bus connection. You can use the parameter to disable a switchover to the "Automatic" mode and operating mode "manual - bus".

Setting options

Parameterization of the control via digital input is possible by the following methods:

- Setting parameterizing mode via key combination on the 3RW50 soft starter (Page 89)
- 3RW5 HMI High Feature
Access protection to 3RW5 HMI High Feature is not active or has been reset.
Menu: "Parameters > Soft Starter > Additional parameters > Control via digital input"

Parameter

Parameter	Description
Control via digital input	Manual activation On failure of the bus connection or a CPU stop the 3RW50 soft starter remains in the "Automatic" mode or the 3RW50 soft starter switches to the "Automatic" mode.
	Permanent activation A switch to the "Automatic" mode and operating mode "manual - bus" is not possible. If the 3RW50 soft starter is in the "Automatic" or "manual - bus" mode, the 3RW50 soft starter switches to the "Manual operation local - input controlled" mode. Control by means of a higher-level control (e.g. PLC) is not possible.
	Activate on bus error (factory setting) On failure of the bus connection or a CPU stop, the 3RW50 soft starter switches from the "Automatic" mode to the "Manual operation local - input controlled" mode or the 3RW50 soft starter remains in the operating mode "manual - local" mode.
	No change on bus error On failure of the bus connection or a CPU stop the master control function does not switch, but the 3RW50 soft starter remains in the current mode.

Note that for the settings "Manual activation" and "No change on bus error", the 3RW50 soft starter switches to the "Automatic" mode after connection of the 3RW5 communication module to the 3RW50 soft starter.

If, on failure of the bus connection or CPU stop, the 3RW50 soft starter remains in the "Automatic" mode or switches to the "Automatic" mode, you can switch to the operating mode "manual - local" by means of the following procedures:

- Via a 3RW5 HMI or SIRIUS Soft Starter ES (TIA Portal) over the local interface on the 3RW5 HMI High Feature (Page 31).
- Change the setting of the parameter "Control via digital input" in the parameterizing mode by means of a key combination on the 3RW50 soft starter (Page 89).
- Remove the COM connecting cable from the 3RW5 communication module (Page 63). Then restore the 3RW50 soft starter on the device to the factory setting, in order to (Page 180) switch to the "Manual operation local - Input controlled" mode.


Further information

For more information, see Chapter Operating modes and master control function (Page 29).

You will find further information about operation on failure of the bus connection to the control in the manual for the 3RW5 communication module in question.

8.12 3RW5 HMI Standard

8.12.1 Design of the Standard 3RW5 HMI



- ① Display
- ② Navigation keys
- ③ RESET / TEST
- ④ Status LED (Page 150)
- ⑤ Device LEDs (Page 150)
- ⑥ Plug-in connection for HMI connecting cable
- ⑦ Locking switch
- ⑧ Cable duct
- ⑨ Start key
- ⑩ Stop key
- ⑩ LOCL / REMT

Navigating and setting

Key	Actions
▼	<ul style="list-style-type: none"> Jump to next menu item Set digit
▲	<ul style="list-style-type: none"> Jump to previous menu item Set digit

8.12 3RW5 HMI Standard

Key	Actions
	<ul style="list-style-type: none"> Identical to RESET key on 3RW50 soft starter
	<ul style="list-style-type: none"> Motor stops as parameterized if the 3RW5 HMI Standard is the master control.
	<ul style="list-style-type: none"> Motor starts as parameterized if the 3RW5 HMI Standard is the master control.
	<ul style="list-style-type: none"> Changes master control LOCL means that the 3RW5 HMI Standard is the master control. REMT means that the 3RW5 HMI Standard is not the master control.
	<ul style="list-style-type: none"> Locking switch Locked / Unlocked: To be able to operate the 3RW50 soft starter with the Standard 3RW5 HMI, the locking switch on the rear of the Standard 3RW5 HMI must be unlocked. If the locking switch on the rear of the 3RW5 HMI Standard is in the "Locked" switch position, the "RESET / TEST", "LOCL / REMT" and "Start" and "Stop" keys are disabled. Navigation through the menu using the navigation keys, however, is still possible.

8.12.2 Standard 3RW5 HMI menu

The following information is shown on the display of the 3RW5 HMI Standard:

- Operating state
- Measured values
- Parameter
While you are setting the parameters, the actual value is shown in the display.
- Diagnostics

Operating state

Display	Explanation
STATE	
ON STATE	The ramp up time comes to an end and the motor is running.
RAMP STATE	The ramp up time or the stopping time is active.
OFF STATE	The motor is switched off.
ER O STATE	The motor is not ready to start because there is a fault. Additional information is provided by the diagnostics display.
OVLD (OVERLOAD)	
WN I OVLD	The motor is switched on. A motor overload protection warning is pending.
WN O OVLD	The motor is switched off. A motor overload protection warning is pending.
ER O OVLD	The motor is switched off. There is a fault at the motor overload protection.

Display	Explanation	
---- OVLD	No motor overload exists.	
OVLD% (OVERLOAD in percent)		
...% OVLD%	Status of the electronic motor overload protection as a percentage.	
SCR % (silicon-controlled rectifier, power semiconductor temperature rise)		
...% SCR %	Status of the intrinsic device protection as a percentage. This measured value reflects the temperature rise of the power semiconductor. It comprises the measurement of the heat sink temperature and the calculated temperature rise of the junction (thermal model of the semiconductor).	
S-TRQ (Soft Torque)		
ON S-TRQ	The Soft Torque function is activated.	
OFF S-TRQ	The Soft Torque function is deactivated.	
CNTRL (CONTROL)		
LOCL CNTRL	Manual mode	The master control function is with the 3RW5 HMI Standard ("Manual operation local - HMI controlled" mode).
REMT CNTRL	Automatic	Master control function is not with the 3RW5 HMI Standard. To make the unit the master control, press the LOCAL / REMOTE key. Refer to Chapter Operating modes and master control function (Page 29).

Measured values

Display	Explanation
...A	The average of the 3 phase currents is displayed in amps.
I AVG	
...A	Current measured value phase L1 is displayed in amps.
I L1	
...A	Current measured value phase L2 is displayed in amps.
I L2	
...A	Current measured value phase L3 is displayed in amps.
I L3	

Parameter list

Display	Explanation
..	Current limiting value as a multiple of the set rated operational current I_e of the motor.
xle	
...%	Starting voltage
U ON	
...s	Ramp up time
t ON	
...s	Stopping time
t OFF	

Display	Explanation	
... CLASS	Tripping class for motor overload protection	
...A I _e	Rated operational current I _e of the motor	
.... RMode	AUTO	Auto RESET
	MAN	Manual RESET
	REMT	Remote RESET
... PBADR	Station address for PROFIBUS (only displayed if a "PROFIBUS" communication module is being used)	
... MODBS	Station address for Modbus (only displayed if a "Modbus RTU" communication module is being used)	

Diagnostics display

Display	Explanation
.... ERROR	Display of the error number with 3RW5 HMI Standard (Page 132) Faults and remedial actions of the 3RW50 soft starter (Page 153)
NO COMM	No connection between the 3RW50 soft starter and the 3RW5 HMI Standard.

8.12.3 Display of the error number with 3RW5 HMI Standard

Display of the error number with 3RW5 HMI Standard

The 3RW5 HMI Standard can display up to 10 active errors (ER 0 ... 9) in the menu item "ERROR".

Procedure

1. Select the menu item "ERROR".
2. Press and hold a navigation key until the entry "ER 0" appears on the display.
3. Select the desired entry (ER 0 ... 9) using the navigation key.
If an entry contains an active error, the associated error number (Page 153) will appear above it.
If an entry contains no errors, the error number "0000" will appear.
4. To exit the menu, press and hold a navigation key until the entry "ERROR" appears on the display.
Alternatively, the 3RW5 HMI Standard automatically exits the menu after 5 seconds of inactivity.

8.13 3RW5 HMI High Feature

Observe the hardware configuration in Chapter Design and operator controls of the High Feature 3RW5 HMI (Page 92).

8.13.1 Monitoring

8.13.1.1 Monitoring the measured values of the 3RW50 soft starter with the 3RW5 HMI High Feature

Requirements

- 3RW5 HMI High Feature
Menu: "Monitoring > Measured values"

Operating principle

The measured values are provided by the respective device functions. All measured values are stored in the measured value memory which is not secure against voltage failure. These values can be read out and evaluated by the 3RW5 HMI High Feature. You can specify up to 5 measured values, which are shown on the operation display (Page 103).

Further display options of the measured values

- With SIRIUS Soft Starter ES (TIA Portal) via the local interface on the 3RW5 HMI High Feature
Brief overview: Window "Project Navigation" with current project under created Soft Starter > "Commissioning" > Window "Work area" > "Soft Starter > Measured values"
- With a fieldbus via a 3RW5 communication module:
 - With SIRIUS Soft Starter ES (TIA Portal) Premium / Professional (only via a 3RW5 PROFINET or PROFIBUS communication module)
Brief overview: See SIRIUS Soft Starter ES (TIA Portal) via the local interface on the 3RW5 HMI High Feature
 - User program

Measured values

Measured value		Description
Phase currents (%)	<ul style="list-style-type: none">• IL1• IL2• IL3• Average• Show bar chart¹⁾	<p>The phase currents are displayed as a percentage. You can monitor each phase (L1/L2/L3) individually, or the average of all 3 phases.</p> <p>These measured values can be presented graphically as bar or line chart on the display of the 3RW5 HMI High Feature. You can find more information in Chapters Design and operator controls of the High Feature 3RW5 HMI (Page 92) and Graphic display of measured values on the 3RW5 HMI High Feature (Page 134).</p>
Phase currents (rms)		<p>The phase currents are displayed in amperes. You can monitor each phase (L1/L2/L3) individually, or the average of all 3 phases.</p> <p>These measured values can be presented graphically as bar or line chart on the display of the 3RW5 HMI High Feature. You can find more information in Chapters Design and operator controls of the High Feature 3RW5 HMI (Page 92) and Graphic display of measured values on the 3RW5 HMI High Feature (Page 134).</p>
Motor temperature rise [%]		Current value of motor temperature rise in %. This measured value is calculated internally by the 3RW52 soft starter and indicates the relative temperature rise of the motor.
Remaining motor cooling time [s]		The remaining recovery time is the minimum cooling time of the motor that must elapse following activation of motor overload protection before the 3RW50 soft starter is once again ready for operation.
Remaining switching element cooling time [s]		The remaining cooling time of the switching element is dependent on the thermal capacity of the power unit and the ambient conditions (temperature, air circulation, installation location, etc.). The remaining cooling time of the switching element is the time that must elapse following activation of the intrinsic device protection before the 3RW50 soft starter is once again ready for operation.
Switching element heating [%]		The currently calculated switching element heating is continuously compared with the previously saved switching element heating and indicated in %.

¹⁾ 3RW5 HMI High Feature firmware version V3.0 or higher

8.13.1.2 Graphic display of measured values on the 3RW5 HMI High Feature

Requirements

- 3RW5 HMI High Feature (accessory) with firmware version V3.0 or higher

Operating principle

The 3RW50 soft starter supports the graphic display of the measured values "Phase currents (%)" and "Phase currents (rms)". These measured values can be presented as bar or line charts on the display of the 3RW5 HMI High Feature.

The following measured values can be displayed in the graphs:


- Phase current IL1 (%) and (rms)
- Phase current IL2 (%) and (rms)

- Phase current IL3 (%) and (rms)
- Phase current average (%) and (rms)

Procedure for displaying bar charts

1. Select the menu item "Monitoring > Measured values > Phase currents (%) / Phase currents (rms) > Show bar chart".
Depending on the menu item selected, the current values of the 3 phase currents (%) or phase currents (rms) and the average value are displayed graphically in a bar chart.
2. Use the left and right navigations keys of the 3RW5 HMI High Feature to switch the view between Phase currents (%) and Phase currents (rms).
3. Press the "ESC" key to exit the bar chart view.

The graph in the example shows the current 3 phase currents (L1/L2/L3) and the associated mean value as a percentage.



Procedure for displaying line charts


Operation display

1. Select the measured value to be displayed in the operating display and press the right navigation key of the 3RW5 HMI High Feature.
The selected measured value is shown graphically in a line chart.
2. Use the left and right navigations keys of the 3RW5 HMI High Feature to switch the view between Phase currents (%) and Phase currents (rms).
3. Press the "ESC" key to exit the line chart view.

"Monitoring" menu

1. Select the menu item "Monitoring > Measured values > Phase currents (%) / Phase currents (rms)".
2. Select the phase current to be displayed and press the right navigation key of the 3RW5 HMI High Feature.
The selected phase current is shown graphically in a line chart.
3. Use the left and right navigations keys of the 3RW5 HMI High Feature to switch the view between Phase currents (%) and Phase currents (rms).
4. Press the "ESC" key to exit the line chart view.

The graph in the example shows the current phase current I L1 as a percentage. The scaling of the y-axis is 200%.



If the measured value exceeds the limit of the scaling (200% in the example), the line extends parallel with the x-axis and is displayed red in that area.

8.13.1.3 Monitoring the process image of the 3RW50 soft starter with the 3RW5 HMI High Feature

Operating principle

The process image input (PII) contains current information about the soft starter and process state. The process image output (PIQ) contains current control commands to the 3RW5 soft starter. The control command states of the control source, which has control priority according to the operating mode controller, are entered in the data memory of the process image output.

Requirements

- 3RW5 HMI High Feature
Menu: "Monitoring > Process image"

Display of the process images

In the process image input (PII) and process image output (PIQ), you can see which bits of the process image are active or inactive:

Checkbox	Status	Bit
☐	inactive	0
☒	active	1

Process image input (PII)

Process data	Process image
DI 0.0	Ready (automatic)
DI 0.1	Motor On
DI 0.2	Group error
DI 0.3	Group warning
DI 0.4	Input 1
DI 1.0	Motor current lact-bit0
DI 1.1	Motor current lact-bit1
DI 1.2	Motor current lact-bit2
DI 1.3	Motor current lact-bit3
DI 1.4	Motor current lact-bit4
DI 1.5	Motor current lact-bit5
DI 1.6	Manual operation local
DI 1.7	Ramp operation
DI 2.0	Motor CW
DI 2.4	Starting mode active
DI 2.5	Operation / bypass active
DI 2.6	Stop mode active
DI 2.7	Test operation active
DI 3.0	Thermal motor model overload
DI 3.1	Temperature sensor overload
DI 3.2	Switching element overload
DI 3.3	Cooling time active
DI 3.4	Device error
AI 4 (Float32)	Measured value 1 (phase current I L1 (rms))
AI 8 (Float32)	Measured value 2 (phase current I L2 (rms))
AI 12 (Float32)	Measured value 3 (phase current I L3 (rms))

Process image output (PIQ)

Process data	Process image
DQ 0.0	Motor CW
DQ 0.3	Reset
DQ 0.5	Self-test (user-test)
DQ 3.0	Manual operation local - input controlled

Further information

You will find further information on transferring the process images via a fieldbus in the device manual for the respective 3RW5 communication module.

8.13.2 Overview

Requirements

- 3RW5 HMI High Feature (accessory)
Menu: "Overview"

Operating principle

The "Overview" menu displays the connected components and their device-related information (I&M data).

Note

Device-related information

Note that, with the 3RW5 HMI High Feature, it is only possible to edit the displayed device name of the 3RW5 soft starter.

Additional display options of the device-related information (I&M data)

- With SIRIUS Soft Starter ES (TIA Portal) via the local interface on the 3RW5 HMI High Feature
Brief overview: Window "Project Navigation" with current project under created Soft Starter > "Online & Diagnostics" > Window "Work area" > "Soft Starter / 3RW5 communication module used / HMI > Diagnosis > General"
- With a fieldbus via a 3RW5 communication module:
 - With SIRIUS Soft Starter ES (TIA Portal) Premium / Professional (only via a 3RW5 PROFINET or PROFIBUS communication module)
Brief overview: See SIRIUS Soft Starter ES (TIA Portal) via the local interface on the 3RW5 HMI High Feature
 - Configuration software of the control system (e.g. STEP 7 with corresponding HSP)
 - User program

Note

I&M data

I&M0 data is assigned for all of the devices (3RW5 soft starter, 3RW5 HMI High Feature, and 3RW5 communication module) and can be read out. Only the proxy for the "Station" (slot 0) has adjustable and readable I&M1, I&M2 and I&M3 data. The "Station" comprises the following devices:

- 3RW5 communication module (slot 1)
 - 3RW5 soft starter (slot 2)
 - 3RW5 HMI High Feature (slot 3)
-

Parameters

Parameter		Description
Soft starter	Module	<ul style="list-style-type: none"> Article number¹⁾ Hardware¹⁾ Firmware¹⁾
	Module information	<ul style="list-style-type: none"> Tag function²⁾
		<ul style="list-style-type: none"> Tag location²⁾
		<ul style="list-style-type: none"> Installation date³⁾
		<ul style="list-style-type: none"> Additional information⁴⁾ Assign a device name to the 3RW5 soft starter via SIRIUS Soft Starter ES (TIA Portal) or with the 3RW5 HMI High Feature. The device name appears in the top line of the display of the 3RW5 HMI High Feature. If you do not assign any name to the 3RW5 soft starter, the 3RW5 soft starter retains its short code. If the set device name is too long, only the first part of the device name is displayed.
HMI	Module	<ul style="list-style-type: none"> Article number¹⁾ Hardware¹⁾ Firmware¹⁾
	Manufacturer information	<ul style="list-style-type: none"> Manufacturer¹⁾ Serial number¹⁾
Communication module (if existing)	Module	<ul style="list-style-type: none"> Article number¹⁾ Hardware¹⁾ Firmware¹⁾
	Manufacturer information	<ul style="list-style-type: none"> Manufacturer¹⁾ Serial number¹⁾

¹⁾ Part of the I&M0 data

²⁾ Part of the I&M1 data

³⁾ Part of the I&M2 data

⁴⁾ Part of the I&M3 data

8.13.3 Local access protection (PIN)

Requirements

- 3RW5 HMI High Feature (accessory)
Menu: "Security > Local access protection"

Operating principle

With the PIN, you can protect the 3RW5 HMI High Feature from unauthorized access. The menus of the 3RW5 HMI High Feature can still be viewed with local access protection activated. It is not possible to issue a control command or to set a parameter. If you issue a control command or change a parameter when local access protection is enabled, you will automatically receive an entry prompt for the current PIN beforehand.

The PIN remains even after the power supply has been interrupted. You can reset the local access protection to the factory setting with the master RESET key on the rear of the 3RW5 HMI High Feature (Page 180). Protect the master RESET key from unauthorized access.

Parameters

Parameter		Description
Local access protection	Define PIN ¹⁾	PIN is set up and active (Page 140). In the factory setting, no PIN is set up and the local access protection is not active.
	Change PIN ²⁾	Existing PIN is changed (Page 141).
	Delete PIN ²⁾	PIN is deactivated and deleted (Page 142).
	Auto log off time ²⁾	If you do not regularly press a key on the 3RW5 HMI High Feature, the current session will be terminated after the auto logoff time has elapsed. <ul style="list-style-type: none"> Factory setting: 0 min = deactivated Setting range: 0 ... 60 min
	Log on ³⁾	Remove the local access protection by logging on with your 4-digit PIN.
	Log off ⁴⁾	Log out of your current session. The local access protection is activated again. Alternatively, the session will be terminated after the auto logoff time.

¹⁾ Menu entry is displayed if no PIN has been defined.

²⁾ Menu entry is displayed if a PIN has been defined.

³⁾ Menu entry is displayed after logging off with an active PIN.

⁴⁾ Menu entry is displayed after logging on with an active PIN.

8.13.3.1 Define PIN

Requirements

- 3RW5 HMI High Feature (accessory)
Menu: "Security > Local access protection"
- No PIN is defined (factory setting).

Procedure

1. Select the menu item "Define PIN".
2. Using the navigation keys, set a 4-digit PIN and confirm your entry with the OK key.
3. The user information "HMI PIN defined" appears on the display of the 3RW5 HMI High Feature. Confirm by pressing the OK key.
The 3RW5 HMI High Feature then returns to the "Local access protection" menu.

Result

You have defined the PIN and the set PIN is active.

8.13.3.2 Change PIN

Requirements

- 3RW5 HMI High Feature (accessory)
Menu: "Security > Local access protection"
- A PIN is defined.

Procedure

1. Select the menu item "Change PIN".
2. Log on using the current 4-digit PIN and confirm your entry with the OK key.
If the entry is correct, the user information "Log on was successful" appears on the display of the 3RW5 HMI High Feature. Confirm by pressing the OK key.
3. Using the navigation keys, set a 4-digit PIN and confirm your entry with the OK key.
The user information "HMI PIN changed" appears on the display of the 3RW5 HMI High Feature. Confirm by pressing the OK key. The 3RW5 HMI High Feature then returns to the "Local access protection" menu.
4. Select the menu item "Log on".
5. Log on using the current 4-digit PIN and confirm your entry with the OK key.
If the entry is correct, the user information "Log on was successful" appears on the display of the 3RW5 HMI High Feature. Confirm by pressing the OK key.

Result

You have changed the PIN and the changed PIN is active.

8.13.3.3 Delete PIN

Requirements

- 3RW5 HMI High Feature (accessory)
Menu: "Security > Local access protection"
- A PIN is defined.

Procedure

1. Select the menu item "Delete PIN".
2. Log on using the current 4-digit PIN and confirm your entry with the OK key.
If the entry is correct, the user information "HMI PIN deleted" appears on the display of the 3RW5 HMI High Feature. Confirm by pressing the OK key. The 3RW5 HMI High Feature then returns to the "Local access protection" menu.

Resetting the PIN via the factory setting

You can reset the local access protection to the factory setting with the master RESET key on the rear of the 3RW5 HMI High Feature (Page 180).

Result

You have deactivated and deleted the current PIN.

8.13.4 Micro SD card

Operating principle

In combination with a micro SD card, the 3RW5 HMI High Feature can perform firmware updates, exchange configuration files and service data, and store logbooks.

The replacing of configuration files allows serial parameter assignment (3RW5 HMI High Feature and 3RW5 communication module) and supports the device replacement. Observe the respective transferred parameters and data in this regard.

Note

Interruption of the connection by an unformatted micro SD card

When an unformatted micro SD card is inserted, the connection between 3RW5 HMI High Feature and the soft starter will be briefly interrupted. If the interruption lasts longer than 5 s, the error message "Preset unequal actual configuration" is output. As soon as the connection is up and running again, the error message is reset automatically.

Requirements

- Inserted micro SD card, e.g. micro SDHC Class 10
 - File format: FAT32
 - Capacity: max. 32 GB
- 3RW5 HMI High Feature
Menu: "Micro SD card"
The "Micro SD card" menu is only visible after you have inserted a micro SD card into the 3RW5 HMI High Feature.
- Access protection to the 3RW5 HMI High Feature is not active or has been reset.
- Load data onto the 3RW50 soft starter ("Load communication and HMI parameters to soft starter" or "Device change"):
 - Make sure that there is only 1 folder with configuration data on the micro SD card.
 - Rename the folder as follows: "1P3RW5 xxx-xxx" (specify the article number of the 3RW50 soft starter instead of the placeholders "x".)
Example: When you use a soft starter of size S6 with article number "3RW5055-2AB04", name the folder as follows: "1P3RW5 055-2AB".

Action

Action	Description
Load communication and HMI parameters to soft starter	<p>The parameters of the communication and the 3RW5 HMI High Feature are transferred from the micro SD card to the 3RW50 soft starter. The following data is transferred:</p> <ul style="list-style-type: none"> • Device parameters of the 3RW5 HMI High Feature • Communication parameters <p>Application: Parameterize 3RW5 HMI High Feature serially / identically (Page 105)</p>
Load communication and HMI parameters to micro SD card	<p>The parameters of the communication and the 3RW5 HMI High Feature are transferred from the 3RW50 soft starter to the micro SD card. The data is saved in an automatically generated folder (e.g. "1P3RW5 xxx-xxxx"). The following data is transferred:</p> <ul style="list-style-type: none"> • I&M 1 data (Page 138) • I&M 3 data (Page 138) • Device parameters of the 3RW5 HMI High Feature • Communication parameters <p>Applications: Parameterize 3RW5 HMI High Feature serially / identically (Page 105) "Device change" function (Page 181)</p>

8.13 3RW5 HMI High Feature

Action		Description
Device change		<p>When a device is replaced, the configuration data and communication parameters can be transferred to the new device.</p> <p>The following data is transferred:</p> <ul style="list-style-type: none"> • I&M 1 data (Page 138) • I&M 3 data (Page 138) • Device parameters of the 3RW5 HMI High Feature • Communication parameters <p>Application: "Device change" function (Page 181)</p>
Save logbooks to micro SD card		The logbooks are backed up on the micro SD card. You can find more information in Chapter Logbooks (Page 168).
Save service data to micro SD card ¹⁾		<p>The 3RW50 soft starter records service data during starting and stopping. If problems occur in the system in conjunction with the 3RW50 soft starter, you can save the service data on the micro SD card and have them evaluated by the service personnel.</p> <p>You can find more information in Chapter Save service data to micro SD card (Page 169).</p>
FW update	<ul style="list-style-type: none"> • Soft starter • Communication module • HMI 	<p>The firmware update is carried out if a valid firmware file is stored on the micro SD card. The 3RW5 HMI High Feature automatically detects which firmware file the micro SD card contains</p> <p>The firmware update is documented in the device logbook (Page 168).</p> <p>You can find more information on the firmware update in Chapter Performing firmware update with micro SD card (3RW5 HMI High Feature) (Page 177).</p>
Download language ²⁾		An additional language is loaded onto the 3RW5 HMI High Feature. You can find more information in Chapter Reloading a language for the High Feature 3RW5 HMI (Page 144).
Memory space	<ul style="list-style-type: none"> • Complete memory • Free memory • Used memory 	The memory capacity is displayed.

1) 3RW5 HMI High Feature firmware version V2.0 or higher

3) 3RW5 HMI High Feature firmware version V3.0 or higher

8.13.5 Reloading a language for the High Feature 3RW5 HMI

Requirements

- Micro SD card (Page 142) with valid language file
The first two digits of the version of the language file must match the first two digits of the firmware version (Vx.y) of the 3RW5 HMI High Feature.
You will find the current language files on the 3RW5 topic page (<https://support.industry.siemens.com/cs/ww/en/view/109747404>).
- The valid language file is located in the root directory (topmost level).

- 3RW5 HMI High Feature
Menu: "Micro SD card"
- Access protection to 3RW5 HMI High Feature is not active or has been reset.

Operating principle

The 3RW5 HMI High Feature supports the subsequent loading of an additional language. The additional language is transferred from the micro SD card to the 3RW5 HMI High Feature and can then be selected. Loading an additional language overwrites or deletes an already loaded additional language. If the additional language is active when the language update is performed, it will be retained until another language is selected. It is only possible to return to this additional language if this language is updated. The following languages contained in the factory setting of the 3RW5 HMI High Feature are not provided for downloading and are always part of the firmware update for the 3RW5 HMI High Feature:

- English (factory setting)
- German
- French
- Spanish
- Italian
- Portuguese
- Chinese

Procedure

1. Choose the menu item "Download language" and confirm with OK.
2. Select the required language file on the micro SD card and confirm with OK.

Result

You have loaded an additional language onto the 3RW5 HMI High Feature and can set it with the selection "Additional language" (Page 103).

Messages and diagnosis

9.1 Diagnostics options

The 3RW50 soft starter offers the following diagnostics options:


- LEDs on the 3RW50 soft starter
- 3RW5 HMI Standard (accessories)
- 3RW5 HMI High Feature (accessories)
- SIRIUS Soft Starter ES (TIA Portal) (accessories) via local interface on the 3RW5 HMI High Feature

Further diagnostics options

Further diagnostics options via the fieldbus can be found in the Equipment Manual for the respective 3RW5 communication module.

9.2 LED display

9.2.1 Overview of the device LEDs of the 3RW50 soft starter



① RUN (green)

Indicates whether the 3RW50 soft starter is ready for operation.

② ERROR (red)

Indicates whether there is an error.

③ MAINTAINANCE (amber)

Indicates whether a message is present.

④ STATE / OVERLOAD with LED (green / yellow-orange / red)

Indicates the motor operating state.

⑤ RESET MODE with LED (green)

Indicates the selected RESET MODE (Page 85).

⑥ SOFT TORQUE with LED (green)

Indicates whether Soft torque (Page 85) is activated or deactivated.

9.2.2 Status and error displays

LED "RN" - RUN

State	Meaning
 Lights up green	The 3RW50 soft starter is now ready for operation.
 Flashes green	The 3RW50 soft starter is not ready, e.g. due to: <ul style="list-style-type: none"> • System startup • Device factory settings are being restored. • Self-test active • Firmware update

LED "ER" - ERROR

State	Meaning
☐ Off	No errors are present.
 Flashes red	There is at least one error.

LED "MT" - MAINTENANCE / WARNING

State	Meaning
☐ Off	No alarm is active.
 Lights up yellow	At least one warning exists. The cause has not been eliminated.

LED combinations

State			Meaning
RN	ER	MT	
 Flashes green	 Flashes red	 Flashes yellow	<ul style="list-style-type: none"> • The 3RW50 soft starter is not ready. • Device error detected

9.2.3 STATE / OVERLOAD LED

ST/OL LED	Status of the 3RW50 soft starter	Motor operating state
 Lights up green	Operation	The ramp-up time comes to an end and the motor is running.
 Flashes green	Ramp-up or ramp-down time active	Motor is ramping up or ramping down.
 Off	Stop	<ul style="list-style-type: none"> Motor is switched off but might still be rotating. Motor is ready to start.
 Flashes yellow-orange	Stop - not ready to start	<ul style="list-style-type: none"> Motor is switched off but might still be rotating. Motor is not ready to start. An ON command will cause an error while at least one of the starting conditions is not fulfilled, e.g.: <ul style="list-style-type: none"> Supply voltage of motor missing.
 Flashes alternately green / yellow-orange	Operation with motor overload warning	<p>Motor has started up and is running. A motor overload warning exists, e.g.:</p> <ul style="list-style-type: none"> Motor is too hot
 Lights up yellow-orange	Stop with motor overload warning	<p>Motor has decelerated to zero speed and shut down. A motor overload warning exists, e.g.:</p> <ul style="list-style-type: none"> Motor is too hot
 Flashes red	Stop with motor overload error	<p>Motor has decelerated to zero speed and shut down due to an overload error. A motor overload error exists, e.g.:</p> <ul style="list-style-type: none"> Motor is too hot Temperature sensor wire break Temperature sensor short circuit

9.2.4 Overview of LEDs on Standard 3RW5 HMI

Device LEDs (RN, ER, MT)

The display of the device LEDs of the 3RW5 HMI Standard (Page 129) shows the status summary for the following devices:

- 3RW50 soft starter
- 3RW5 communication module (if there is one)

Please note that the display of the device LEDs of the 3RW5 HMI Standard does not have to correlate with the display of the device LEDs of the 3RW50 soft starter.

Status LED

The display on the status LEDs of the 3RW5 HMI Standard (Page 129) indicates the state of the 3RW50 soft starter and the operating state of the motor.

Status LED	Status of the soft starter	Motor operating state
 Lights up green	Operation	The ramp up time comes to an end and the motor is running.
 Flashes green	Starting or stopping time active	Motor is ramping up or ramping down.

Further information

You will find more information on the messages of the 3RW50 soft starter in the Chapter Status and error displays (Page 149).

You will find more information on the messages of the 3RW5 communication module in the manual for the 3RW5 communication module in question.

9.2.5 Overview of LEDs on High Feature 3RW5 HMI

Device LEDs (RN, ER, MT)

The display of the device LEDs of the 3RW5 HMI High Feature (Page 92) shows the status summary for the following devices:

- 3RW50 soft starter
- 3RW5 communication module (if there is one)
- 3RW5 HMI High Feature

Please note that the display of the device LEDs of the 3RW5 HMI High Feature does not have to correlate with the display of the device LEDs of the 3RW50 soft starter.

Status LED

The display on the status LEDs of the 3RW5 HMI High Feature (Page 92) indicates the state of the 3RW50 soft starter and the operating state of the motor.

Status LED	Status of the 3RW50 soft starter	Motor operating state
 Lights up green	Operation	The ramp up time comes to an end and the motor is running.
 Flashes green	Starting or stopping time active	Motor is ramping up or ramping down.

Further information

You will find more information on the messages of the 3RW50 soft starter in the Chapter Status and error displays (Page 149).

You will find more information on the messages of the 3RW5 communication module in the manual for the 3RW5 communication module in question.

9.3 Warnings and remedial actions of the 3RW50 soft starter

Display of the warnings

The 3RW50 soft starter signals warnings by means of the following displays:

- LED "MT" (yellow)
- 3RW5 HMI High Feature (accessories)
- 3RW5 HMI Standard (accessory)

Display of the warnings on the 3RW5 HMI High Feature

Detailed information about warnings and remedial actions appears in plain text on the display of the 3RW5 HMI High Feature.

Display of warnings on the 3RW5 HMI Standard

Since the 3RW5 HMI Standard does not distinguish between warnings and errors, warnings are displayed as a warning on the 3RW50 soft starter, but as errors on the 3RW5 HMI Standard. The display of the 3RW5 HMI Standard shows error numbers that you can assign to the respective warning using the following table.

Warnings and remedial measures

Error no.	Warning	Cause	Remedy
360	Connection abort in manual mode	Connection to a local control station (e.g. device HMI) has been interrupted.	<ul style="list-style-type: none"> Check the connection between the HMI and the device. Check the connection between the PC and the local device interface.
1416	Switching element too hot for Start	Switching element (switch contact, power semiconductors) too hot.	<ul style="list-style-type: none"> Check the ambient conditions associated with cooling. You may want to consider lowering the operating characteristics. Check the number of switching operations.
1539	Motor heating warning limit exceeded	<ul style="list-style-type: none"> The motor feeder is overloaded. The motor temperature has exceeded a limit. 	<ul style="list-style-type: none"> Check the motor and the applications driven by the motor. You can switch on the motor again after the cooling-off period has expired or after deleting the thermal motor model.
1629	Check fan	<ul style="list-style-type: none"> Internal fan is dirty (not rotating freely). Connecting cable has fallen off or is defective. Internal fan faulty 	<ul style="list-style-type: none"> Check the function of the fan. Clean the fan. Check the wiring. Replace the fan.

9.4 Faults and remedial actions of the 3RW50 soft starter

Display of the faults

The 3RW50 soft starter signals faults by means of the following displays:

- LED "ER" (red)
- 3RW5 HMI Standard (accessories)
- 3RW5 HMI High Feature (accessories)

Display of the faults on the 3RW5 HMI

- 3RW5 HMI Standard: The display shows fault numbers that you can assign to the respective fault on the basis of the following table.
- 3RW5 HMI High Feature: Detailed information about faults and remedial actions appears in plain text on the display.

Faults and remedial actions

Error No. ¹⁾	Error	Cause	Remedy	RESET MODE		
				Man-ual ²⁾	Re-mote ³⁾	Auto ⁴⁾
303	Bus error	-	<ul style="list-style-type: none"> • Acknowledgment via Au-to RESET 	-	-	x
308	Switching element defective	-	<ul style="list-style-type: none"> • Check switching elements L1, L2, and L3. • Replace the defective devices. 	-	-	-
309	Switching element overload	Contact block (switching contact, power semiconductor) too hot	<ul style="list-style-type: none"> • Check the ambient conditions associated with cooling. You may want to consider lowering the operating characteristics. • Check the number of switching operations. • Acknowledgment after cooling down 	x	x	-
317	Electronics supply voltage too low	The power supply (control supply voltage) is below the permissible value.	Check the power supply (load dimensioning, voltage range).	-	-	x
319	No line voltage	<ul style="list-style-type: none"> • The line side switch or the power supply is not plugged in correctly. • No current 	Check the cables and the cable connections and replace any defective components.	x	x	-
324	Temperature sensor overload	The temperature of the motor is too high.	<ul style="list-style-type: none"> • Check the motor and the application that is driven by the motor. • After triggering, the motor can only be switched on again if the temperature has reached the release position of the temperature sensor. 	x ⁵⁾	x ⁵⁾	x ⁵⁾
325	Temperature sensor wire break	A wire has broken in the sensor cable of the temperature sensor.	Check the sensor cable and the temperature sensor.	x ⁵⁾	x ⁵⁾	x ⁵⁾

9.4 Faults and remedial actions of the 3RW50 soft starter

Error No. ¹⁾	Error	Cause	Remedy	RESET MODE		
				Man-ual ²⁾	Re-mote ³⁾	Auto ⁴⁾
326	Temperature sensor short-circuit	A short-circuit has occurred in the sensor line of the temperature sensor.	Check the sensor cable and the temperature sensor.	x ⁵⁾	x ⁵⁾	x ⁵⁾
327	Thermal motor model overload	<ul style="list-style-type: none"> The motor feeder is overloaded. The motor temperature has exceeded a limit. 	<ul style="list-style-type: none"> Check the motor and the applications driven by the motor. You can switch on the motor again after the cooling-off period has expired or after deleting the thermal motor model. 	x ⁵⁾	x ⁵⁾	x ⁵⁾
328	Motor overload protection - shutoff	<ul style="list-style-type: none"> The motor feeder has been overloaded The temperature rise of the motor has exceeded a limit value 	<ul style="list-style-type: none"> Check the motor and the applications driven by the motor. You can switch on the motor again after the cooling-off period has expired or after deleting the thermal motor model. 	x ⁵⁾	x ⁵⁾	x ⁵⁾
360	Warning, shown in 3RW59 HMI Standard as an error, see Chapter Warnings and remedial actions of the 3RW50 soft starter (Page 152)	-	-	-	-	-
378	FW update faulty	The firmware is incomplete and / or the firmware expansions are incomplete or incompatible.	<ul style="list-style-type: none"> Execute a complete firmware update. Check any occurring error messages. Check to see whether the firmware update has been interrupted. 	-	-	x
381	Self-test error	Unrecoverable error detected after internal diagnostics (self-test, contactor contacts, switching element, etc.).	<p>Switch off the power supply (control supply voltage) for at least 5 seconds and switch it on again. If the error is still present, proceed as follows:</p> <ul style="list-style-type: none"> Please contact Technical Support (Support Request (Page 10)). Replace the device. 	-	-	-

9.4 Faults and remedial actions of the 3RW50 soft starter

Error No. ¹⁾	Error	Cause	Remedy	RESET MODE		
				Man-ual ²⁾	Re-mote ³⁾	Auto ⁴⁾
1408	Missing load	No current flow is detected after the motor feeder is switched on. Possible causes: <ul style="list-style-type: none"> • Main circuit interrupted (fuse, circuit breaker) • Motor contactor or contactor control is defective • No load 	<ul style="list-style-type: none"> • Acknowledgment once the cause has been rectified. 	x	x	-
1409	Loss of phase L1	The main power monitoring detects a phase failure.	<ul style="list-style-type: none"> • Acknowledgment once the cause has been rectified. 	x	x	-
1410	Loss of phase L2					
1411	Phase failure L3					
1416	Warning, shown in 3RW59 HMI Standard as an error, see Chapter Warnings and remedial actions of the 3RW50 soft starter (Page 152)	-	-	-	-	-
1417	Bypass defective	<ul style="list-style-type: none"> • Bypass defective • The error can also be generated by successive, brief interruptions of the supply voltage (control supply voltage). 	Switch off the power supply (control supply voltage) for at least 5 seconds and switch it on again. If the error is still present, proceed as follows: <ul style="list-style-type: none"> • Please contact Technical Support (Support Request (Page 10)). • Check bypasses for L1, L2, and L3 and replace defective bypasses. 	-	-	-
1418	Bypass protective shut-off	An excessively high current has occurred in bypass mode.	<ul style="list-style-type: none"> • Check the motor. • Check the dimensioning of the soft starter. • Acknowledgment after cooling down 	x	x	-
1454	Preset unequal actual configuration	There is a difference between a real module slot and a slot configured in the SIRIUS Soft Starter ES (TIA Portal).	<ul style="list-style-type: none"> • Ensure consistency between plugged and configured module. Possibly the referenced module has a wiring error. • After the cause is eliminated, the error self-acknowledges. 	-	-	-

9.4 Faults and remedial actions of the 3RW50 soft starter

Error No. ¹⁾	Error	Cause	Remedy	RESET MODE		
				Man-ual ²⁾	Re-mote ³⁾	Auto ⁴⁾
1466	Switching element L1 defective	Switching element defective	Switch off the power supply (control supply voltage) for at least 5 seconds and switch it on again. If the error is still present, proceed as follows: <ul style="list-style-type: none"> • Please contact Technical Support (Support Request (Page 10)). • Check the switching elements for L1 and L3 and replace any that are defective. 	-	-	-
1468	Switching element L3 defective					
1479	Phase control failure	<ul style="list-style-type: none"> • Error appears without motor start: <ul style="list-style-type: none"> – Motor incorrectly connected – Inside-delta circuit wrongly configured – Ground fault • Error appears while motor is starting: <ul style="list-style-type: none"> – Starting voltage too high 	<ul style="list-style-type: none"> • Check and correct the wiring. • Adapt parameters. 	x	x	-
1482	Current measuring range exceeded	<ul style="list-style-type: none"> • With sensors: The measured value exceeds the measuring range • With actuators: The output value exceeds a high limit value 	<ul style="list-style-type: none"> • Check the interaction between the module and the sensor or actuator. 	x	x	-
1523	Device error	Unrecoverable error detected after internal diagnostics (self-test, contactor contacts, switching element, etc.).	Switch off the power supply (control supply voltage) for at least 5 seconds and switch it on again. If the device error is still present, proceed as follows: <ul style="list-style-type: none"> • Please contact Technical Support (Support Request (Page 10)). • Replace the device. 	-	-	-

9.5 Faults and remedial actions of the 3RW5 HMI High Feature

Error No. ¹⁾	Error	Cause	Remedy	RESET MODE		
				Man-ual ²⁾	Re-mote ³⁾	Auto ⁴⁾
1539	Warning, shown in 3RW59 HMI Standard as an error, see Chapter Warnings and remedial actions of the 3RW50 soft starter (Page 152)	-	-	-	-	-
1605	Line voltage for test required	<ul style="list-style-type: none"> The line side switch or the power supply is not plugged in correctly. No current 	Check the cables and the cable connections and replace any defective components.	x	x	-
1629	Warning, shown in 3RW59 HMI Standard as an error, see Chapter Warnings and remedial actions of the 3RW50 soft starter (Page 152)	-	-	-	-	-
1755	Operating temperature too high	The temperature in the components has exceeded the maximum limit.	Check the ambient temperature or the control cabinet ventilation.	-	-	x

¹⁾ Visible on the display of the 3RW5 HMI Standard.

²⁾ Acknowledgment via Manual RESET.

³⁾ Acknowledgment via Remote RESET.

⁴⁾ Acknowledgment via Auto RESET.

⁵⁾ Acknowledgment depends on parameter RESET MODE.

9.5 Faults and remedial actions of the 3RW5 HMI High Feature

Display of the faults on the 3RW5 HMI High Feature

Detailed information about faults and remedial actions appears in plain text on the display.

Faults and remedial actions

Error	Cause	Remedy
Error HMI	Unrecoverable error detected after internal diagnostics (self-test, etc.).	Replace the device.
FW update not successful	The firmware is incomplete and/or the firmware expansions are incomplete or incompatible.	<ul style="list-style-type: none"> Run a complete firmware update. Check any error messages that occur. Check to see whether or not the firmware update was aborted.

9.6 Performing diagnostics of the 3RW50 soft starter with the 3RW5 HMI High Feature

Error	Cause	Remedy
Error during self-test	Unrecoverable error detected after internal diagnostics (self-test, etc.).	Replace the device.
Write Error	File cannot be written to the micro SD card.	<ul style="list-style-type: none"> Check whether the micro SD card is inserted. Check whether the micro SD card is write-protected.
FWUpdateInvalidSignature	The firmware is incomplete and/or the firmware expansions are incomplete or incompatible.	<ul style="list-style-type: none"> Run a complete firmware update. Check any error messages that occur. Check to see whether or not the firmware update was aborted.
No device answer	The connection to the connected soft starter has been interrupted.	Check the connection between the HMI and the device.
Loading language unsuccessful ¹⁾	Subsequently loading the language is incomplete and/or the loaded language is incomplete or incompatible.	<ul style="list-style-type: none"> Ensure the languages are loaded completely. Check any error messages that occur. Check to see whether or not loading the language has been interrupted.
Invalid signature 'Load additional language' ¹⁾		

¹⁾ 3RW5 HMI High Feature firmware version V3.0 or higher

9.6 Performing diagnostics of the 3RW50 soft starter with the 3RW5 HMI High Feature

Requirements

- 3RW5 HMI High Feature
Menu: "Diagnosis > Soft Starter"

Parameter

Diagnostic value	Comment
Diagnosis state	Shows all active warnings and faults. You can acknowledge errors here (manual RESET).

9.6 Performing diagnostics of the 3RW50 soft starter with the 3RW5 HMI High Feature

Diagnostic value		Comment
Device state	Type of connection	<p>If the 3RW50 soft starter is supplied with main power and a motor is connected, the type of connection is automatically detected.</p> <ul style="list-style-type: none"> Type of motor connection unknown Type of motor connection inline
	Rotation direction	<ul style="list-style-type: none"> Unknown main power direction (direction of phase rotation of the power system at terminals L1/L2/L3 not detected) Clockwise Counter-clockw.
	Ready (automatic)	
	Motor CW	
	Starting mode active	
	Stopping mode active	
	Cooling time active	
	Current limiting active	
	Input control	
	Input 1	
	Maximum pointer reset	
	CPU/Master STOP	
	Automatic mode	
	Operating mode manual - bus	
	Operating mode manual - local	
	Main power rotation right	
	Main power rotation left	
	Output 1 active	
	Output 2 active	
	Output 3 active	
	Ready to start for motor ON	
	Thermal motor model deactivated	
	Switching element cooling time active	
	Manual operation bus - PC controlled	
	Manual operation local - input controlled	
	Manual operation local - HMI controlled	
	Manual operation local - PC controlled	
	FW update rejected	
	FW update active	
	FW update successful	
	Operation / bypass active	
	Normal operation active	
	Test mode active	
	Missing initialization after maintenance	
	Test with small load active	
	Logbook application – errors deleted	

Diagnostic value		Comment
Statistic data ¹⁾	Operating hours - motor	
	Number of motor overload trips	
	Number of starts motor CW	
	Phase current max (%)	
	Phase current max (rms)	
	Last tripping current I_A (%)	
	Last tripping current I_A (rms)	
	Number of switching element overload trips	
	Number of bypass overload trips	
	Operating hours – device	
Maximum pointer ²⁾	Phase currents (%)	Phase current I L1 min (%)
		Phase current I L2 min (%)
		Phase current I L3 min (%)
		Phase current I L1 max (%)
		Phase current I L2 max (%)
		Phase current I L3 max (%)
	Phase currents (rms)	Phase current I L1 min (rms)
		Phase current I L2 min (rms)
		Phase current I L3 min (rms)
		Phase current I L1 max (rms)
		Phase current I L2 max (rms)
		Phase current I L3 max (rms)
	Maximum trigger current	
	Maximum trigger current	
	Number of motor overload trips	
	Maximum switching element heating	
Self-test (user-test)		Initiate the self-test functions of the 3RW50 soft starter here. For more information, see Chapter Self-test (user-test) (Page 164).
Logbooks		The logbook is a history memory in which events, warnings and faults are shown with a real-time stamp and stored in a list. The logbook can be stored on a micro SD card (Page 142). For more information, see Chapter Logbooks (Page 168).

¹⁾ The statistic data is based primarily on operating states relating to operating hours and operating frequency of the 3RW50 soft starter in the past.

²⁾ Maximum pointers are based on measured values and represent the highest or smallest measured value that occurred in the past.

9.7 Performing diagnostics of the 3RW5 communication module with the 3RW5 HMI High Feature

With the diagnosis, you can display the diagnosis state of the 3RW5 communication module.

Requirements

- 3RW5 HMI High Feature (accessory)
Menu: "Diagnosis > Communication module"
- 3RW5 communication module (accessory)

Parameter

Diagnostic value	Comment
Diagnosis state	Shows all active prewarnings and faults. You can acknowledge faults here.

Additional information

You will find further information on the diagnostics of the 3RW5 communication module in the Equipment Manual for the respective 3RW5 communication module.

9.8 Execute HMI diagnostics with the 3RW5 HMI High Feature

With the diagnosis, you can display the diagnosis state of the 3RW5 HMI High Feature and check correct functioning of the 3RW5 HMI High Feature with various tests.

Requirements

- 3RW5 HMI High Feature (accessory)
Menu: "Diagnosis > HMI"

Note

Self-tests

To be able to start the self-tests with a 3RW5 HMI High Feature with firmware version V3.1, the motor connected to the 3RW5 soft starter must be switched off.

3RW5 HMI High Feature with firmware version V3.1 or earlier: During the self-test, you cannot switch off the motor on the 3RW5 HMI High Feature. If you are controlling the motor via the 3RW5 HMI High Feature, switch off the motor before a self-test.

Parameters

Diagnostic value		Comment
Diagnosis state		Shows all active diagnostic messages (faults, warnings, device state).
Self-test	Test LEDs	The device LEDs of the 3RW5 HMI High Feature are tested one after the other. The display shows which device LED is currently being controlled. Navigate through the test operation with the OK key.
	Test buttons	The 3RW5 HMI High Feature keys are tested one after the other. The display shows which keys must be actuated in sequence in order to perform the test.
	Test display	The 3RW5 HMI High Feature runs a color program on the display. Navigate through the test operation with the OK key.

9.9 Self-test (user-test)

With the Self-test (user-test), you can test correct functioning of the 3RW5 soft starter (LEDs, current measurement, electronic motor overload protection).

Requirements

- The 3RW5 soft starter is in a fault-free condition.
- Perform the test with the motor switched off.

Activation options

- Using the RESET / TEST key on the 3RW5 soft starter
- 3RW5 HMI High Feature (accessory)
Menu: "Diagnosis > Soft Starter > Self-test"
The 3RW5 HMI High Feature (LOCAL) has master control. Access protection to 3RW5 HMI High Feature is not active or has been reset.
Here the self-test (user-test) is run through completely.

Procedure - Activation with the RESET / TEST key

Depending on how long the RESET / TEST keys are held pressed, the following tests are performed in the specified sequence. Thus, if the key is held pressed for longer than 8 seconds, all 4 tests are performed. If you press and hold the key for only 3 seconds, for example, the first 2 tests are conducted.

Operating time	Explanation
0.15 ... 2 s	LED test All LEDs are controlled.
2 ... 5 s	Visual display of the position of the rotary coding switch 16 different positions are available for the rotary coding switch for setting the rated operational current I_e of the motor. The table "Visual display of the position of the rotary coding switch" displays the exact position of the rotary coding switch based on a combination of 5 LEDs. You can find more information in Chapter Setting elements on 3RW50 soft starter (Page 81).
5 ... 8 s	Current detection test The current detection is tested in all 3 phases. In the case of 3RW5 soft starters with thermistor motor protection, the thermistor evaluation unit is also checked.
> 8 s	Motor overload protection test The entire control circuit is tested, including the contact blocks and the error signaling output. If the 3RW5 soft starter responds correctly, an overload trip occurs. This can be reset immediately without a cooling-down period by pressing the TEST / RESET key again.

Test result

The test results are provided in the following tables. If the 3RW5 soft starter does not respond as shown in the tables below during the function test, check the external connections, their function, and the wiring. If the error persists even though the connections are correct, the 3RW5 soft starter must be replaced.

If a 3RW5 HMI is connected to the 3RW5 soft starter, the 3RW5 HMI indicates "Motor overload protection - shutoff" when it passes the function test. If the 3RW5 soft starter does not pass the function test, the 3RW5 HMI indicates a device error.

LED test

LED	Display of test result	
	pass	fail
"RN"	 Lights up green	☐ Off
"ER"	 Lights up red	☐ Off

9.9 Self-test (user-test)

LED	Display of test result	
	pass	fail
"MT"	 Lights up yellow	☐ Off
"STATE / OVERLOAD"	 Lights up yellow-orange	☐ Off
"RESET MODE"	 Lights up green	☐ Off
"SOFT TORQUE"	 Lights up green	☐ Off

Visual display of the position of the rotary coding switch

Position of the rotary coding switch "Rated operational current I_e of the motor"	LED					
	"RN"	"ER"	"MT"	"STATE / OVERLOAD"	"RESET MODE"	"SOFT TORQUE"
1	 Flickers green	☐ Off	☐ Off	☐ Off	☐ Off	 Lights up green
2	 Flickers green	☐ Off	☐ Off	☐ Off	 Lights up green	☐ Off
3	 Flickers green	☐ Off	☐ Off	☐ Off	 Lights up green	 Lights up green
4	 Flickers green	☐ Off	☐ Off	 Lights up green	☐ Off	☐ Off
5	 Flickers green	☐ Off	☐ Off	 Lights up green	☐ Off	 Lights up green
6	 Flickers green	☐ Off	☐ Off	 Lights up green	 Lights up green	☐ Off
7	 Flickers green	☐ Off	☐ Off	 Lights up green	 Lights up green	 Lights up green

Position of the rotary coding switch "Rated operational current I_e of the motor"	LED					
	"RN"	"ER"	"MT"	"STATE / OVERLOAD"	"RESET MODE"	"SOFT TORQUE"
8	 Flickers green	☐ Off	 Lights up yellow	☐ Off	☐ Off	☐ Off
9	 Flickers green	☐ Off	 Lights up yellow	☐ Off	☐ Off	 Lights up green
10	 Flickers green	☐ Off	 Lights up yellow	☐ Off	 Lights up green	☐ Off
11	 Flickers green	☐ Off	 Lights up yellow	☐ Off	 Lights up green	 Lights up green
12	 Flickers green	☐ Off	 Lights up yellow	 Lights up green	☐ Off	☐ Off
13	 Flickers green	☐ Off	 Lights up yellow	 Lights up green	☐ Off	 Lights up green
14	 Flickers green	☐ Off	 Lights up yellow	 Lights up green	 Lights up green	☐ Off
15	 Flickers green	☐ Off	 Lights up yellow	 Lights up green	 Lights up green	 Lights up green
16	 Flickers green	 Lights up red	☐ Off	☐ Off	☐ Off	☐ Off

Current detection test

LED	Display of test result	
	pass	fail
"STATE / OVERLOAD"	 Flickers red	☐ Off In case of error: System LEDs (RN, ER, MT) flashing. Device error, replace device.

Motor overload protection test

	Display of test result	
	pass	fail
"STATE / OVERLOAD" LED	 Flashes red	☐ Off In case of error: System LEDs (RN, ER, MT) flashing. Device error, replace device.
"ER" LED	 Flashes red	In case of error: System LEDs (RN, ER, MT) flashing. Device error, replace device.
Error signaling output	Active	Not active
Contact blocks / motor	Deactivated	Unchanged

Self-test of the 3RW5 HMI High Feature

You will find more information on the self-test of the 3RW5 HMI High Feature in Chapter Execute HMI diagnostics with the 3RW5 HMI High Feature (Page 163).

9.10 Logbooks**Operating principle**

The logbook lists events, warnings, and faults in chronological order. Each entry is stamped with the real time. For the 3RW50 soft starter there are the following logbooks:

- Logbook application
- Logbook device

The logbook is designed as a circular buffer.

Display and editing options

- 3RW5 HMI High Feature
Menu: "Diagnosis > Soft Starter > Logbook"
- With SIRIUS Soft Starter ES (TIA Portal) via the local interface on the 3RW5 HMI High Feature
Brief overview: Window "Project Navigation" with current project under created Soft Starter > "Commissioning" > Window "Work area" > "Soft Starter > Logbook"
- With a fieldbus via a 3RW5 communication module (only via a 3RW5 PROFINET or PROFIBUS communication module):
 - With SIRIUS Soft Starter ES (TIA Portal) Premium / Professional

Logbook application

The logbook application contains all messages relating to functions and parameters. This logbook is only available in the 3RW50 soft starter. The logbook application can be deleted with the command "Delete logbook application – error".

Logbook device

The following messages are recorded in the device logbook:

- Error
- Warnings
- Event

The device logbook is available in every module (3RW50 soft starter, 3RW5 HMI High Feature, 3RW5 communication module) and cannot be deleted.

Saving logbooks

1. You can save the logbooks on a micro SD card (Page 142) if a micro SD card is inserted in the HMI HF:
 - Menu: "Micro SD card > Save logbooks to micro SD card"
 - Click "OK". A *.csv file is stored on the micro SD card, which you can read out with Microsoft Excel, for example.

9.11 Save service data to micro SD card

Requirements

- 3RW50 soft starter as of firmware version V1.0.1
- 3RW5 HMI High Feature firmware from version V2.0
Menu: "Micro SD card"
The "micro SD Card" menu appears after you have inserted a micro SD card into the 3RW5 HMI High Feature.

9.11 Save service data to micro SD card

- Inserted micro SD card (Page 142)
- Access protection to the 3RW5 HMI High Feature is not active or has been reset.
- Motor switched off

Operating principle

The 3RW50 soft starter records service data during starting and stopping. If problems occur in the system in conjunction with the 3RW50 soft starter, you can save the service data on the micro SD card. The service data can help Technical Support to handle the case in the event of a Support Request (Page 10). The service data contain the following data, for example:

- Parameters
- Logbooks
- Statistic data
- Maximum pointer
- I&M data

Procedure

Save the service data on the 3RW5 HMI High Feature onto the micro SD card.

Menu: "Micro SD card > Save service data to micro SD card"

Saving the service data can take a little time (> 1 minute). At the top level of the micro SD card, a folder is created with the serial number of the 3RW50 soft starter in which the service data are stored. Example of a created folder name: "1P3RW5 xxx-xxxxx+SLO..."

Note

Save service data to micro SD card

While the service data are being saved to the micro SD card, the color of the micro SD card icon changes from blue to red on the display 3RW5 HMI High Feature. If the service data have been saved completely, the color of the icon changes back to blue.

Icon of the micro SD card on the display of the 3RW5 HMI High Feature:



Alternative procedure with the Soft Starter ES V18 and higher

Alternatively, you can also store the service data on the micro SD card with Soft Starter ES V18 and higher.

An online connection between the 3RW50 soft starter and Soft Starter ES is required.

Open "Commissioning" in the "Project navigation" with the corresponding soft starter. In the "Work area", navigate to "Soft Starter > Functions > Service Data".

Result

You have stored the service data on the micro SD card.

These service data can help Technical Support to handle the case in the event of a Support Request (Page 10). If necessary, read the micro SD card in at a PC and send the folder of service data as a ZIP file.

Maintenance and service

10.1 Maintenance and repairs

WARNING

Hazardous voltage.

Will cause death or serious injury.

The present device / part conducts hazardous voltages.

Touching live components will result in death or severe injury.

Installation, commissioning, and maintenance only by qualified specialist personnel.

Repair of the devices is only permissible by qualified personnel. Contact the authorized Siemens service partner for this.

Note

Loss of ATEX / IECEx approval

The repair of devices with approval according to IEC 61508 / EN 13849 is only permissible in the manufacturer's plant.

A repair to the 3RW50 soft starters that is not performed in the manufacturer's plant results in loss of ATEX / IECEx approval.

10.2 Replacing the fan

Requirements

- Replacement fan
- Optional: The fan cover is disassembled.

Procedure




DANGER

Hazardous voltage.


Will cause death or serious injury.

Disconnect the system and the device from the power supply before starting work.


10.2 Replacing the fan




On the underside of the soft starter, pull the lugs on the left and right out of the latch guide ①. The lugs remain in the enclosure.



Remove the defective fan ② and disconnect the plug with the cable ③.



Insert the plug of the cable of the replacement part ① and fit the replacement fan ②.



Press the two lugs back into the housing until they audibly engage ③.

10.3 Firmware update

During operation, it may be necessary to update the firmware (e.g. to extend the available functions). You update the firmware of the respective device with the help of device-specific firmware files. The retentive data is retained after the firmware has been updated.

Firmware updates and a history of the versions with the innovations are provided to you on the Internet. Depending on what firmware updates are available, you can update the devices individually or together.

You can perform a firmware update for the following devices:

- 3RW50 soft starter
- 3RW5 HMI High Feature (not possible via fieldbus)
- 3RW5 communication modules

Requirements

- Valid firmware update
You will find the latest firmware files on the 3RW5 topic page (<https://support.industry.siemens.com/cs/ww/en/view/109747404>).

Procedure

1. Make sure that the motor is switched off and you do not start the motor during the firmware update.
A control command for starting the motor is not supported during the firmware update. To ensure the quickest and most fault-free firmware update, it is recommended that you disconnect the main power of the 3RW50 soft starter and set the CPU / PLC to the STOP operating state.
2. Perform the update of the device firmware.
The following procedures are possible:
 - With a micro SD card via the 3RW5 HMI High Feature (Page 177)
 - Via the local interface of the 3RW5 HMI High Feature with SIRIUS Soft Starter ES (TIA Portal)
 - With a fieldbus via a 3RW5 communication module with SIRIUS Soft Starter ES (TIA Portal) Premium / Professional or the configuration software of the controller (e.g. STEP 7 with corresponding HSP) (via a 3RW5 PROFINET or PROFIBUS communication module only).

Result

You have performed a firmware update for the selected device. The selected device automatically restarts.

Note

Firmware update of the 3RW5 HMI High Feature

Please note that the display switches off for about 30 seconds when the firmware is activated.

10.4 Performing firmware update with micro SD card (3RW5 HMI High Feature)

Requirements

- Micro SD card with valid firmware file (*.upd)
- The valid firmware file is located in the root directory (topmost level)
- 3RW5 HMI High Feature
Menu: "Micro SD card > FW update"
- Access protection to 3RW5 HMI High Feature is not active or has been reset.

Procedure

Note

Access to micro SD card.

Please note that the micro SD card is inserted in the 3RW5 HMI High Feature during updating of the firmware.

Premature removal of the micro SD card from the 3RW5 HMI High Feature is not permissible and will terminate updating of the firmware. Data could also be lost.

1. Select the folder of the respective device.
2. Select the firmware file of the device and confirm with the OK key.
You can see the firmware update is being performed from the progress bar on the display. Following successful updating of the firmware, the respective device then restarts automatically.

Note

Firmware update of the 3RW5 HMI High Feature:

Please note that the display switches off for about 30 seconds when the firmware is activated.

3. Check the new firmware version in the "Overview" menu.

Result

You have performed a firmware update for the selected device using the micro SD card.

10.5 Restoring factory setting

10.5.1 Effects of the factory setting

Effects of the factory setting

The following devices can be reset to the factory setting:

- 3RW50 soft starter
 - The parameters of the 3RW50 soft starter that were not set via the setting elements are reset.
- 3RW5 communication module
 - The parameters of the 3RW5 communication module are reset.
- 3RW5 HMI High Feature
 - The parameters of the 3RW5 HMI High Feature and the PIN for access protection are reset to the factory setting.
- All devices
 - The 3RW50 soft starter, the 3RW5 communication module, and the 3RW5 HMI High Feature are reset to the factory settings, as described above.

Possible factory settings

The following procedures are possible:

- With the MODE and RESET / TEST (Page 180) keys.
- Via the 3RW5 HMI High Feature:
 - Restoring the factory settings via High Feature 3RW5 HMI (Page 179)
 - Restoring the factory settings with the Master RESET button via 3RW5 HMI High Feature (Page 180)
- Via the local interface on the 3RW5 HMI High Feature with SIRIUS Soft Starter ES (TIA Portal)
- With a fieldbus via a 3RW5 communication module:
 - With SIRIUS Soft Starter ES (TIA Portal) Premium / Professional (only via a 3RW5 PROFINET or PROFIBUS communication module).
 - "Factory settings" command in data record 93 (only via a 3RW5 PROFINET or PROFIBUS communication module).
 - With the configuration software of the control (only via a 3RW5 PROFINET or EtherNet/IP communication module). Only the communication parameters are reset here.

Result

The factory setting of the selected device or all devices is restored.

10.5.2 Restoring the factory settings via High Feature 3RW5 HMI

Requirements

- Make sure that the motor is switched off and you do not start the motor while restoring the factory settings.
To ensure the quickest and most fault-free restoration of the factory setting, it is recommended that you disconnect the main power at the 3RW50 soft starter.
- 3RW5 HMI High Feature
Menu: "Parameters > Factory settings"
- Access protection to 3RW5 HMI High Feature is not active or has been removed.
- The 3RW5 HMI High-Feature (LOCAL) has master control.

Procedure

1. Select the desired menu item.
 - Soft starter
 - Communication module
 - HMI High Feature
 - All devices
2. Confirm the menu item by pressing the OK key.

Result

The factory setting of the selected device or all devices is restored.

Note the effects of the factory settings described in Chapter Effects of the factory setting (Page 178).

10.5.3 Restoring the factory settings with the Master RESET button via 3RW5 HMI High Feature

Requirements

- Make sure that the motor is switched off and you do not start the motor while restoring the factory settings.
To ensure the quickest and most fault-free restoration of the factory setting, it is recommended that you disconnect the main power at the 3RW50 soft starter.
- Free access to the Master RESET key of the 3RW5 HMI High Feature.
- 3RW5 HMI High Feature is connected to the 3RW5 soft starter via the HMI connecting cable.

Procedure

1. Press the Master RESET key on the rear of the 3RW5 HMI High Feature.
The menu for restoring the factory setting appears on the display.
2. Select the desired menu item.
 - Soft starter
 - Communication module
 - HMI High Feature
 - All devices
3. Confirm the menu item by pressing the OK key.

Result

The factory setting of the selected device or all devices is restored.

Note the effects of the factory settings described in Chapter Effects of the factory setting (Page 178).

10.5.4 Restoring the factory settings with the MODE and RESET / TEST keys

Requirements

- Make sure that the motor is switched off and you do not start the motor while restoring the factory settings.
To ensure the quickest and most fault-free restoration of the factory setting, it is recommended that you disconnect the main voltage at the 3RW50 soft starter.
- The 3RW5 communication module must be isolated from the 3RW50 soft starter.

Procedure

1. Start the restoration of the factory settings by pressing the MODE key longer than 2 s until the STATE / OVERLOAD LED flickers green.
Press and hold the MODE key.
2. Simultaneously press the RESET / TEST key down for at least 10 s.
After 2 s, the STATE / OVERLOAD LED begins to illuminate red.
After 10 s the STATE / OVERLOAD LED goes out and switches back to displaying the motor operating state (e.g. flashing yellow-orange if there is no supply voltage).
3. Release the MODE and RESET / TEST keys.

Result

The factory setting of the 3RW50 soft starter has been restored.

Note the effects of the factory settings described in Chapter Effects of the factory setting (Page 178).

10.6 "Device change" function



WARNING

**Hazardous voltage.
Can cause death or serious injury.**

The present device/part conducts hazardous voltages.

Touching live components will result in death or severe injury.

Installation, commissioning, and maintenance only by qualified specialist personnel.

The device replacement is only permissible by qualified personnel.

Operating principle

If the 3RW5 soft starter, the 3RW5 HMI High Feature (accessory) or the 3RW5 communication module (accessory) has to be replaced because of a fault, you can transfer data to your new device (identical type) using the "Device change" function or SIRIUS Soft Starter ES (TIA Portal). To be able to transfer data, you must first save it.

The following data are transferred with the "Device change" function:

- I&M 1 data
- I&M 3 data
- Device parameters of the 3RW5 HMI High Feature
- Communication parameters

Transmission options

- Device change with micro SD card on the 3RW5 HMI High Feature (Page 182)
- Device change with SIRIUS Soft Starter ES (TIA Portal) (Page 183)

10.6.1 Device change with micro SD card on the 3RW5 HMI High Feature

Requirements

- 3RW5 HMI High Feature (accessory)
- Micro SD card with the saved data (Page 142)
 - The folder (e.g. "1P3RW5 xxx-xxxxx+SLO...") is located in the root directory (top level).
 - The article number in the name of the folder must match the article number of the 3RW5 soft starter. The serial number in the name of the folder ("SLO...") does not need to match.
 - Menu: "Micro SD card > Load communication and HMI parameters to micro SD card"
The data is saved in an automatically generated folder (e.g. "1P3RW5 xxx-xxxxx+SLO...").

Procedure

1. Plug the micro SD card into the 3RW5 HMI High Feature.
2. Transfer the data to the device (3RW5 soft starter, 3RW5 HMI High Feature, 3RW5 communication module).
Menu: "Micro SD card > Device change"

Note

Device change

The current data of all devices (3RW5 soft starter, 3RW5 HMI High Feature, 3RW5 communication module) are overwritten by the data on the micro SD card.

3. Check the transferred data.

Result

You have transferred your saved data to your devices (3RW5 soft starter, 3RW5 HMI High Feature, 3RW5 communication module) with the "Device change" function.

Set the required device parameters of the 3RW50 soft starter.

10.6.2 Device change with SIRIUS Soft Starter ES (TIA Portal)

Requirements

- Accessories, e.g. 3RW5 HMI High Feature or 3RW5 PROFINET or PROFIBUS communication module
- Connection of the 3RW5 soft starter to the PC / programming device on which the SIRIUS Soft Starter ES (TIA Portal) is installed.
The 3RW5 soft starter must not be connected online to SIRIUS Soft Starter ES (TIA Portal).
- Project in SIRIUS Soft Starter ES (TIA Portal) with saved data (identical type)
Button: "Upload from device" on the toolbar.
In the "Project navigation" window, the 3RW5 soft starter must be selected in the current project so that the button can be operated.

Procedure

1. Transfer the data to the device (3RW5 soft starter, 3RW5 HMI High Feature, 3RW5 communication module) with SIRIUS Soft Starter ES (TIA Portal).
Button: "Load to device" on the toolbar.
In the "Project navigation" window, the 3RW5 soft starter must be selected in the current project so that the button can be operated.

Note

Device change

The current data of all devices (3RW5 soft starter, 3RW5 HMI High Feature, 3RW5 communication module) are overwritten by the transferred data.

2. Check the transferred data.

Result

You have transferred your saved data to your devices (3RW5 soft starter, 3RW5 HMI High Feature, 3RW5 communication module) with SIRIUS Soft Starter ES (TIA Portal).

Set the required device parameters of the 3RW50 soft starter.

10.6 "Device change" function

Technical specifications

11.1 Product information in the Siemens SiePortal

Product data

You can find the technical specifications, CAx data and more information for the product in Siemens SiePortal (<https://sieportal.siemens.com/en-ww/home>).

1. In the search window, enter the article number of the product.
2. In the list of products that opens, click on the desired product.
3. On the following page you will find specifications, documents and downloads for E-CAD, dimensional drawings, product data sheets for your product.

Dimension drawings

12.1 Product information in the Siemens SiePortal


Product data

You can find the technical specifications, CAx data and more information for the product in Siemens SiePortal (<https://sieportal.siemens.com/en-ww/home>).

1. In the search window, enter the article number of the product.
2. In the list of products that opens, click on the desired product.
3. On the following page you will find specifications, documents and downloads for E-CAD, dimensional drawings, product data sheets for your product.


12.2 Drilling pattern for 3RW5 HMI Standard

The drilling pattern below supports you when installing a 3RW5 HMI Standard with push-in lugs on a level surface.




12.3 Drilling pattern for 3RW5 HMI High Feature

The drilling pattern below supports you when installing a 3RW5 HMI High Feature with push-in lugs on a level surface.




12.4 Drilling patterns for 3RW5 communication module on the 3RW50 soft starter

3RW5 communication module on the 3RW50 soft starter size S6



3RW5 communication module on the 3RW50 soft starter size S12



Circuit diagrams

13.1 Product information in the Siemens SiePortal

Product data

You can find the technical specifications, CAx data and more information for the product in Siemens SiePortal (<https://sieportal.siemens.com/en-ww/home>).

1. In the search window, enter the article number of the product.
2. In the list of products that opens, click on the desired product.
3. On the following page you will find specifications, documents and downloads for E-CAD, dimensional drawings, product data sheets for your product.


Example circuits

A.1 Main circuit connection

A.1.1 Feeder assembly, type of coordination 1 fuseless

Feeder assembly, type of coordination 1 fuseless

The connections of the 3RW50 soft starter are wired into the motor feeder between the motor starter protector and the motor. This achieves type of coordination 1.



- Q1 Motor starter protector (e.g. 3RV2 or 3VA)
- Q11 3RW50 soft starter
- M1 Motor


PE Protective conductor

A.1.2 Feeder assembly, type of coordination 1 with fuses

If a main or line contactor is used, it should not be connected between the 3RW50 soft starter and the motor. The 3RW50 soft starter could otherwise indicate a "Missing load voltage" fault in case of a start command and delayed connection of the contactor.

Feeder assembly, type of coordination 1 with fuses


If galvanic isolation is required, install a main or line contactor between the 3RW50 soft starter and the fuses.



A.1.3 Feeder assembly, type of coordination 2

Feeder assembly, type of coordination 2

In order to achieve type of coordination 2, you must provide protection for all thyristors against short circuits by means of special semiconductor fuses (e.g. SITOR fuses from Siemens). A short circuit can occur, for instance, as a result of a defect in the motor windings or in the motor's power supply cable.



A.2 Control current connection

A.2.1 Control by pushbutton

Requirements

ON / RUN relay output was parameterized to ON.



WARNING

Automatic restart.


Can cause death or serious injury.

If a starting command is pending, a restart will be triggered automatically after the reset. This particularly applies if the motor protection has tripped. Dangerous states of the system can result.

Reset the start command (e.g. via the PLC or switch) before performing a reset.

To do this, for example, link the group error output (terminals 95 and 96) into the control.

Wiring of control circuit for control by pushbutton



- | | |
|-----|-------------------------|
| F1 | Fuse |
| S1 | Pushbutton: Start motor |
| S2 | Pushbutton: Reset > 4 s |
| S4 | Pushbutton: Stop motor |
| Q1 | Motor starter protector |
| Q11 | 3RW50 soft starter |
| M1 | Motor |
| PE | Protective conductor |

Alternatively, the motor feeder can be assembled as a fuseless or fused version with type of coordination 1 or 2.

A.2.2 Control by switch

Requirements

! WARNING


**Automatic restart.
Can cause death or serious injury.**

If a starting command is pending, a restart will be triggered automatically after the reset. This particularly applies if the motor protection has tripped. Dangerous states of the system can result.

Reset the start command (e.g. via the PLC or switch) before performing a reset.

To do this, for example, link the group error output (terminals 95 and 96) into the control.

Wiring of control circuit for control by switch




- F1 Fuse
- S1 Switch
- S2 Pushbutton: Reset > 4 s
- Q1 Motor starter protector
- Q11 3RW50 soft starter
- M1 Motor
- P1 Indicator light
- P2 Indicator light
- P3 Indicator light

A.2.3 Switching with the control supply voltage

Requirements

Owing to the intrinsic protection, an interval of at least 5 minutes must be allowed to elapse before the device is restarted if the device is switched on and off in normal operation by means of the control supply voltage.



WARNING


**Automatic restart.
Can cause death or serious injury.**

If a starting command is pending, a restart will be triggered automatically after the reset. This particularly applies if the motor protection has tripped. Dangerous states of the system can result.

Reset the start command (e.g. via the PLC or switch) before performing a reset.

To do this, for example, link the group error output (terminals 95 and 96) into the control.

Wiring control circuit on switching with the control supply voltage



F1	Fuse
S1	Switch: Reset > 4 s OFF
Q1	Motor starter protector
Q11	3RW50 soft starter
M1	Motor
P1	Indicator light
P2	Indicator light
P3	Indicator light
PE	Protective conductor

A.2.4 Control by PLC

Requirements

Utilization of a 3RW50...-....4 (24 V) soft starter and power supply with DC voltage.

! WARNING


**Automatic restart.
Can cause death or serious injury.**

If a starting command is pending, a restart will be triggered automatically after the reset. This particularly applies if the motor protection has tripped. Dangerous states of the system can result.


Reset the start command (e.g. via the PLC or switch) before performing a reset.

To do this, for example, link the group error output (terminals 95 and 96) into the control.

Wiring of control circuit for control by PLC



- F1 Fuse
- K1 Coupling relay control for reset > 4 s
- Q1 Motor starter protector
- Q11 3RW50 soft starter
- Q21 PLC
- M1 Motor
- PE Protective conductor



A.2.5 Actuation of a line contactor

Requirements

ON / RUN relay output was parameterized to RUN.



WARNING

Automatic restart.



Can cause death or serious injury.

If a starting command is pending, a restart will be triggered automatically after the reset. This particularly applies if the motor protection has tripped. Dangerous states of the system can result.

Reset the start command (e.g. via the PLC or switch) before performing a reset.

To do this, for example, link the group error output (terminals 95 and 96) into the control.


Wiring of control circuit for controlling a line contactor



- F1 Fuse
- S1 Switch
- S2 Pushbutton: Reset > 4 s
- Q1 Motor starter protector
- Q11 3RW50 soft starter
- Q21 Line contactor
- M1 Motor
- P1 Indicator light
- P3 Indicator light
- PE Protective conductor

A.2.6 Wiring for remote RESET

Procedure



Result



WARNING

Automatic restart.

Can cause death or serious injury.

If a starting command is pending, a restart will be triggered automatically after the reset. This particularly applies if the motor protection has tripped. Dangerous states of the system can result.

Reset the start command (e.g. via the PLC or switch) before performing a reset.

To do this, for example, link the group error output (terminals 95 and 96) into the control.

You can reset a pending error message by operating the reset button for > 4 s.


A.2.7 Connecting the temperature sensor

Requirements

- 3RW50 soft starter with thermistor motor protection
- Motor with temperature switch (e.g. Thermoclick) or thermistor (e.g. PTC type A)

Procedure

1. Remove the copper link between terminals and T11 / T21 and T22.
2. Connect the temperature sensor:



Note

3RW50 soft starter with thermistor motor protection in hazardous areas

Note that the operation of a 3RW50 soft starter with thermistor motor protection in hazardous areas is only possible with a thermistor (e.g. PTC Type A).

You will find additional information on the operation of motors in hazardous areas in Chapters ATEX / IECEx-certified motor overload protection (Page 121) and Thermistor motor protection with temperature sensor (optional) (Page 118).

Result

The 3RW50 soft starter monitors the motor for excessive temperature. The motor is shut down if the maximum temperature limit is exceeded. The setting for RESET MODE determines how the motor is restarted.

A.2.8 Connecting the evaluation unit to the analog output

Requirements

- 3RW50 soft starter with analog output
- Evaluation unit for displaying the analog output signal
- Parameterized analog output
Parameterizing analog output AQ via the High Feature 3RW5 HMI (Page 101)

Procedure


NOTICE

Parasitic voltages, malfunction and property damage

The analog output is galvanically connected to the supply voltage and control input (A1/A2 and IN) of the 3RW50 soft starter. If the analog input of the evaluation unit (e.g. PLC) is connected to the potential of the supply voltage and control input (A1/A2 and IN) of the 3RW50 soft starter, then this can lead to parasitic voltages, malfunctions and/or defect of the soft starter and/or the evaluation unit.

Therefore, make sure that the analog input of the evaluation unit (e.g. PLC) is not connected to the potential of the supply voltage and control input (A1/A2 and IN) of the 3RW50 soft starter.

Connect the evaluation unit:



Result

The actual average phase current of the motor is displayed in % at the evaluation unit via the analog output.

A.3 Special applications

A.3.1 Reversing circuit

Requirements

Soft stopping is not possible. Set the stopping time on the setting element of the 3RW50 soft starter to "0 s" (factory setting).



WARNING

Automatic restart.

Can cause death or serious injury.


If a starting command is pending, a restart will be triggered automatically after the reset. This particularly applies if the motor protection has tripped. Dangerous states of the system can result.

Reset the start command (e.g. via the PLC or switch) before performing a reset.

To do this, for example, link the group error output (terminals 95 and 96) into the control.

Wiring

The example shows the 3RW50 soft starter in the standard circuit.



F1	Fuse
S1	Pushbutton: Motor ON - RIGHT
S2	Pushbutton: Motor ON - LEFT
S4	Pushbutton: Reset > 4 s
Q1	Motor starter protector
Q11	3RW50 Soft Starter
Q21	Contactor right
Q22	Contactor left
P1	Indicator light
M1	Motor
PE	Protective conductor


A.3.2 Wiring for ATEX / IECEx applications with additional line contactor

Requirements

 DANGER
<p>Loss of the certified motor overload protection according to ATEX / IECEx. Risk of death or serious injury.</p> <p>Note that operation in the standard type of motor connection without implementing one of the two following remedial measures results in loss of certified motor overload protection according to ATEX / IECEx.</p> <p>Depending on the structure of the circuit, choose one of the following possibilities for ensuring certified motor overload protection according to ATEX / IECEx:</p> <ul style="list-style-type: none">• Use an additional line contactor in the main circuit. Connect the line contactor at outputs 95, 96 and 98 (output 3).• For a motor feeder configuration with a circuit breaker, use an additional undervoltage trip unit. Connect the undervoltage trip unit at outputs 95, 96 and 98 (output 3). For more information, see Chapter Connections (Page 67).

 WARNING
<p>Automatic restart. Can cause death or serious injury.</p> <p>If a starting command is pending, a restart will be triggered automatically after the reset. This particularly applies if the motor protection has tripped. Dangerous states of the system can result.</p> <p>Reset the start command (e.g. via the PLC or switch) before performing a reset.</p> <p>To do this, for example, link the group error output (terminals 95 and 96) into the control.</p>

Wiring of control circuit for controlling a line contactor



- F1 Fuse
- S1 Switch
- S2 Pushbutton: Reset > 4 s
- Q1 Motor starter protector
- Q11 3RW50 soft starter
- Q21 Line contactor
- M1 Motor
- P1 Indicator light
- P3 Indicator light
- PE Protective conductor

A.3.3 Controlling a motor with a magnetic parking brake

Requirements

ON / RUN relay output was parameterized to RUN.

! WARNING


**Automatic restart.
Can cause death or serious injury.**

If a starting command is pending, a restart will be triggered automatically after the reset. This particularly applies if the motor protection has tripped. Dangerous states of the system can result.

Reset the start command (e.g. via the PLC or switch) before performing a reset.

To do this, for example, link the group error output (terminals 95 and 96) into the control.

Wiring




A.3.4 EMERGENCY STOP shutdown to SIL 1 or PL c with a 3SK1 safety relay

The 3RW50 soft starter has no effect or influence on the safety function of the application. For this reason, it is neither positively nor negatively considered in the safety application, and also does not have to be included in the calculation for proof according to the standards.

If achievement of SILCL 1 according to IEC 62061:2005 or PL c according to EN ISO 13849-1:2015 is required, the series connection of an additional contactor with the 3RW50 soft starter, in conjunction with a suitable safety relay (e.g.: 3SK1111), is required, as well as monitoring of the contactor's auxiliary contacts.

Basic configuration



Requirements

! WARNING

Automatic restart. Can cause death or serious injury.

If a starting command is pending, a restart will be triggered automatically after the reset. This particularly applies if the motor protection has tripped. Dangerous states of the system can result.

Reset the start command (e.g. via the PLC or switch) before performing a reset.


To do this, for example, link the group error output (terminals 95 and 96) into the control.

Tripping of the EMERGENCY STOP circuit


If the soft stop function is set (stopping time setting element set to > 0 s) and the emergency stop circuit is tripped, a "Missing load voltage, phase failure / missing load" fault may be indicated on the 3RW50 soft starter. In this case, the 3RW50 soft starter must be reset according to the selected RESET MODE.

Wiring

Wiring of the 3SK1 safety relay



Wiring of the 3RW50 soft starter




- F1 Fuse
- S1 Switch: Start / stop
- S2 Pushbutton: Reset > 4 s
- Q1 Motor starter protector
- Q11 3RW50 soft starter
- Q21 Contactor
- P1 Indicator light
- P2 Indicator light
- M1 Motor

A.3.5 EMERGENCY STOP shutdown to SIL 3 or PL e with a 3SK1 safety relay

The 3RW50 soft starter has no effect or influence on the safety function of the application. For this reason, it is neither positively nor negatively considered in the safety application, and also does not have to be included in the calculation for proof according to the standards.

Safe shutdown up to SILCL 3 according to IEC 62061:2005 and PL e according to EN ISO 13849-1:2015 requires the use of 2 redundant contactors and monitoring of the auxiliary contacts of both contactors. Two-channel monitoring of the EMERGENCY STOP is also required here.

Basic configuration



- ① Emergency stop
- ② 3RT20 contactors
- ③ 3RW50 soft starter
- ④ Motor
- ⑤ 3SK1 safety relay

Requirements

! WARNING

Automatic restart. Can cause death or serious injury.

If a starting command is pending, a restart will be triggered automatically after the reset. This particularly applies if the motor protection has tripped. Dangerous states of the system can result.

Reset the start command (e.g. via the PLC or switch) before performing a reset.


To do this, for example, link the group error output (terminals 95 and 96) into the control.

Tripping of the EMERGENCY STOP circuit

If the soft stop function is set (stopping time setting element set to > 0 s) and the emergency stop circuit is tripped, a "Missing load voltage, phase failure / missing load" fault may be indicated on the 3RW50 soft starter. In this case, the 3RW50 soft starter must be reset according to the selected RESET MODE.


Wiring

Wiring of the 3SK1 safety relay



- Q21 Contactor
- Q22 Contactor
- S3 Start button
- S4 Emergency stop
- K1 3SK1111 safety relay

Wiring of the 3RW50 soft starter



- F1 Fuse
- S1 Switch: Start / stop
- S2 Pushbutton: Reset > 4 s
- Q1 Motor starter protector
- Q11 3RW50 soft starter
- Q21 Contactor
- Q22 Contactor
- P1 Indicator light
- P2 Indicator light
- M1 Motor

A.3.6 Contactor for emergency start

Requirements

WARNING
--

Automatic restart.

Can cause death or serious injury.

If a starting command is pending, a restart will be triggered automatically after the reset. This particularly applies if the motor protection has tripped. Dangerous states of the system can result.

Reset the start command (e.g. via the PLC or switch) before performing a reset.


To do this, for example, link the group error output (terminals 95 and 96) into the control.

Note


Loss of certified motor overload protection according to ATEX / IECEx / UKEX.

Note that this wiring is not permissible when operating motors in hazardous areas.

Wiring



- F1 Fuse
- S1 Switch
- S2 Pushbutton: Reset > 4 s
- S_n Soft start selector button
- S_{n1} Start / stop (direct-on-line starting)
- Q1 Motor starter protector
- Q11 3RW50 soft starter
- Q21 Direct-on-line starting contactor
- P1 Indicator light, fault
- P2 Indicator light
- P3 Indicator light
- M1 Motor



Glossary

Auto RESET

"Auto RESET" means that faults are automatically reset as soon as the cause is eliminated.

Ground fault

Fault whereby an external conductor comes into contact with ground or the grounded neutral point.

GSD

Generic station description file

This file is required to be able to configure a device as a DP standard slave in the HW Config of a Siemens or external system.

GSDML

Generic station description file

This file is required in order to configure a device as a PN device in the HW Config of a Siemens or external system.

HSP

Hardware support package

The hardware support packages allow you to configure modules that are not listed in the hardware catalog of your TIA Portal installation.

Manual RESET

"Manual RESET" means that the following options are available for acknowledging faults:

- RESET / TEST key on the 3RW50 soft starter
- RESET / TEST key on the 3RW5 HMI Standard
- Reset via bus interface
- Reset via F key on 3RW5 HMI High Feature
- Reset via 3RW5 HMI High Feature

PII / PIQ

Process image input/process image output

Process image

Image of the signal states of the digital inputs and outputs in the memory of a controller.

The process images can be transferred as follows:

- Cyclically in the fieldbus protocol
- Acyclically using data sets

Remote RESET

"Remote RESET" means that faults are acknowledged by switching the control supply voltage off and on again. The control supply voltage on the 3RW50 soft starter must be switched off for at least 4 s.

STS

Simulation Tool for Soft Starters

The soft starter can be configured with the STS (Simulation Tool for Soft Starters) software. The STS suggests suitable soft starters for the application based on the motor and load data and application requirements that you enter.

Index

3

- 3RW5 HMI High Feature, 43
 - Communication diagnostics, 163
 - Control cabinet door, 51
 - Device design and controls, 92
 - Device LEDs, 151
 - Diagnostics of the soft starter, 159
 - Diagnostics on the 3RW5 HMI High Feature, 163
 - Download languages, 144
 - Factory setting, 179
 - Faults and remedial actions, 158
 - Firmware update, 177
 - First commissioning, 108
 - Graphic display of measured values, 134
 - Installing, 51
 - Logbooks, 168
 - Micro SD card, 142
 - Monitoring, 133, 136
 - Mounting, 48, 56
 - Overview, 138
 - Parameter assignment, 104
 - Save service data to micro SD card, 169
- 3RW5 HMI Standard, 42
 - Control cabinet door, 49
 - Device LEDs, 150
 - Hardware configuration, 129
 - Installing, 49
 - Menu, 130
 - Mounting, 48, 54
- 3RW50 soft starter, 57, 71
 - Connecting, 70
 - Device LEDs, 148, 149
 - First commissioning, 107
 - Logbooks, 168
 - Maintenance and repair, 173
 - Mounting, 45, 46
 - Parameter assignment, 84
 - Sealing, 107
 - Setting elements, 81

A

- Actuation of a line contactor, 202
- Additional parameters, 124
- Analog output AQ
 - Parameter assignment, 101

- Applications, 36
- Auto RESET, 87

C

- Catalog, 11
- Circuit diagram example
 - Actuation of a line contactor, 202
 - Connecting the evaluation unit to the analog output, 205
 - Connecting the temperature sensor, 204
 - Contactor for emergency starting, 218
 - Control by PLC, 201
 - Control by pushbutton, 197
 - Control by switch, 198
 - Control of a motor with a magnetic parking brake, 211
 - EMERGENCY STOP shutdown to SIL 1 or PL c with a 3SK1 safety relay, 212
 - EMERGENCY STOP shutdown to SIL 3 or PL e with a 3SK1 safety relay, 214
 - Feeder assembly, type of coordination 1 fuseless, 193
 - Feeder assembly, type of coordination 1 with fuses, 194
 - Feeder assembly, type of coordination 2, 195
 - Reversing circuit, 207
 - Switching with the control supply voltage, 199
 - Wiring for ATEX / IECEx applications with additional line contactor, 209
 - Wiring for remote RESET, 204
- COM connecting cable
 - Connecting, 62
 - Connection, 61
 - Pull out, 63, 64
- COM connection cable, 40
- Communication modules, 39
- Connect the HMI connecting cable, 48
- Connecting the evaluation unit to the analog output, 205
- Connecting the temperature sensor, 204
- Connections
 - Overview, 67
- Contactor for emergency starting, 218
- Control by PLC, 201
- Control by pushbutton, 197
- Control by switch, 198
- Control of a motor with a magnetic parking brake, 211

Control via digital input, 89, 127

D

Data transfer, 27
Device change, 181
 Micro SD card, 182
 SIRIUS Soft Starter ES (TIA Portal), 183
Device versions, 34
Device-related information, 138
Diagnostics options, 147
Drilling pattern, 189

E

Electronic motor overload protection, 117
EMERGENCY STOP shutdown to SIL 1 or PL c with a 3SK1 safety relay, 212
EMERGENCY STOP shutdown to SIL 3 or PL e with a 3SK1 safety relay, 214

F

Factory setting, 178
 3RW5 HMI High Feature, 179
 Master RESET key, 180
 MODE and RESET / TEST keys, 180
 Options, 178
 Restore, 181
Fan cover
 Mounting, 45
FAQs, 11
Faults and remedial actions, 153
 3RW5 HMI High Feature, 158
Feeder assembly, type of coordination 1 fuseless, 193
Feeder assembly, type of coordination 1 with fuses, 194
Feeder assembly, type of coordination 2, 195
Firmware update, 21, 176
Function test, 164
Functions, 25
 Additional parameters, 124
 Control via digital input, 127
 Current limiting function, 113
 Soft starting, 111, 115
 Thermistor motor protection with temperature sensor, 118

G

Graphic display of measured values
 Bar chart, 134
 Line chart, 134

H

Hinged cover
 Replacing, 57
History, 23

I

I&M data, 138
Interaction interfaces, 27
Intrinsic device protection, 119

K

Knowledge, 23

L

LED test, 164
LEDs
 Status and error displays, 149
Local access protection (PIN), 139
 Change, 141
 Defining, 140
 Delete, 142
Logbooks, 168

M

Main circuit connection (mains supply / motor)
 Connecting, 71
Main circuit connections
 Mounting, 74
Main menu
 Micro SD card, 142
 Monitoring, 136
Maintenance, 173
Manual RESET, 87
Manuals, 11
Master RESET key
 Factory setting, 180

- Measured values
 - Monitoring, 133
- Messages and diagnosis
 - Communication diagnostics, 163
 - Diagnostics on the 3RW5 HMI High Feature, 163
 - Faults and remedial actions of the 3RW5 HMI High Feature, 158
 - Logbooks, 168
 - Status and error displays, 149
- Micro SD card, 142
- Micro SD card, 177
- Mode, 29
- MODE and RESET / TEST keys
 - Factory setting, 180
- Monitoring
 - Measured values, 133
 - Process image, 136
- Motor protection
 - Full motor protection, 116
 - Motor overload protection, 117
 - Thermistor motor protection with temperature sensor, 118
- Mounting
 - On a level surface, 58

O

- Online help, 11
- Output 13 / 14
 - Parameter assignment, 88
- Output 13, 14
 - Parameter setting, 89
- Output signal ON or RUN, 88
- Overview
 - Device-related information, 138

P

- Parameter
 - Additional parameters, 124
 - Control via digital input, 127
 - Overview, 83
- Process image
 - Monitoring, 136
- Push-in lugs, 40

R

- Reactive power compensation, 17
- References, 11
- Remote RESET, 87

- Removing
 - On a level surface, 60
- Repairs, 173
- Replacing
 - Control terminals, 79
 - Terminals, 72
- RESET MODE, 85
- Response to bus errors, 89
- Reversing circuit, 207

S

- Save service data to micro SD card, 169
- Screw terminals
 - Connecting, 75
 - Control current, 76
- Self-test (user-test), 164
- Setting the mode, 31
- Simulation Tool for Soft Starters, 37
- SIRIUS Soft Starter ES (TIA Portal), 40
- Soft torque, 85, 119
- Spring-type terminal
 - Connecting, 77
- Spring-type terminals
 - Control current, 78
- STATE / OVERLOAD LED, 150
- Status and error displays, 149
- Status graphs, 69
- Structure of the article number, 37
- Suggested settings, 84
- Switching with the control supply voltage, 199

T

- Target group, 23
- Terminal covers, 74
- Test
 - Current acquisition, 164
 - Motor overload protection, 164
- Test with small load, 126
- Thermistor motor protection with temperature sensor, 118

W

- Warnings and remedial measures, 152
- Wiring for ATEX / IECEx applications with additional line contactor, 209
- Wiring for remote RESET, 204

