User Manual

Revision 1.001
English

S7comm / PROFIBUS Slave - Converter

(Order Code: HD67619-A1)

For Website information:
http://www.adfweb.com/?Product=HD67619

For Price information:
http://www.adfweb.com/?Price=HD67619-A1

Benefits and Main Features:

- Triple electrical isolation
- Two Ethernet ports
- Temperature range: -40°C/+85°C (-40°F/+185°F)

For others S7comm devices, see also the following links:

S7comm from/to ...

www.adfweb.com?Product=HD67618	(**Modbus TCP Slave**)
www.adfweb.com?Product=HD67620	(**IEC61850 Server**)
www.adfweb.com?Product=HD67621	(**Serial**)
www.adfweb.com?Product=HD67622	(**Modbus Slave**)
www.adfweb.com?Product=HD67623	(**CAN**)
www.adfweb.com?Product=HD67624	(**CANopen**)
www.adfweb.com?Product=HD67625	(**DeviceNet Slave**)
www.adfweb.com?Product=HD67626	(**SNMP Agent**)
www.adfweb.com?Product=HD67627	(**EtherNet/IP Slave**)
www.adfweb.com?Product=HD67628	(**KNX**)
www.adfweb.com?Product=HD67629	(**MQTT**)
www.adfweb.com?Product=HD67630	(**BACnet Slave**)
www.adfweb.com?Product=HD67631	(**Ethernet**)
www.adfweb.com?Product=HD67632	(**OPC UA Server**)
www.adfweb.com?Product=HD67633	(**PROFINET Slave**)

Do you have an your customer protocol?
See the following links:
www.adfweb.com?Product=HD67003

Do you need to choose a device? do you want help?
Ask it to the following link:
www.adfweb.com?Cmd=helpme

User Manual

INDEX:

	Page
INDEX	2
UPDATED DOCUMENTATION	2
REVISION LIST	2
WARNING	2
TRADEMARKS	2
SECURITY ALERT	3
EXAMPLE OF CONNECTION	4
CONNECTION SCHEME	5
CHARACTERISTICS	6
CONFIGURATION	6
POWER SUPPLY	7
FUNCTION MODES	8
LEDS	9
PROFIBUS	10
ETHERNET	10
USE OF COMPOSITOR SW67619	11
NEW CONFIGURATION / OPEN CONFIGURATION	12
SOFTWARE OPTIONS	13
SET COMMUNICATION	15
S7comm ACCESS	16
GSD FILE	20
UPDATE DEVICE	21
MECHANICAL DIMENSIONS	23
ORDERING INFORMATIONS	24
ACCESSORIES	24
DISCLAIMER	25
OTHER REGULATIONS AND STANDARDS	25
WARRANTIES AND TECHNICAL SUPPORT	26
RETURN POLICY	26

UPDATED DOCUMENTATION:

Dear customer, we thank you for your attention and we remind you that you need to check that the following document is:

- Updated
- Related to the product you own

To obtain the most recently updated document, note the "document code" that appears at the top right-hand corner of each page of this document.

With this "Document Code" go to web page www.adfweb.com/download/ and search for the corresponding code on the page. Click on the proper "Document Code" and download the updates.

REVISION LIST:

Revision	Date	Author	Chapter	Description
1.000	13/03/2020	Ff	All	First release version
1.001	28/07/2025	Mdb	All	New design

WARNING:

ADFweb.com reserves the right to change information in this manual about our product without warning.
ADFweb.com is not responsible for any error this manual may contain.

TRADEMARKS:

All trademarks mentioned in this document belong to their respective owners.

SECURITY ALERT:

GENERAL INFORMATION

To ensure safe operation, the device must be operated according to the instructions in the manual. When using the device, legal and safety regulation are required for each individual application. The same applies also when using accessories.

INTENDED USE

Machines and systems must be designed so the faulty conditions do not lead to a dangerous situation for the operator (i.e. independent limit switches, mechanical interlocks, etc.).

QUALIFIED PERSONNEL

The device can be used only by qualified personnel, strictly in accordance with the specifications.
Qualified personnel are persons who are familiar with the installation, assembly, commissioning and operation of this equipment and who have appropriate qualifications for their job.

RESIDUAL RISKS

The device is state-of-the-art and is safe. The instruments can represent a potential hazard if they are inappropriately installed and operated by untrained personnel. These instructions refer to residual risks with the following symbol:




This symbol indicates that non-observance of the safety instructions is a danger for people that could lead to serious injury or death and / or the possibility of damage.

CE CONFORMITY

The declaration is made by our company. You can send an email to support@adfweb.com or give us a call if you need it.

EXAMPLE OF CONNECTION:



CONNECTION SCHEME:




Figure 1: Connection scheme for HD67619-A1

CHARACTERISTICS:

The HD67619-A1 is a S7comm / PROFIBUS slave Converter.

It allows the following characteristics:

- Two-directional information between S7comm and PROFIBUS;
- Mountable on 35mm Rail DIN;
- Wide power supply input range: 8…24V AC or 12…35V DC;
- Wide temperature range: -40°C / +85°C [-40°F / +185°F].

CONFIGURATION:

You need Compositor SW67619 software on your PC in order to perform the following:

- Define the parameter of the PROFIBUS;
- Define the parameter of the S7comm;
- Define the S7comm requests to send to the S7comm servers;
- Update the device.

POWER SUPPLY:


The devices can be powered between a wide range of tensions. For more details see the two tables below.

	VAC ~		VDC ⎓	
	Vmin	**Vmax**	**Vmin**	**Vmax**
HD67619-A1	**8V**	**24V**	**12V**	**35V**


Consumption at 24V DC:

Device	W/VA
HD67619-A1	4

Caution: Not reverse the polarity power



HD67619-A1




FUNCTION MODES:

The device has got two functions mode depending of the position of the Dip2 of 'Dip-Switch A':

- The first, with Dip2 in Off position (factory setting), is used for the normal working of the device.
- The second, with Dip2 in On position, is used for upload the Project/Firmware.

For the operations to follow for the updating (see 'UPDATE DEVICE' section).


According to the functioning mode, the LEDs will have specifics functions (see 'LEDS' section).



LEDS:

The device has got six LEDs that are used to give information of the functioning status.
The various meanings of the LEDs are described in the table below.

LED	Normal Mode	Boot Mode
1: ON [supply voltage] (green)	**ON:** Device powered **OFF:** Device not powered	**ON:** Device powered **OFF:** Device not powered
2: Device State (green)	Blinks slowly (~1Hz)	**Blinks quickly:** Boot state **Blinks very slowly (~0.5Hz):** update in progress
3: PROFIBUS comm. (green)	Blinks when PROFIBUS communication is running	**Blinks quickly:** Boot state **Blinks very slowly (~0.5Hz):** update in progress
4: S7comm comm. (green)	Blinks when a S7comm response is received	**Blinks quickly:** Boot state **Blinks very slowly (~0.5Hz):** update in progress
5: Ethernet1 Tx (green)	Blinks when it is transmitting Ethernet frames	**Blinks quickly:** Boot state **Blinks very slowly (~0.5Hz):** update in progress
6: Ethernet2 Tx (green)	Blinks when it is transmitting Ethernet frames	**Blinks quickly:** Boot state **Blinks very slowly (~0.5Hz):** update in progress




PROFIBUS:

The PROFIBUS uses a 9-pin D-SUB connector. The pin assignment is defined like in the right figure.


Here some codes of cables:

- Belden: p/n 183079A - Continuous Armor DataBus® ISA/SP-50 PROFIBUS Cable.



ETHERNET:

The Ethernet connection must be made using Connector3 or Connector4 of HD67619-A1 with at least a Category 5E cable. The maximum length of the cable should not exceed 100m. The cable has to conform to the T568 norms relative to connections in cat.5 up to 100 Mbps. To connect the device to an Hub/Switch is recommended the use of a straight cable, to connect the device to a PC/PLC/other is recommended the use of a cross cable.



USE OF COMPOSITOR SW67619:

To configure the Converter, use the available software that runs with Windows called SW67619. It is downloadable on the site www.adfweb.com and its operation is described in this document. *(This manual is referenced to the last version of the software present on our web site)*. The software works with MSWindows (XP, Vista, Seven, 8, 10 or 11; 32/64bit).

When launching the SW67619, the window below appears (Fig. 2).

Note:
It is necessary to have installed .Net Framework 4.





Figure 2: Main window for SW67619


NEW CONFIGURATION / OPEN CONFIGURATION:

The "**New Configuration**" button creates the folder which contains the entire device's configuration.



A device's configuration can also be imported or exported:

- To clone the configurations of a programmable "S7comm / PROFIBUS Slave - Converter" in order to configure another device in the same manner, it is necessary to maintain the folder and all its contents;
- To clone a project in order to obtain a different version of the project, it is sufficient to duplicate the project folder with another name and open the new folder with the button "**Open Configuration**".




SOFTWARE OPTIONS:


By pressing the "**Settings**" ( ) button there is the possibility to change the language of the software and check the updatings for the compositor.

In the section "Language" it is possible to change the language of the software.





In the section "Connection Options", it is possible to check if there are some updatings of the software compositor in ADFweb.com website.
Checking the option "**Check Software Update at Start of Program**", the SW67619 check automatically if there are updatings when it is launched.



In the section "Software Settings", it is possible to enable/disable some keyboard's commands for an easier navigation inside the tables contained in the different sections of the software.

SET COMMUNICATION:

This section define the fundamental communication parameters of two buses, PROFIBUS and S7comm.

By Pressing the "**Set Communication**" button from the main window for SW67619 (Fig. 2) the window "Set Communication" appears (Fig. 3).

The means of the fields for "S7comm" are:

- In the fields "**IP Address**" the IP address for S7comm side of the converter is defined;
- In the fields "**SubNet Mask**" the SubNet Mask for S7comm side of the converter is defined;
- In the fields "**Gateway**" the default gateway of the net is defined. This feature can be enabled or disabled pressing the Check Box field. This feature is used for going out of the net.

The means of the fields for "PROFIBUS" are:

- In the field "**ID Device**" the ID of PROFIBUS side of the converter is defined;
- In the field "**Baudrate**" the data rate used for PROFIBUS communication is defined (fixed to 'Auto Baudrate');
- In the field "**Number Byte In**" the number of Input bytes of PROFIBUS side of the converter is defined;
- In the field "**Number Byte Out**" the number of Output bytes of PROFIBUS side of the converter is defined.




Figure 3: "Set Communication" window

S7comm ACCESS:

By Pressing the "**S7comm Access** " button from the main window of SW67619 (Fig. 2), the window "Set S7comm Access" appears (Fig. 4). The window is divided in two parts, the "**S7comm Read**" that contains the data that the converter reads from the S7comm servers and "**S7comm Write**" that contains the data that the converter writes into the S7comm servers.





Figure 4a: "S7 Protocol Access → S7comm Read" window

The means of the fields in the window "S7comm Read" are the following:

- If the option "**Enable**" is checked, the S7comm variable is enabled;
- In the field "**PLC Address**" the IP address of the PLC that contains the data to be read is defined;
- In the field "**PLC Port**" the port used for S7comm communication is defined;
- In the field "**PLC Type**" the family of the PLC is defined;
- In the field "**Rack**" the Rack's ID of the PLC is defined;
- In the field "**Slot**" the Slot's ID is defined;
- In the field "**Data Type**" the data format of the variable to read is defined;
- In the field "**Data Identifier**" the identifier of the variable to read is defined;
- In the field "**DB Number**" the number of the DB of the PLC to read is defined;
- In the field "**PLC Area**" the memory area where the data is located inside the PLC is defined;
- In the field "**PLC Add**" the starting memory address where the data is located is defined;
- In the field "**PLC Bit**" the starting bit of the selected PLC Address is defined;
- In the field "**Poll Time**" the frequency of the request is defined (in ms);

- In the field "**Position**" the starting byte of the PROFIBUS array from which mapping the data read is defined;
- In the field "**Start Bit**" is used for the "Bit" data. It is possible to select the bit of the selected Position where mapping the data;
- If the field "**Swap**" is checked, the bytes' order is reversed;
- If the field "**Swap W**" is checked, the words' order is reversed;
- In the field "**Mnemonic**" a description of the data inserted in the row is defined.



N	Enable	PLC Address	PLC Port	PLC Type	Rack	Slot	Data Type	Data Identifier	DB Number	PLC Area	PLC Add	PLC Bit	Poll Time	On Change	On CMD	Position	Start Bit	Swap	Swap Word	Mnemonic
1	☑	192.168.2.60	1001	Logo0BA8	0	0	Bit	OB	0	Direct peripheral	0	0	1000	☐	☐	0	0	☐	☐	
2	☑													☐	☐			☐	☐	
3	☑													☐	☐			☐	☐	
4	☑													☐	☐			☐	☐	
5	☑													☐	☐			☐	☐	

Figure 4b: "S7 Protocol Access → S7comm Write" window

The means of the fields in the window "S7comm Read" are the following:

- If the option "**Enable**" is checked, the S7comm variable is enabled;
- In the field "**PLC Address**" the IP address of the PLC that contains the data to be read is defined;
- In the field "**PLC Port**" the port used for S7comm communication is defined;
- In the field "**PLC Type**" the family of the PLC is defined;
- In the field "**Rack**" the Rack's ID of the PLC is defined;
- In the field "**Slot**" the Slot's ID is defined;
- In the field "**Data Type**" the data format of the variable to read is defined;
- In the field "**Data Identifier**" the identifier of the variable to read is defined;
- In the field "**DB Number**" the number of the DB of the PLC to read is defined;
- In the field "**PLC Area**" the memory area where the data is located inside the PLC is defined;
- In the field "**PLC Add**" the starting memory address where the data is located is defined;
- In the field "**PLC Bit**" the starting bit of the selected PLC Address is defined;
- In the field "**Poll Time**" the frequency of the request is defined (in ms);
- By checking the field "**On Change**" the S7comm write request is sent only if PROFIBUS data are changed;
- By checking the field "**On CMD**" the S7comm write request is sent when a PROFIBUS writing for the selected variable is received;
- In the field "**Position**" the starting byte of the PROFIBUS array from which taking the data to write is defined;
- The field "**Start Bit**" is used for the "Bit" data. It is possible to select the bit of the selected Position from which taking the data;
- If the field "**Swap**" is checked, the bytes' order is reversed;

- If the field "**Swap W**" is checked, the words' order is reversed;
- In the field "**Mnemonic**" a description of the data inserted in the row is defined.

GSD FILE:

By pressing the "***GSD File***" button it is possible to save the GSD file for the PROFIBUS side.
With this feature you can save the configuration of the gateway of the PROFIBUS side.

Note:
When you import the .gsd file on your Master PROFIBUS you have to add all the modules that are present inside it.

UPDATE DEVICE:

By pressing the "**Update Device**" button, it is possible to load the created Configuration into the device; and also the Firmware, if necessary. This by using the Ethernet port.

If you don't know the actual IP address of the device you have to use this procedure:

- Turn OFF the Device;
- Put Dip2 of 'Dip-Switch A' in ON position;
- Turn ON the device
- Connect the Ethernet cable;
- Insert the IP "**192.168.2.205**";
- Select which operations you want to do;
- Press the "**Execute update firmware**" button to start the upload;
- When all the operations are "OK" turn OFF the Device;
- Put Dip2 of 'Dip-Switch A' in OFF position;
- Turn ON the device.




Figure 5: "Update device" windows

If you know the actual IP address of the device, you have to use this procedure:

- Turn ON the Device with the Ethernet cable inserted;
- Insert the actual IP of the Converter;
- Select which operations you want to do;
- Press the "**Execute update firmware**" button to start the upload;
- When all the operations are "OK" the device automatically goes at Normal Mode.

At this point the configuration/firmware on the device is correctly updated.

Note:
When you receive the device, for the first time, you also have to update the Firmware in the HD67619 device.

Warning:
If Fig. 6 appears when you try to do the Update try these points before seeking assistance:

- Try to repeat the operations for the updating;
- Try with another PC;
- Try to restart the PC;
- Check the LAN settings;
- If you are using the program inside a Virtual Machine, try to use in the main Operating System;
- If you are using Windows Seven, Vista, 8, 10 or 11 make sure that you have the administrator privileges;
- In case you have to program more than one device, using the "UDP Update", you have to cancel the ARP table every time you connect a new device on Ethernet. For do this you have to launch the "Command Prompt" and write the command "arp -d". Pay attention that with Windows Vista, Seven, 8, 10 or 11 you have to launch the "Command Prompt" with Administrator Rights;
- Pay attention at Firewall lock.




Figure 6: "Error" window

Warning:
In the case of HD67619 you have to use the software "SW67619": www.adfweb.com\download\filefold\SW67619.zip.

MECHANICAL DIMENSIONS:




Figure 7: Mechanical dimensions scheme for HD67619-A1

ORDERING INFORMATIONS:

The ordering part number is formed by a valid combination of the following:

HD67619 – A 1

Connectors Type
1: Removable 5mm Screw Terminal

Enclosure Type
A: 1M, 35mm DIN Rail mounting

Device Family
HD67619: S7comm / PROFIBUS Slave - Converter

Order Code: **HD67619-A1** - S7comm / PROFIBUS Slave - Converter

ACCESSORIES:

Order Code: **AC34011** - Rail DIN - Power Supply 220/240V AC 50/60Hz – 12 V DC
Order Code: **AC34012** - Rail DIN - Power Supply 220/240V AC 50/60Hz – 24 V DC

DISCLAIMER:

All technical content within this document can be modified without notice. The content of the document is a under continual renewal.
For losses due to fire, earthquake, third party access or other accidents, or intentional or accidental abuse, misuse, or use under abnormal conditions repairs are charged to the user. ADFweb.com S.r.l. will not be liable for accidental loss of use or inability to use this product, such as loss of business income. ADFweb.com S.r.l. shall not be liable for consequences of improper use.

OTHER REGULATIONS AND STANDARDS:

WEEE INFORMATION



Disposal of old electrical and electronic equipment (as in the European Union and other European countries with separate collection systems).
This symbol on the product or on its packaging indicates that this product may not be treated as household rubbish. Instead, it should be taken to an applicable collection point for the recycling of electrical and electronic equipment. If the product is disposed correctly, you will help prevent potential negative environmental factors and impact of human health, which could otherwise be caused by inappropriate disposal. The recycling of materials will help to conserve natural resources. For more information about recycling this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

RESTRICTION OF HAZARDOUS SUBSTANCES DIRECTIVE

The device respects the 2002/95/EC Directive on the restriction of the use of certain hazardous substances in electrical and electronic equipment (commonly referred to as Restriction of Hazardous Substances Directive or RoHS).

CE MARKING

The product conforms with the essential requirements of the applicable EC directives.

WARRANTIES AND TECHNICAL SUPPORT:

For fast and easy technical support for your ADFweb.com SRL products, consult our internet support at www.adfweb.com.
Otherwise contact us at the address support@adfweb.com

RETURN POLICY:

If while using your product you have any problem and you wish to exchange or repair it, please do the following:

- Obtain a Product Return Number (PRN) from our internet support at www.adfweb.com. Together with the request, you need to provide detailed information about the problem.
- Send the product to the address provided with the PRN, having prepaid the shipping costs (shipment costs billed to us will not be accepted).

If the product is within the warranty of twelve months, it will be repaired or exchanged and returned within three weeks. If the product is no longer under warranty, you will receive a repair estimate.

ADFweb.com S.r.l.
Via Strada Nuova, 17
IT-31010 Mareno di Piave
TREVISO (Italy)
Phone +39.0438.30.91.31
Fax +39.0438.49.20.99
www.adfweb.com