EXTERNAL LINKS

QR of Manual

www.adfweb.com/download/
filefold/MN67B78_ENG.pdf

BOX SHEET

PROFINET Master / EtherNet/IP Slave Converter

QR of Box-Sheet

www.adfweb.com/download/
filefold/BS67B78-A1_ENG.pdf

Box Sheet for Order code: HD67B78-A1
Document code: BS67B78-A1
V1.100


QR of Software

www.adfweb.com/download/
filefold/SW67B78.zip

ADFweb.com srl
Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

CONNECTION SCHEME

Order code: HD67B78-A1



Order code: HD67B78-A1