EXTERNAL LINKS

QR of Manual

www.adfweb.com/download/
filefold/MN67E52_ENG.pdf

QR of Box-Sheet

www.adfweb.com/download/
filefold/BS67E52-5-A1_ENG.pdf

QR of Software

www.adfweb.com/download/
filefold/SW67E52.zip

BOX SHEET


EtherCAT Master / Modbus Slave Converter

Box Sheet for Order code: HD67E52-5-A1
Document code: BS67E52-5-A1
V1.001

ADFweb.com srl
Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

CONNECTION SCHEME

Order code: HD67E52-5-A1



Order code: HD67E52-5-A1