Electronic Devices

Modbus TCP Slave / SNMP Manager - Converter


To obtain the complete manual please go to

www.adfweb.com/download/filefold/MN67176_ENG.pdf

To obtain the new version of this box sheet please go to

www.adfweb.com/download/filefold/BS67176-A1_ENG.pdf

CONNECTION SCHEME:



CONFIGURATION SOFTWARE:

For setting up the device you need the software named SW67176.
To obtain this software please go to

www.adfweb.com/download/filefold/SW67176.zip

ADFweb.com S.r.l.
www.adfweb.com
support@adfweb.com

Manual	Box-Sheet	Software