

Difference in 2 Segment and 3 Segment Models

2 Segment Display Emulator	3 Segment Display Emulator
	
Supports data upto **100 floppies** on single USB Flash Drive Unit Switch moves thru – 01 , 02 --- 09 Tens Switch Moves thry – 10 , 20 --- 90	Supports data upto **1000 floppies** on single USB Flash Drive Unit Switch moves thru – 01 , 02 --- 09 Tens Switch Moves thry – 10 , 20 --- 90 **Hundred Counter will move when both Unit + Tens switches are pressed.** Hundred Counter Moves thru– 000, 100—900
DOTS in between Segments **disappear** when USB Pen drive is plugged in.	DOTS in between Segments **DO NOT disappear** when USB Pen drive is plugged in.
The Busy LED is **GREEN** in colour	The Busy LED is **RED** in colour
Rest all the functionalities of the emulators will remain the same as 3 Segment models	Rest all the functionalities of the emulators will remain the same as 2 Segment models