EXTERNAL LINKS

QR of Manual

www.adfweb.com/download/filefold/MN67E16_ENG.pdf

QR of Box-Sheet

www.adfweb.com/download/filefold/BS67E16-A1_ENG.pdf

QR of Software

www.adfweb.com/download/filefold/SW67E16.zip

BOX SHEET

EtherCAT Slave / J1939 - Converter


Box Sheet for Order code: **HD67E16-A1**
Document code: **BS67E16-A1**
V2.001

ADFweb.com srl

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

CONNECTION SCHEME

Order code: **HD67E16-A1**



Order code: **HD67E16-A1**