EXTERNAL LINKS



QR of Manual

www.adfweb.com/download/
filefold/MN67B71_ENG.pdf

BOX SHEET

PROFINET Master / Modbus Slave Converter



QR of Box-Sheet

www.adfweb.com/download/
filefold/BS67B71-485-A1_ENG.pdf

Box Sheet for Order code: HD67B71-485-A1
Document code: BS67B71-485-A1
V1.100



QR of Software


www.adfweb.com/download/
filefold/SW67B71.zip

ADFweb.com srl
Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

www.ADFweb.com

CONNECTION SCHEME

Order code: HD67B71-485-A1



Order code: HD67B71-485-A1