EXTERNAL LINKS

QR of Manual

www.adfweb.com/download/
filefold/MN67E01_ENG.pdf

QR of Box-Sheet

www.adfweb.com/download/
filefold/BS67E01-5-A1_ENG.pdf

QR of Software

www.adfweb.com/download/
filefold/SW67E01.zip

BOX SHEET

EtherCAT Slave / Modbus Master - Converter


Box Sheet for Order code: **HD67E01-5-A1**
Document code: **BS67E01-5-A1**
V2.000

ADFweb.com srl

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

CONNECTION SCHEME

Order code: **HD67E01-5-A1**



Order code: **HD67E01-5-A1**