EXTERNAL LINKS



QR of Manual

www.adfweb.com/download/
filefold/MN67E77_ENG.pdf

BOX SHEET

EtherCAT Master / Ethernet IP slave Converter



QR of Box-Sheet

www.adfweb.com/download/
filefold/BS67E77-A1_ENG.pdf

Box Sheet for Order code: HD67E77-A1
Document code: BS67E77-A1
V1.001




QR of Software

www.adfweb.com/download/
filefold/SW67E77.zip

ADFweb.com srl
Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

CONNECTION SCHEME

Order code: HD67E77-A1



Order code: HD67E77-A1