EXTERNAL LINKS

QR of Manual

www.adfweb.com/download/filefold/MN67C05_ENG.pdf

QR of Box-Sheet

www.adfweb.com/download/filefold/BS67C05-5-B2_ENG.pdf

QR of Software

www.adfweb.com/download/filefold/SW67C05_ENG.pdf

BOX SHEET


Modbus Slave / MQTT Broker Converter

Box Sheet for Order code: HD67C05-5-B2
Document code: BS67C05-5-B2
V1.000

ADFweb.com srl
Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

CONNECTION SCHEME

Order code: HD67C05-5-B2



Order code: HD67C05-5-B2